Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nedis HTFA15BK

Nedis HTFA15BK Ceramic Fan Heater User Manual

Model: HTFA15BK | Brand: Nedis

1. Introduction

Thank you for purchasing the Nedis HTFA15BK Ceramic Fan Heater. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read these instructions carefully before use and retain them for future reference.

The Nedis HTFA15BK is a compact ceramic fan heater designed to provide supplemental heating for small areas up to 5 m². It features a 500W ceramic PTC heating element, an adjustable thermostat for consistent temperature control, and integrated safety mechanisms including tip-over protection and overheat protection.



Figure 1: Front view of the Nedis HTFA15BK Ceramic Fan Heater. The heater features a black spherical design with a metal grille and an indicator light.

2. Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.

- Read all instructions before using this heater.
- Do not use this heater in the immediate vicinity of a bath, shower, or swimming pool.
- Do not use this heater if it has been dropped.
- Do not use if there are visible signs of damage to the heater.
- Use this heater on a horizontal and stable surface.
- Keep combustible materials such as furniture, curtains, and other flammable items at least 1 meter (3 feet) from

the front, sides, and rear of the heater.

- Do not use this heater with a programmer, timer, separate remote-control system, or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- This heater is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the heater by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the heater.
- Unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- The heater is equipped with a tip-over safety switch. If the heater is accidentally tipped over, it will automatically shut off.
- The heater is equipped with an overheat protection system. If the heater reaches an unsafe temperature, it will automatically shut off.

3. Product Components



Figure 2: Top view showing the control knob for adjusting the thermostat. The 'Nedis' logo is visible on the top surface.

1. Air Outlet Grille (Front)
2. Power Indicator Light
3. Thermostat Control Knob (Top)
4. Air Inlet Grille (Rear)
5. Power Cord and Plug
6. Tip-Over Safety Switch (Bottom)



Figure 3: Rear view of the heater, showing the air inlet grille and the attached power cord with a European-style plug.

4. Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for storage or disposal.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater from walls, furniture, and other objects. Do not place it on soft surfaces like carpets or rugs that might block the air inlet.
3. **Power Connection:** Ensure the heater is switched off (thermostat knob turned to minimum/off position). Plug the power cord into a suitable grounded electrical outlet. Ensure the outlet voltage matches the heater's requirements (refer to specifications).



Figure 4: The heater positioned in a room, demonstrating appropriate placement away from furniture and bedding.

5. Operating Instructions

1. **Power On:** Plug the heater into a power outlet. The power indicator light (usually red) will illuminate, indicating the unit is receiving power.
2. **Set Temperature:** Turn the thermostat control knob clockwise towards the "MAX" setting. The heater will begin to emit warm air.
3. **Adjusting Thermostat:** Once the room reaches your desired temperature, slowly turn the thermostat control knob counter-clockwise until the heater turns off. The heater will now cycle on and off automatically to maintain the set temperature.
4. **Power Off:** To turn off the heater, turn the thermostat control knob fully counter-clockwise to the minimum/off position. Unplug the heater from the wall outlet when not in use for extended periods.

Safety Features:

- **Tip-Over Protection:** The heater is equipped with an internal switch that automatically shuts off the unit if it is tipped over. To resume operation, place the heater upright on a stable surface.



Figure 5: Close-up of the heater's base, illustrating the tip-over safety switch mechanism. This switch automatically deactivates the heater if it is not upright.

- **Overheat Protection:** If the heater's internal components reach an unsafe temperature, the overheat protection system will automatically shut off the unit. If this occurs, unplug the heater, allow it to cool down for at least 30 minutes, and check for any obstructions to the air inlets or outlets before restarting.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your heater.

- **Cleaning:**

- Always unplug the heater and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet grilles.
- Never immerse the heater in water or any other liquid.

- **Storage:**
  - When not in use, store the heater in a cool, dry place.
  - It is recommended to store the heater in its original packaging to protect it from dust and damage.

7. Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	• Not plugged in. • Power outlet not working. • Thermostat set too low. • Tip-over switch activated. • Overheat protection activated.	• Ensure the power cord is securely plugged into a working outlet. • Test the outlet with another appliance. • Turn the thermostat knob clockwise to a higher setting. • Ensure the heater is on a flat, stable surface and upright. • Unplug, allow to cool for 30 minutes, and check for obstructions before restarting.
Heater produces insufficient heat.	• Thermostat set too low. • Room size too large for heater capacity. • Air inlets/outlets blocked.	• Increase the thermostat setting. • This heater is designed for small areas (up to 5 m^2). • Ensure grilles are clear of dust and obstructions.
Heater suddenly stops working.	• Overheat protection activated. • Tip-over switch activated.	• Unplug, allow to cool for 30 minutes, and check for obstructions before restarting. • Ensure the heater is on a flat, stable surface and upright.

8. Specifications

Brand	Nedis
Model Number	HTFA15BK
Type	Ceramic Fan Heater
Heat Output	500 Watts
Heating Method	Convection (PTC Ceramic Element)
Special Features	Rapid heating, Electronic Thermostat, Energy-efficient, Overheat Protection, Tip-over Protection

Color	Black
Product Dimensions (L x W x H)	15.5 x 11.5 x 16 cm (approximately 6.1 x 4.5 x 6.3 inches)
Item Weight	9.32 Kilograms
Power Source	Corded Electric
Mounting Type	Table Mount



Figure 6: Dimensions of the Nedis HTFA15BK Ceramic Fan Heater, showing its compact size.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4KDZM1T

More documents and user manuals: **https://manuals.plus/**