Manuals+
Q & A | Deep Search | Upload

AM alphamount APFS01

AM alphamount TV Floor Stand User Manual

Model: APFS01

Introduction

Thank you for choosing the AM alphamount TV Floor Stand. This manual provides essential information for the safe and efficient use of your new TV stand. Please read it thoroughly before assembly and operation.
This portable TV stand is designed to accommodate most 13-50 inch flat or curved TVs and monitors, supporting weights up to 44 lbs. It features 8 levels of height adjustment, flexible tilt, and screen leveling functions for optimal viewing.

Image: The AM alphamount TV Floor Stand, a black, minimalist stand supporting a large flat-screen television. The stand features a sturdy base and a central pole that holds the TV mount.

Product Features

- **Wider TV Compatibility:** Fits most 13-50 inch flat/curved TVs and monitors, compatible with major brands. Supports up to 44 lbs with VESA patterns from 75x75mm to 200x200mm.

Image: A visual representation of the TV stand's compatibility, showing a TV mounted on the stand with text overlays indicating "Fits TVs 13"-50"" and "Weight Capacity 44 lbs". Below, a list of supported VESA patterns is displayed.

- **8 Level Height Adjustment:** Adjust the screen height from 42.87 inches to 53.89 inches for optimal viewing.

Image: Two TV stands side-by-side, illustrating the height adjustment feature. One stand is set to its lowest height (42.87") and the other to its highest (53.89"), with yellow arrows indicating the adjustable range.

- **Flexible 30° Tilt & Level Function:** Tilt your TV up to 30° to reduce glare and level by +/-3° after installation for fine-tuning.

Image: A visual demonstrating the TV stand's tilt feature, showing a TV tilted upwards for optimal viewing while a person is on a treadmill.

Image: A TV mounted on the stand, with arrows indicating a +/-3° screen leveling adjustment, highlighting the fine-tuning capability.

- **Sturdy & Stable Base:** The 18.3" x 16.7" tempered glass base provides solid support. Adjustable foot pads ensure balance on uneven floors.

Image: A close-up view of the TV stand's base, showing its dimensions (18.3" x 16.73") and the adjustable leveling feet designed to stabilize on uneven flooring.

- **Easy Installation & Space Saving:** No drilling required. Comes with detailed instructions and tools for assembly in less than 10 minutes. Features cable management for a clean environment.

Image: The TV stand in a living room, emphasizing its "Simple & Space-Saving" design and the fact that "No drilling needed".

Image: The TV stand in a living room, showing a yellow cable neatly routed along the stand's pole, illustrating the "Cable Management" feature for an organized look.

Setup Instructions

Please follow these steps carefully for proper assembly. It is recommended to have a second person assist with mounting the TV to the stand.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Verify all components are present against the included parts list.
2. **Assemble the Base:** Attach the vertical support pole to the tempered glass base using the provided screws and tools. Ensure all connections are secure.
3. **Attach TV Brackets:** Secure the TV mounting brackets to the back of your television. Select the appropriate screws and spacers based on your TV's VESA pattern.
4. **Mount TV to Stand:** With assistance, carefully lift the TV and hook the brackets onto the vertical support pole's mounting plate. Secure the TV using the locking mechanisms on the brackets.
5. **Adjust Height:** Loosen the height adjustment screws on the vertical pole, raise or lower the TV to your desired viewing height, and then securely tighten the screws.
6. **Adjust Tilt and Level:** Adjust the tilt angle of the TV by loosening the tilt knobs, setting the desired angle (up to 30 degrees), and re-tightening. Use the leveling function (+/-3 degrees) to ensure the screen is perfectly horizontal.
7. **Cable Management:** Route all cables through the integrated cable management clips or channels on the back of the pole for a neat appearance.
8. **Stabilize on Uneven Floors:** Adjust the four foot pads at the base of the stand to ensure stability on any surface, preventing wobbling.

Image: A rear view of the TV stand, highlighting the VESA mounting plate where the TV attaches, and the central pole which houses the height adjustment and cable management features.

Operating Instructions

Once assembled, operating your AM alphamount TV Floor Stand is straightforward.

- **Viewing Angle Adjustment:** To change the vertical viewing angle, gently push or pull the top or bottom of the TV screen to achieve the desired tilt. Ensure the tilt mechanism is not overly tightened to allow for smooth adjustment.
- **Height Adjustment:** For significant height changes, refer to step 5 in the Setup Instructions. Always ensure the TV is securely locked in place after adjustment.
- **Relocation:** While the stand is portable, always remove the TV from the stand before moving it to a new location to prevent damage or injury.

Maintenance

Regular maintenance will ensure the longevity and safe operation of your TV stand.

- **Cleaning:** Use a soft, dry cloth to wipe down the stand. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying. Avoid abrasive cleaners or solvents.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight and secure. Loose connections can compromise stability.
- **Inspect for Damage:** Regularly inspect the stand for any signs of wear, damage, or deformation. Do not use the stand if any part is damaged.

Troubleshooting

Problem	Possible Cause	Solution
Stand is wobbly/unstable.	Uneven floor; loose connections.	Adjust the leveling foot pads at the base. Tighten all assembly screws.
TV not level after mounting.	Improper leveling adjustment.	Utilize the +/-3° screen leveling function to fine-tune the horizontal position.
Difficulty adjusting TV height.	Height adjustment screws are too tight or mechanism is stuck.	Loosen height adjustment screws sufficiently. Ensure no cables are obstructing the mechanism.
TV not tilting smoothly.	Tilt knobs are too tight.	Slightly loosen the tilt knobs to allow for smoother movement, then re-tighten to secure.

Specifications

Feature	Detail
Model Number	APFS01
Compatible TV Sizes	13 - 50 inches
Weight Capacity	Up to 44 lbs (20 kg)
VESA Compatibility	75x75mm, 100x100mm, 100x150mm, 150x150mm, 100x200mm, 200x200mm

Feature	Detail
Height Adjustment Range	42.87 - 53.89 inches
Tilt Angle	0° to +30°
Screen Leveling	+/-3°
Base Dimensions	18.3 inches (L) x 16.7 inches (W)
Material	Alloy Steel, Tempered Glass
Color	Black

Warranty and Support

AM alphamount stands behind the quality of its products. For warranty information or technical support, please refer to the official AM alphamount website or contact their customer service directly.
You can also find the official user manual PDFhere for additional details and diagrams.
For further assistance, please visit the AM alphamount Store on Amazon.

© 2024 AM alphamount. All rights reserved.