Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka NEC582

Eureka Lightweight Cordless Vacuum Cleaner User Manual

Model: NEC582 | Brand: Eureka

Product Overview

The Eureka Lightweight Cordless Vacuum Cleaner is designed for versatile and efficient cleaning. It features a powerful 450W BLDC motor, a removable battery for extended runtime, LED headlights, and a large capacity dust cup. Its cordless design allows for easy maneuverability across various surfaces, including multi-flooring, carpets, and hard floors.



Image: Eureka Lightweight Cordless Vacuum Cleaner and its components.

Key Features

- Easy Empty XL Dust Cup
- LED Headlight
- Lay Flat Design
- 450W highly efficient BLDC motor
- Complete Seal System
- Ideal for Pet Owners

Setup and Assembly

Battery Installation

The vacuum comes with a removable Lithium-Ion battery. To install, align the battery pack with the slot on the main unit and slide it in until it clicks securely.

Charging the Battery

Connect the charging adapter to the battery charging station. Place the battery into the charging station. The indicator lights on the battery will show the charging status. Ensure the battery is fully charged before first use.

Assembling the Vacuum

Connect the extension wand to the main vacuum body. Then, attach the desired floor head or accessory to the other end of the extension wand. Ensure all connections are secure.

Operating Instructions

Powering On/Off

Press the power button located on the handle to turn the vacuum on or off.

Adjusting Suction Power and Floor Type

The vacuum features a user-friendly LED display. Use the "Floor Type" button to switch between Hard Floor and Carpet modes. Use the "Mode" button to select between Min, Mid, and Max suction power settings.



Image: User-friendly LED display for easy control.



Image: UI display for customized cleaning.

Using Attachments

The vacuum includes various attachments for different cleaning needs. The motorized pet tool is effective for removing pet hair from upholstery and carpets. The crevice tool is ideal for tight spaces, and the brush tool can be used for delicate surfaces.



Image: Motorized pet tool for effective pet hair removal.



Image: Vacuum in use on different floor types.

Maintenance and Care

Emptying the Dust Cup

To empty the XL dust cup, detach it from the main unit by pressing the release button. Position the dust cup over a trash bin and press the bottom release button to open the trap door and empty the contents.



Image: Easy empty XL dust cup design.

Cleaning Filters

Regularly clean the HEPA filter and other internal filters to maintain optimal suction. Refer to the user manual (PDF) for detailed instructions on filter removal and cleaning frequency.



Image: Complete Seal Cyclonic Filtration System.

Cleaning the Roller Brush

It is recommended to clean the roller brush and belt every 2 weeks to prevent clogging by hair and dirt. Long-term failure to clean may cause malfunction.

Troubleshooting

For common issues and solutions, please refer to the officialTroubleshooting Guide (PDF).

Product Specifications

Feature	Detail
Brand	Eureka
Special Feature	Bagless
Included Components	Battery, HEPA Filter
Is Cordless?	Yes
Capacity	1 Liters
Wattage	450 watts
Runtime	2 hours
Form Factor	Stick, Handheld
Color	Red
Battery Description	Lithium-Ion
Amperage	15.17 Amps
Manufacturer	Eureka
Controller Type	Push Button
Motor Horsepower	0.603 horsepower
Control Method	Touch
Number of Speeds	2
Portable	Yes
Number of Handles	1
Number of Power Levels	2
Number of Wheels	3
Series Number	582
Indoor/Outdoor Usage	Indoor
UPC	840296500118
Item Weight	6.31 pounds
Product Dimensions	10.9 x 9.1 x 45.7 inches
Item model number	NEC582
Batteries	2 Lithium Ion batteries required. (included)

Feature	Detail
Manufacturer Part Number	NEC582
Special Features	Bagless
ASIN	B0B5R38RX9
Customer Reviews	3.6 3.6 out of 5 stars 114 ratings 3.6 out of 5 stars
Date First Available	July 4, 2022

Warranty and Support

Warranty Information

For detailed warranty information, please consult the official user manual or contact Eureka customer support.

Customer Support

For further assistance, visit the Eureka Store on Amazon or refer to the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B5R38RX9

More documents and user manuals: **https://manuals.plus/**