Manuals+
Q & A | Deep Search | Upload

Beetel F2N+FWP

Beetel F2N+FWP Fixed Corded Landline Phone User Manual

Model: F2N+FWP

Introduction

Thank you for choosing the Beetel F2N+FWP Fixed Corded Landline Phone. This device combines the reliability of a traditional landline with the flexibility of wireless cellular technology, supporting Quad Band GSM and Dual SIM operation. It features an LCD display, voice recording capabilities, an MP3 player, FM radio, and essential utilities like an alarm and basic calculator. This manual provides comprehensive instructions for setup, operation, and maintenance to ensure optimal performance of your device.

Safety Information

- Read all instructions carefully before using the phone.
- Keep the phone away from water and moisture.
- Do not attempt to disassemble or repair the phone yourself. Refer all servicing to qualified personnel.
- Use only the provided power adapter and accessories.
- Avoid exposing the phone to extreme temperatures or direct sunlight.
- Ensure proper ventilation around the phone during operation.

Package Contents

Please check the box for the following items:

- Beetel F2N+FWP Fixed Corded Landline Phone Unit
- Handset with coiled cord
- Power Adapter
- Rechargeable Lithium Ion Batteries (2 included)
- TNC Antenna
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your Beetel F2N+FWP phone.

Figure 1: Front view of the Beetel F2N+FWP phone, showing the main unit with keypad, LCD display, handset, and external antenna.

Figure 2: Side view of the Beetel F2N+FWP phone, highlighting the USB port for MP3 playback and the 3.5mm audio jack for headphones.

Key Components:

- **LCD Display:** Shows network status, battery level, caller ID, menu options, etc.
- **Keypad:** Standard numeric and function keys for dialing and navigation.
- **Handset:** For traditional call handling.
- **Antenna Port:** For connecting the external TNC antenna.
- **SIM Card Slots:** Located under the battery cover, supports Dual SIM.
- **Battery Compartment:** Houses the rechargeable Lithium Ion batteries.
- **Power Port:** For connecting the power adapter.
- **3.5mm Audio Jack:** For connecting headphones or external speakers.
- **USB Port:** For connecting a memory stick for MP3 playback and call recording.

Setup

1. Battery Installation:

1. Remove the battery compartment cover on the back of the phone.
2. Insert the two provided Lithium Ion batteries, ensuring correct polarity (+/-).
3. Replace the battery compartment cover.

2. SIM Card Insertion:

The phone supports two full-size SIM cards.

1. With the battery cover removed, locate the SIM card slots.
2. Carefully insert your SIM card(s) into the designated slots until they click into place. Ensure the gold contacts face downwards.
3. If using only one SIM, insert it into SIM1 slot for primary operation.

3. Antenna Connection:

1. Locate the TNC antenna port on the back or side of the phone.
2. Screw the provided TNC antenna clockwise into the port until secure. Do not overtighten.

4. Power Connection:

1. Connect the power adapter to the power port on the phone.
2. Plug the power adapter into a standard electrical outlet.
3. The phone will automatically power on and begin charging the batteries.

Operating Instructions

Making Calls:

1. Lift the handset or press the **Speaker** button.
2. Dial the desired phone number using the keypad.
3. Press the **Send** button to initiate the call.

Receiving Calls:

1. When the phone rings, lift the handset or press the**Send** button to answer.
2. To end a call, replace the handset or press the**End** button.

Dual SIM Operation:

The phone supports two active SIM cards. You can select which SIM to use for outgoing calls via the phone's menu settings or by pressing a dedicated SIM selection button if available (refer to on-screen prompts).

Call Recording:

The phone supports call recording. To utilize this feature, you will need to insert a MicroSD card (up to 32GB, not included) into the designated slot. Refer to the phone's menu for options to enable automatic call recording or to start/stop recording during a call.

MP3 Player and FM Radio:

- **MP3 Player:** Store MP3 audio files on a memory stick (USB drive) and connect it to the phone's USB port. Navigate to the MP3 player menu to browse and play your music.
- **FM Radio:** Access the FM radio function through the phone's menu. You may need to connect headphones to the 3.5mm audio jack to act as an antenna for better reception.

Contact Management:

The phone can store up to 1000 contacts with names. Access the "Contacts" or "Phonebook" menu to add, edit, or delete entries.

SMS Messaging:

You can send and receive SMS messages. The phone can store up to 400 SMS messages. Navigate to the "Messages" menu to compose new messages, read incoming messages, or manage your inbox.

Alarm and Calculator:

The phone includes built-in alarm clock functionality and a basic calculator. Access these features through the main menu.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Do not use liquid cleaners or aerosols.
- **Storage:** If storing the phone for an extended period, remove the batteries and store them in a cool, dry place.
- **Battery Care:** Fully charge the batteries before first use. Avoid completely draining the batteries frequently to prolong their lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Phone does not power on.	Low battery or power adapter not connected.	Connect the power adapter and allow the phone to charge. Ensure batteries are correctly installed.
No network signal.	SIM card not inserted correctly, antenna not connected, or poor network coverage.	Reinsert SIM card(s) properly. Ensure antenna is securely attached. Move to an area with better network coverage.

Problem	Possible Cause	Solution
Cannot make or receive calls.	No network signal, SIM card issues, or call barring enabled.	Check network signal. Verify SIM card is active. Check phone settings for call barring.
Poor audio quality.	Weak signal, interference, or handset/speaker issue.	Improve signal strength. Move away from other electronic devices. Test with both handset and speaker.
MP3 player not working.	USB drive not inserted correctly, unsupported file format, or no MP3 files on drive.	Ensure USB drive is fully inserted. Verify files are in MP3 format. Check if MP3 files are present on the drive.

Specifications

- **Model:** F2N+FWP
- **Dimensions:** 14 x 19.5 x 7.5 cm
- **Weight:** 550 g
- **Network Support:** Quad Band GSM (850MHz/900MHz/1800MHz/1900MHz)
- **SIM Support:** Dual SIM
- **Battery:** 2 x Lithium Ion (included)
- **Standby Time:** Up to 20 Hours
- **Memory Card Support:** Up to 32GB (for call recording)
- **Audio Jack:** 3.5 mm
- **Special Features:** MP3 Player, FM Radio, Voice Recording, Auto Answering, Alarm, Basic Calculator, Screen Auto Lock
- **Material:** Plastic
- **Manufacturer:** Beetel Teletech Limited

Warranty and Support

Your Beetel F2N+FWP Fixed Corded Landline Phone comes with a**1 Year Warranty** from the date of purchase.
For warranty claims, technical support, or service inquiries, please contact Beetel customer service. Keep your purchase receipt as proof of purchase.
Manufacturer: Beetel Teletech Limited
For further assistance, please visit the official Beetel website or contact their customer support helpline.

© 2023 Beetel Teletech Limited. All rights reserved.