Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK JC598UNIi2

LEXiBOOK Unicorn Educational and Bilingual Laptop Instruction Manual

Model: JC598UNIi2

Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Setup

This section provides instructions for the initial setup of your LEXiBOOK Unicorn Educational and Bilingual Laptop.

1.1. Unboxing

Carefully remove all components from the packaging. Ensure all items listed in the package contents are present.



Image: The LEXiBOOK Unicorn Educational Laptop in its open position, displaying the keyboard, screen, and connected mouse.

1.2. Battery Installation

The laptop requires 2 AA batteries (not included). Locate the battery compartment on the underside of the device. Use a screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the cover.

1.3. Mouse Connection

Connect the provided wired mouse to the designated port on the side of the laptop. The mouse is designed for easy navigation within the activities.



Image: A close-up view of the laptop's keyboard, screen displaying activity numbers, and the connected mouse, highlighting the ergonomic design.

1.4. Power On/Off

To power on the laptop, press the **"on/off"** button located on the top right of the keyboard. To turn off the device, press the same button again.

2. Operation

Learn how to navigate and enjoy the various educational activities on your laptop.

2.1. Language Selection

The laptop supports both English and Spanish languages. To switch between languages, press the **"Lang"** button on the keyboard. The current language will be displayed on the screen.

2.2. Activity Selection

A list of 124 activities is printed on the laptop's screen panel. Each activity is assigned a number. To select an activity, type its corresponding number using the numeric keys on the keyboard and then press **"Enter"**.



Image: A young child smiling and interacting with the LEXiBOOK Unicorn Educational Laptop, demonstrating ease of use.

2.3. Keyboard and Mouse Usage

Use the keyboard to input answers, select options, and interact with games. The mouse can be used to navigate and make selections on the screen, similar to a standard computer mouse.

2.4. Volume and Contrast Adjustment

Adjust the sound volume using the **"vol+"** and **"vol-"** buttons. The screen contrast can be adjusted using the **"Contrast+"** and **"Contrast-"** buttons to optimize visibility.

2.5. Activity Categories

The laptop offers a wide range of educational activities across several categories:

- **Mathematics:** Numbers learning, writing, spelling, tests, counting, ordering, comparison, addition, subtraction, multiplication, and division.
- **Language (English & Spanish):** Words learning, spelling, finding words, initial letter filling, missing letters, word ordering, word correction, word tests, letters learning, writing, small-capital letters, letters tests, completion, and ordering.
- **Typing:** Typing games to improve dactylography skills.
- **Logic:** Games designed to enhance logical thinking.
- **Music:** Musical notes learning, composing, and playing melodies.
- **Clock Reading:** Activities focused on telling time.

▶ **Watch video online**
Educational and Bilingual Laptop Spanish/English, JC598i2

Video: Official product video demonstrating the educational and bilingual features of the LEXiBOOK Unicorn Laptop, including various activities and language switching.

3. Maintenance

Proper care ensures the longevity and optimal performance of your laptop.

3.1. Cleaning

Wipe the surface of the laptop with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water. Keep the screen free from dust and fingerprints for clear visibility.

3.2. Storage

Store the laptop in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

4. Troubleshooting

This section addresses common issues you might encounter.

4.1. No Power

- Ensure batteries are correctly installed with proper polarity.
- Replace old batteries with new AA batteries.
- Confirm the "on/off" button is pressed firmly.

4.2. No Sound or Low Volume

- Press the "vol+" button to increase the volume.
- Check if the batteries are low, as this can affect sound output.

4.3. Screen Display Issues

- Adjust the screen contrast using the "Contrast+" and "Contrast-" buttons.
- Ensure the screen is clean and free from obstructions.

5. Specifications

Model Number:	JC598UNIi2
Product Dimensions:	9.4 x 7.1 x 0.1 inches
Item Weight:	1.41 pounds
Batteries:	2 AA batteries required (not included)
Recommended Age:	3 years and up

Languages:	English, Spanish
Manufacturer:	Lexibook

6. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official LEXiBOOK website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question