Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kisonli KS-1992

Kisonli KS-1992 USB Wireless Bluetooth Loud Speaker User Manual

Model: KS-1992

1. Introduction

Thank you for purchasing the Kisonli KS-1992 USB Wireless Bluetooth Loud Speaker. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it thoroughly before use to ensure optimal performance and longevity.

2. Product Overview

The Kisonli KS-1992 is a versatile portable speaker offering multiple connectivity options including Bluetooth, USB, and FM radio. It features a compact design with integrated controls and a phone cradle.



Figure 2.1: Kisonli KS-1992 Loud Speaker with antenna extended.

2.1. Components and Controls

- **Power Button:** Turns the speaker on/off.
- **Mode Button (M):** Switches between Bluetooth, USB, and FM Radio modes.
- **Previous Track/Volume Down (-):** Short press for previous track, long press to decrease volume.
- **Play/Pause Button (►/ ‌ ‌):** Plays or pauses audio. In FM mode, short press to auto-scan.
- **Next Track/Volume Up (+):** Short press for next track, long press to increase volume.
- **USB Port:** For USB flash drive playback.
- **Micro USB Port:** For charging the speaker.
- **AUX Input:** For connecting external audio devices via a 3.5mm cable (not included).
- **FM Antenna:** Extend for improved FM radio reception.
- **Phone Cradle:** Integrated slot to hold a smartphone.



Figure 2.2: Front view of the speaker showing the control buttons (M, -, Play/Pause, +).



Figure 2.3: Rear view of the speaker displaying the Micro USB charging port, USB port, and AUX input.

3. Setup

3.1. Charging the Speaker

1. Connect the Micro USB end of the charging cable (not included) to the Micro USB port on the back of the speaker.
2. Connect the standard USB end of the cable to a USB power adapter (e.g., phone charger, computer USB port).

3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

Note: Ensure the speaker is fully charged before first use for optimal battery life. The battery capacity is 1200mAh.

3.2. Powering On/Off

Press and hold the Power button to turn the speaker on or off.

4. Operating Instructions

4.1. Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing light and an audible prompt.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "KS-1992" (or similar name) from the list of devices.
4. Once paired, the speaker will emit an audible confirmation, and the indicator light will stop flashing.
5. You can now play audio from your device through the speaker.

Note: The effective Bluetooth range is approximately 10 meters (33 feet).



Figure 4.1: The speaker features an integrated cradle for holding a smartphone during use.

4.2. USB Playback Mode

1. Insert a USB flash drive containing MP3 audio files into the USB port on the back of the speaker.
2. Press the **Mode (M)** button until the speaker enters USB mode. It will automatically begin playing audio from the USB drive.
3. Use the **Previous Track (-)** and **Next Track (+)** buttons to navigate through tracks.
4. Long press the **Previous Track (-)** or **Next Track (+)** buttons to adjust the volume.

4.3. FM Radio Mode

1. Extend the FM antenna for better reception.
2. Press the **Mode (M)** button until the speaker enters FM Radio mode.
3. Short press the **Play/Pause (►/ ⌐ ⌐)** button to initiate an automatic scan for available radio stations. The speaker will save detected stations.
4. Use the **Previous Track (-)** and **Next Track (+)** buttons to switch between saved stations.

5. Long press the **Previous Track (-)** or **Next Track (+)** buttons to adjust the volume.

4.4. AUX Input Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.
2. Connect the other end of the cable to the audio output jack of your external device.
3. Press the **Mode (M)** button until the speaker enters AUX mode.
4. Control playback and volume from your external device.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or high humidity.

6. Troubleshooting

- **No Power:** Ensure the speaker is charged. Connect it to a power source using the Micro USB cable.
- **No Sound:** Check the volume level on both the speaker and your connected device. Ensure the correct mode (Bluetooth, USB, FM, AUX) is selected.
- **Bluetooth Not Connecting:** Ensure the speaker is in Bluetooth pairing mode. Turn off and on Bluetooth on your device, then try pairing again. Move your device closer to the speaker.
- **Poor FM Radio Reception:** Fully extend the FM antenna. Try repositioning the speaker to find a better signal.
- **USB Playback Issues:** Ensure the USB flash drive is formatted correctly (FAT32) and contains compatible audio files (MP3).
- **Only one speaker working:** Verify the audio source. If using Bluetooth, ensure your device's audio settings are not set to mono. If the issue persists, contact customer support.

7. Specifications

Brand	Kisonli
Model Number	KS-1992 (Item model number: QUN-051)
Output Power	5W*2
Connectivity Technology	Bluetooth, USB
Wireless Distance	10M
Battery Capacity	1200mAh
Power Source	Battery Powered
Special Features	USB Charging, Wireless

Tuner Technology	FM
Radio Bands Supported	FM
Color	Black
Item Dimensions (L x W x H)	20L x 20W x 30H centimeters (Note: Product image indicates different dimensions, please refer to actual product for precise measurements.)
Package Dimensions	25.8 x 10 x 8.9 cm
Included Components	Radio & Speaker



Figure 7.1: Approximate dimensions of the Kisonli KS-1992 speaker.

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. Kisonli strives to provide reliable products and customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B7CMG7H8

More documents and user manuals: **https://manuals.plus/**