Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard Soul Track

Billboard Soul Track Over-Ear Wireless Headphones User Manual

Model: Soul Track | Brand: Billboard

Introduction

Thank you for choosing the Billboard Soul Track Over-Ear Wireless Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

Package Contents

Verify that all items are present in your package:

- Billboard Soul Track Over-Ear Wireless Headphones
- USB Charging Cable
- 3.5mm Auxiliary Audio Cable
- User Manual (this document)

Product Features

- **High-Fidelity Audio:** Delivers clear and powerful sound.
- **Active Noise Cancellation (ANC):** Reduces ambient noise for an immersive listening experience.
- **Long Battery Life:** Up to 5 hours of continuous playback on a single charge.
- **Dual Connectivity:** Seamlessly switch between wireless Bluetooth and wired 3.5mm auxiliary connection.
- **Built-in Microphone:** Enables hands-free calling.
- **Comfortable Design:** Over-ear cushions and adjustable headband for extended wear.
- **Foldable Design:** For easy portability and storage.

Product Overview

Familiarize yourself with the different parts of your Billboard Soul Track headphones.



Figure 1: Front view of the Billboard Soul Track Over-Ear Headphones in Tinto color.



Figure 2: Angled view showcasing the earcups and headband.



Figure 3: The headphones in their folded position, highlighting portability.

Setup

1. Initial Charging

Before first use, fully charge your headphones. Connect the provided USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status and turn off or change color when fully charged.
Average battery duration: Approximately 5 hours.

2. Powering On/Off

To power on, press and hold the Power button until the LED indicator lights up. To power off, press and hold the Power button again until the LED indicator turns off.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.

3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Billboard Soul Track" from the list of found devices.
5. Once paired, the LED indicator will turn solid blue or flash blue slowly.
6. The headphones are now ready for wireless audio playback.

Compatible devices include mobile phones, tablets, laptops, and desktop computers.

2. Wired Connection (Auxiliary Mode)

If the battery is low or you prefer a wired connection, use the provided 3.5mm auxiliary audio cable:

1. Connect one end of the 3.5mm auxiliary cable to the audio input jack on the headphones.
2. Connect the other end to the 3.5mm audio output jack on your device.
3. The headphones will automatically switch to wired mode.



Figure 4: Illustration of the dual connectivity feature, showing the option for a 3.5mm auxiliary cable.

3. Audio Playback Controls

The headphones feature integrated controls for managing your audio:

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.

4. Call Management

Utilize the built-in microphone for hands-free communication:

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.

- **Avoid Water:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (flashing blue/red). Turn on device Bluetooth. Move headphones closer to device (within 10 meters).
No sound.	Volume too low; incorrect source; headphones not connected.	Increase volume on headphones and device. Check Bluetooth connection or 3.5mm cable connection.
Poor sound quality/disconnections.	Interference; device too far; low battery.	Move closer to the device. Charge headphones. Avoid strong electromagnetic interference.

Specifications

Feature	Detail
Model Name	Soul Track OE
Part Number	BB-H75006
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Noise Control	Active Noise Cancellation
Sensitivity	108 dB
Impedance	32 Ohm
Average Battery Life	5 Hours
Battery Cell Composition	Lithium Polymer
Special Features	Microphone Included
Dimensions (Package)	22.4 x 18.3 x 9 cm
Weight	390 g

Safety Information

- Do not disassemble or modify the headphones.
- Avoid exposing the headphones to extreme temperatures or humidity.
- Do not use the headphones while driving or in situations where you need to hear your surroundings.
- Prolonged listening at high volumes may cause hearing damage.

© 2025 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B7VSCSLD

More documents and user manuals: **https://manuals.plus/**