Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

One For All URC3660

One For All Universal Essential 6-Device Remote (URC3660) User Manual

Model: URC3660

Introduction

The One For All Universal Essential 6-Device Remote, model URC3660, is designed to consolidate control of up to six home entertainment devices. This remote offers a convenient solution for managing your TV, Set-top Box, Streamer, DVD player, and Blu-ray player with a single device. It features SimpleSet for quick configuration with major television brands and includes a learning capability for compatibility with a wider range of devices. Dedicated buttons provide shortcuts to streaming services and full control over Smart TV menus.



Image: The One For All Universal Essential 6-Device Remote (URC3660) in an angled view, showcasing its button layout.

Setup

1. Battery Installation

The remote requires two AA batteries (not included). To install:

1. Open the battery compartment cover on the back of the remote.

2. Insert two AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

2. Device Setup (SimpleSet)

SimpleSet allows for quick configuration of your devices. Follow these steps:

1. Turn on the device you wish to control (e.g., your TV).
2. On the One For All remote, press and hold the **SETUP** button until the LED under the device key (e.g., **TV**) blinks twice and then stays lit.
3. Press the device key you want to set up (e.g., **TV**). The LED will remain lit.
4. Point the One For All remote at your device and press the **POWER** button. If the device turns off, the setup is complete for that device.
5. If the device does not turn off, repeatedly press the **POWER** button until it does. This cycles through codes for your brand.
6. Once the device turns off, press the **SETUP** button to save the code. The LED will blink twice.

Repeat this process for each device you wish to control (TV, STB, STREAM, AUDIO, BLURAY, DVD).



Image: Illustration showing the One For All remote replacing a traditional remote, symbolizing its universal compatibility.

3. Learning Function

The learning function allows you to copy functions directly from your original remote control if a specific function is not available after SimpleSet setup.

1. Place the One For All remote and your original remote on a flat surface, pointing their IR eyes towards each other, approximately 1-2 inches apart.
2. Press and hold the **SETUP** button until the LED blinks twice and then stays lit.
3. Press the device key (e.g., **TV**) for the device you want to learn a function for.
4. Press the button on the One For All remote where you want to store the learned function. The LED will blink rapidly.
5. Press and hold the corresponding button on your original remote until the LED on the One For All remote blinks twice, indicating successful learning.
6. Repeat for other buttons you wish to learn.
7. Press the **SETUP** button to exit learning mode. The LED will blink twice.

Operating Instructions

After setup, you can operate your devices using the One For All remote.

1. Device Selection

To control a specific device, press the corresponding device key at the top of the remote (**TV**, **STB**, **STREAM**, **AUDIO**, **BLURAY**, **DVD**). The LED under the selected device key will light up, indicating that the remote is now in control of that device.



Image: Close-up of the top section of the remote, highlighting the device selection buttons (TV, STB, STREAM, AUDIO, BLURAY, DVD) and the Power button.

2. Basic Functions

- **Power:** Press the **POWER** button to turn the selected device on or off.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons to adjust the volume. The **MUTE** button silences the audio.
- **Channel Control:** Use the **CH +** and **CH -** buttons to change channels.
- **Navigation:** The directional pad (up, down, left, right) and **OK** button are used for menu navigation and selection.
- **Playback Controls:** Buttons like **PLAY**, **PAUSE**, **STOP**, **REWIND**, and **FAST FORWARD** control media playback.



Image: Close-up of the central section of the remote, showing the Volume, Channel, and Mute buttons.

3. Special Features

- **Streaming Service Shortcuts:** Dedicated buttons provide direct access to popular streaming services.
- **Smart TV Menus:** The remote offers full control over Smart TV menus, allowing you to navigate apps and settings.
- **Activity-Based Programs:** The remote supports activity-based programs for TV, Music, and Movies, simplifying control for common scenarios.



Image: Close-up of the bottom section of the remote, featuring the colored function buttons and numeric keypad.

Maintenance

1. Cleaning

To clean your remote control:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- Ensure no liquid enters the remote's interior.

2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or the LED indicator does not light up consistently. Refer to the "Battery Installation" section for detailed steps.

Troubleshooting

- **Remote not working:** Ensure batteries are correctly installed and not depleted. Replace if necessary. Check if the remote is pointed directly at the device.
- **Device not responding:** Verify that the correct device key (e.g., **TV**) is selected. Re-attempt the SimpleSet setup process for the unresponsive device.
- **Specific function not working:** Use the learning function to copy the specific function from your original remote. Ensure the original remote has working batteries during the learning process.
- **LED indicator not blinking:** This may indicate low battery power or an issue with the remote. Try replacing the batteries.

Specifications

Brand	One For All
Model	URC3660
Compatible Devices	TV, Set Top Box, Streaming Device, DVD/Blu-ray Player, Home Theater
Max Number of Supported Devices	6
Special Features	Infrared, Universal, Learning Function, SimpleSet
Power Source	2 x AA Batteries (not included)
Material Type	Plastic
Color	Black

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official One For All website. Support resources typically include FAQs, troubleshooting guides, and contact information for customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9CHJ4L6

More documents and user manuals: **https://manuals.plus/**