Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QFX BT-67

QFX BT-67 Portable Bluetooth Speaker User Manual

Model: BT-67

Introduction

The QFX BT-67 is a versatile portable Bluetooth rechargeable speaker designed for various audio needs. It features a 6.5-inch full-range speaker, built-in FM radio, and dynamic RGB LED party lights. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your BT-67 speaker to ensure optimal performance and longevity.

Key features include wireless Bluetooth connectivity, support for MP3 files via USB drives and TF cards, an AUX input for external audio devices, and a microphone input for presentations or karaoke. For an enhanced audio experience, two BT-67 speakers can be paired for True Wireless Stereo (TWS) sound.

Product Overview



Figure 1: Front view of the QFX BT-67 speaker, showcasing the illuminated LED party lights around the speaker cone and control panel at the top.



Figure 2: Angled front view of the QFX BT-67 speaker, highlighting its portable design and textured casing.





Figure 3: Side view of the QFX BT-67 speaker, showing the integrated handle for easy portability.



Figure 4: Top view of the QFX BT-67 speaker, displaying the control panel with various buttons for power, EQ, mode, and track control.



Figure 5: Rear view of the QFX BT-67 speaker, detailing the input ports including microphone, AUX, DC power, USB, and TF card slots.



Figure 6: Bottom view of the QFX BT-67 speaker, showing the stable feet for placement on flat surfaces.

Setup

Unpacking and Initial Charge

1. Carefully remove the speaker and all accessories from the packaging. Ensure all included components are present: QFX BT-67 speaker, Remote Control/App, AUX Cable, USB Cable, TF Card Adapter.
2. Before first use, fully charge the speaker. Connect the provided USB cable to the speaker's DC 5V input port and the other end to a compatible USB power adapter (not included) or a computer USB port. The charging indicator light will illuminate.
3. Allow approximately 3-4 hours for a full charge. The charging indicator will change or turn off once charging is complete.

Powering On/Off

- To power on the speaker, press and hold the **Power/Mode** button on the control panel until the display illuminates.
- To power off the speaker, press and hold the **Power/Mode** button again until the display turns off.

Operating Instructions

Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon or audible prompt.
2. Enable Bluetooth on your device (smartphone, tablet, etc.) and search for available devices.
3. Select "QFX BT-67" from the list of devices. Once paired, the speaker will confirm with an audible sound, and the Bluetooth indicator will stop flashing.
4. You can now play audio from your device through the speaker. Use your device or the speaker's controls for volume, play/pause, and track navigation.

FM Radio Mode

1. Press the **Mode** button repeatedly until "FM" is displayed.
2. Press the **Play/Pause** button to automatically scan and save available FM stations.
3. Use the **Previous/Next Track** buttons to navigate between saved stations.

USB/TF Card Mode

- Insert a USB flash drive or TF (microSD) card containing MP3 audio files into the respective port.
- The speaker will automatically switch to USB or TF card mode and begin playing the first compatible audio file. If it doesn't, press the **Mode** button to select the correct input.
- Use the speaker's controls for play/pause, volume, and track navigation.

AUX Input Mode

- Connect one end of the provided AUX cable to the speaker's AUX input port and the other end to the audio output of an external device (e.g., MP3 player, laptop).
- Press the **Mode** button until "AUX" is displayed.
- Audio from your external device will now play through the speaker. Control playback and volume primarily from your external device.

Microphone Input

- Plug a 6.35mm microphone (not included) into the MIC input port on the speaker.
- Adjust the microphone volume using the dedicated knob or controls on the speaker, if available.

LED Party Lights

- The speaker features built-in RGB LED party lights. These lights typically activate automatically when the speaker is powered on.
- Press the **Light Mode** button (often labeled with a lightbulb icon) to cycle through different light patterns or to turn the lights off/on.

True Wireless Stereo (TWS) Pairing

To pair two QFX BT-67 speakers for a stereo sound experience:

1. Ensure both BT-67 speakers are powered on and in Bluetooth mode, but not connected to any other Bluetooth device.
2. On one of the speakers (this will be the primary speaker), press and hold the**TWS** button (often labeled "TWS" or "HI TWS").
3. The speaker will search for the second BT-67 speaker. Once connected, you will hear an audible confirmation.
4. Now, connect your Bluetooth device to the primary speaker. Audio will play in stereo through both speakers.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents. Avoid getting moisture into any openings.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in constant use.
- **Water Resistance:** This speaker is NOT waterproof. Avoid exposure to water, rain, or excessive moisture to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is low or depleted.	Connect the speaker to a power source using the USB cable and charge it fully.
No sound from speaker.	Volume is too low; Incorrect input mode; Device not connected.	Increase speaker and device volume. Press **Mode** button to select correct input (Bluetooth, AUX, USB, TF). Ensure Bluetooth device is paired or AUX cable is fully inserted.

Problem	Possible Cause	Solution
Bluetooth device cannot pair.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth mode and flashing. Move device closer to speaker. Turn off other Bluetooth devices nearby. Try unpairing and re-pairing.
FM radio reception is poor.	Weak signal; No external antenna.	Reposition the speaker. Extend any available antenna (if applicable). Try scanning for stations again.
TWS pairing fails.	Speakers already connected to other devices; Too far apart.	Ensure both speakers are not connected to any Bluetooth device. Place speakers within close proximity (e.g., 1-2 meters). Repeat TWS pairing steps.

Specifications

- **Model Name:** BT-67
- **Speaker Type:** Woofer
- **Speaker Size:** 6.5 Inches
- **Audio Driver Type:** Dynamic Driver
- **Connectivity Technology:** Bluetooth, USB, TF Card, AUX, FM Radio
- **Wireless Communication Technology:** Bluetooth
- **Control Method:** App, Manual Buttons
- **Power Source:** Corded Electric (Rechargeable Battery)
- **Batteries:** 1 Lithium Ion battery required (included)
- **Product Dimensions:** 6"D x 8"W x 11"H
- **Item Weight:** 2.31 pounds
- **Included Components:** Remote Control/App, AUX Cable, USB Cable, TF Card Adapter
- **Manufacturer:** QFX
- **UPC:** 606540040461

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official QFX website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may contact QFX customer service through their official channels. Please have your model number (BT-67) and UPC (606540040461) ready when contacting support.
Note: This product is from a small business brand. Your support is appreciated.

© 2024 QFX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9HP7GFZ

More documents and user manuals: **https://manuals.plus/**