Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EazeHome B0BC1DT9DJ

EazeHome Mini Fridge Stand with Storage

Model: B0BC1DT9DJ

Brand: EazeHome

Introduction

Thank you for choosing the EazeHome Mini Fridge Stand with Storage. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new product. Please read these instructions thoroughly before use and retain them for future reference.





Image: The EazeHome Mini Fridge Stand in grey, featuring two fabric drawers and a sturdy metal frame, with a white mini fridge positioned on its top surface. The stand is shown in a bedroom setting, demonstrating its compact and functional design.

Safety Information

Ensure all parts are properly secured before use. Do not allow children to play on, with, or around cart. Use caution when moving on uneven surfaces to prevent tipping. Be aware of sharp objects or hot surfaces in the vicinity of the cart.

Product Features

- **Durable Steel Frame:** Mobile fridge stand is made of strong metal frame and polyester fabric drawers (up to 120lbs). Refrigerator stand will provide a long-term life span. Daily cleaning can be easily solved by gently wiping with a towel.
- **2 Drawers Storage:** Reduce wasted space in kitchen, 2 gray drawers to hold cooking supplies, food, cups,

plates, etc. Scratch-resistant metal top accommodates most kitchen machines. Overall Dimension: 20” L x20” W x 16.8 H.

- **Find Convenience in Details:** For those who seek convenient storage, fridge cabinet makes it easier to access everything within reach. The fridge cart raises home appliances off the floor, no more crouching and give knees a break.
- **Easy Mobility:** 4 swivel wheels (2 wheels with brakes) at the bottom can rotate 360 degrees, allowing you to easily move to any place. You can place it in any position and then lock the stand firmly to keep it from moving while in use.
- **Durable Construction:** The stand's steel frame and metal top provide exceptional stability and support while the powder coat finish helps resist chipping and scratching for an extended professional appearance.
- **Easy Assembly:** With clear instructions and labeled parts, you'll have this kitchen organizer up and ready in no time, effortlessly transforming your messy corner into an organized and clean space. Attention: the refrigerator is not included.

SPECIFICATIONS

Feature	Detail
Product Dimensions	23.62"D x 22.28"W x 22.17"H
Shelf Type	Tiered Shelf
Frame Material	Metal
Brand	EazeHome
Color	Grey
Furniture Finish	Metal
Style	Modern
Maximum Weight Recommendation	120 Pounds
Item Weight	20.1 pounds
Number of Shelves	2
Product Care Instructions	Wipe with Dry Cloth



Image: A detailed diagram illustrating the dimensions of the EazeHome Mini Fridge Stand, including overall height, width, depth, and individual drawer sizes. It also notes that the refrigerator is not included.

Setup and Assembly

The EazeHome Mini Fridge Stand is designed for easy assembly. Follow these general steps:

1. Unpack all components and verify against the parts list (refer to included packaging for specific parts list).
2. Assemble the metal frame according to the provided diagrams, ensuring all screws are tightened securely.
3. Insert the fabric drawers into their designated slots. Ensure they slide smoothly.
4. Attach the swivel wheels to the bottom of the frame. Make sure the locking mechanisms are functional.
5. Place your mini fridge or other appliance on the top surface, ensuring it is centered and stable.

Your browser does not support the video tag.

Video: An official EazeHome video demonstrating the assembly and features of the fridge stand, including the drawers and wheels.



Image: A close-up view highlighting the stable frame structure of the stand, including rounded armrests for safety and side rails to prevent items from sliding out.

Operating Instructions

Using your EazeHome Mini Fridge Stand is straightforward:

- **Drawer Usage:** Gently pull the handles to open the fabric drawers. Push them back in until they are fully closed. Avoid overloading drawers to ensure smooth operation and prevent damage.
- **Mobility:** To move the stand, unlock the two braked swivel wheels by flipping their levers upwards. Once in the desired position, push the levers downwards to lock the wheels and secure the stand.
- **Top Surface:** The metal top surface is designed to hold mini-fridges, microwaves, or coffee machines up to 120 lbs. Ensure the appliance is placed centrally for optimal stability.

Your browser does not support the video tag.

Video: A customer display video showcasing the EazeHome Mini Fridge Stand in use, highlighting its storage drawers and mobility with a mini fridge on top.



Image: The EazeHome Mini Fridge Stand in a kitchen, featuring a mini fridge on its top surface and two grey fabric drawers for additional storage. The stand is positioned next to kitchen cabinets, illustrating its integration into a home environment.

Maintenance

To ensure the longevity and appearance of your EazeHome Mini Fridge Stand, follow these maintenance guidelines:

- **Cleaning the Frame:** Wipe the metal frame with a dry cloth to remove dust and debris. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- **Cleaning the Drawers:** The polyester fabric drawers can be cleaned by gently wiping with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Wheel Maintenance:** Periodically check the swivel wheels for any accumulated dust or hair that might hinder smooth movement. Clean as necessary. Ensure the locking mechanisms are free of obstructions.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 120 pounds on the top surface or in the drawers to prevent structural damage.



Image: A detailed view of the durable steel frame and breathable non-woven fabric storage drawers, emphasizing the quality materials used in the stand's construction.

Troubleshooting

If you encounter any issues with your EazeHome Mini Fridge Stand, refer to the following common problems and solutions:

- **Drawers are Sticking or Not Sliding Smoothly:**
  - Check if the drawers are overloaded. Remove some items if necessary.
  - Ensure the drawers are inserted correctly and are not misaligned.
  - Inspect the drawer tracks for any obstructions or damage.
- **Stand is Wobbly:**
  - Verify that all assembly screws are securely tightened.
  - Ensure the mini fridge or appliance on top is centered and its weight is evenly distributed.
  - Check if the floor surface is even. Adjust the stand's position if needed.

- **Wheels are Not Locking/Unlocking:**
  - Ensure the locking levers are fully engaged or disengaged.
  - Check for any debris or obstructions in the wheel mechanism.

Warranty and Support

EazeHome is committed to providing durable and practical home products. For any quality issues or further assistance, please contact EazeHome customer service. Refer to your purchase documentation for specific warranty details and contact information.
You can also visit the EazeHome Store for more information and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BC1DT9DJ

More documents and user manuals: **https://manuals.plus/**