Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 1395-001

TRESKO Glass Convector Heater 1500W with WiFi Function

Model: 1395-001 | Instruction Manual

1. Important Safety Instructions

Please read this instruction manual carefully before using the appliance and keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the rating label matches your mains voltage. Do not operate the heater with a damaged cord or plug. Do not immerse the heater in water or other liquids.
- **Placement:** Always place the heater on a firm, level surface. Maintain a minimum distance of 1 meter (3 feet) from flammable materials such as curtains, furniture, and other objects. Do not cover the heater.
- **Water and Moisture:** This heater has an IP24 splash protection rating, making it suitable for use in bathrooms. However, do not place it directly under a water outlet or where it could fall into water. Always ensure hands are dry when handling the plug or controls.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Overheating Protection:** The heater is equipped with a double overheating protection system. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool down before attempting to restart.
- **Power Cord:** Do not route the power cord under carpets or where it could be tripped over. Avoid placing heavy objects on the cord.
- **Maintenance:** Unplug the heater before cleaning or performing any maintenance. Do not attempt to repair the heater yourself; contact qualified service personnel.

2. Product Overview

The TRESKO Glass Convector Heater provides efficient and comfortable heating for your home, featuring modern design and smart control options.



Image: The TRESKO Glass Convector Heater, showcasing its sleek black design, integrated LED display, and WiFi connectivity with a smartphone displaying the control app.

Components

- Heater Unit with Glass Panel and LED Touch Display
- Feet with Wheels (for freestanding use)
- Wall Mounting Kit (brackets, screws, anchors)
- Instruction Manual

Key Features

- **1500W Heating Power:** Rapid and efficient convection heating.
- **WiFi Functionality:** Control your heater remotely via a smartphone app.
- **LED Touch Display:** Intuitive control panel for direct adjustments.
- **Digital Thermostat:** Precise temperature control from 5°C to 40°C.
- **Timer Function:** Programmable timer from 1 to 24 hours.
- **ECO Mode:** Energy-saving operation to minimize power consumption.

- **Weekly Mode:** Create targeted daily and weekly heating schedules.
- **Child Lock:** Prevents unintended changes to settings.
- **Double Overheat Protection:** Enhanced safety feature.
- **IP24 Splash Protection:** Suitable for use in damp environments like bathrooms.
- **Flexible Installation:** Can be used freestanding with wheels or wall-mounted.
- **Quiet Operation:** Designed for minimal noise, suitable for bedrooms or offices.

3. Setup

3.1 Unpacking

1. Carefully remove the heater and all components from the packaging.
2. Check for any signs of damage. If damaged, do not use the appliance and contact your retailer.
3. Retain the packaging for future storage or transport.

3.2 Freestanding Assembly

If you intend to use the heater as a freestanding unit, attach the provided feet with wheels.

1. Place the heater carefully on a soft, flat surface to avoid scratching the glass panel.
2. Align the feet with the designated holes on the bottom of the heater.
3. Secure each foot using the screws provided. Ensure they are tightened firmly.
4. Carefully stand the heater upright.

3.3 Wall-Mounted Installation

If you prefer to mount the heater on a wall, use the provided wall mounting kit.



Image: Diagram showing the dimensions of the TRESKO Glass Convector Heater (68.5 cm width, 12 cm depth, 54.5 cm height) and illustrating both wall-mounted and freestanding options with wheels.

1. Choose a suitable wall location, ensuring sufficient clearance from flammable materials (at least 1 meter).
2. Mark the drilling points for the wall brackets using the provided template or by measuring carefully.
3. Drill holes and insert wall anchors.
4. Attach the wall brackets securely to the wall using screws.
5. Carefully hang the heater onto the wall brackets, ensuring it is securely seated.

3.4 Initial Power-Up

1. Ensure the heater is correctly assembled or installed.
2. Plug the power cord into a suitable 220V electrical outlet.
3. The LED display will illuminate, indicating the heater is in standby mode.

4. Operating Instructions

4.1 Control Panel Operation

The heater features an intuitive LED touch display for direct control.



Image: Close-up of the TRESKO Glass Convector Heater's LED touch control panel, showing temperature display and various function icons, alongside a smartphone screen demonstrating the Smart Life App interface.

- **Power On/Off:** Touch the power symbol to turn the heater on or off.
- **Temperature Adjustment:** Use the '+' and '-' symbols to set the desired room temperature between 5°C and 40°C. The heater will automatically adjust its output to maintain this temperature.
- **Mode Selection:** Press the 'Mode' button to cycle through available heating modes (e.g., Comfort, ECO).
- **Timer Function:** Press the 'Timer' button to set an operating duration from 1 to 24 hours. The heater will automatically switch off after the set time.
- **Child Lock:** Activate the child lock by pressing and holding the designated symbol (often a lock icon) for a few seconds. This prevents accidental changes to settings. Repeat to deactivate.

4.2 WiFi and App Control

Control your TRESKO heater conveniently from your smartphone using the 'Smart Life' app.



Image: A TRESKO Glass Convector Heater with its LED display showing a temperature of 25 degrees Celsius, next to a hand holding a smartphone displaying the control app with a set temperature of 18 degrees. Icons for WiFi, app control, desired temperature setting (5-50°C), and weekly mode are also visible.

1. **Download the App:** Search for 'Smart Life' in your smartphone's app store (iOS or Android) and install it.
2. **Register/Log In:** Create a new account or log in if you already have one.
3. **Add Device:** Follow the in-app instructions to add a new device. Ensure your heater is powered on and in pairing mode (refer to the app for specific pairing instructions, usually involving a long press on a WiFi button on the heater).
4. **Connect to WiFi:** Connect your smartphone to a 2.4GHz WiFi network. The app will guide you through connecting the heater to your home WiFi.
5. **Remote Control:** Once connected, you can control the heater from anywhere with an internet connection. Functions include:
    - Power On/Off
    - Temperature Setting
    - Mode Selection (e.g., ECO, Comfort)
    - Timer Setting

- Weekly Schedule Programming

4.3 Special Features

- **Frost Protection:** The integrated sensor thermostat activates the heater if the room temperature drops below a certain threshold (typically 5-7°C) to prevent freezing.
- **Automatic Power Off (Tip-Over Protection):** For safety, the heater will automatically switch off if it is accidentally knocked over.
- **ECO Mode:** This mode optimizes energy consumption by maintaining a comfortable temperature with reduced power output.

5. Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your heater.

1. **Before Cleaning:** Always unplug the heater from the power outlet and allow it to cool down completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior surfaces, especially the glass panel, with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
3. **Dust Removal:** Use a soft brush or vacuum cleaner to remove dust from the air inlets and outlets.
4. **Storage:** If storing the heater for an extended period, clean it thoroughly, then place it back in its original packaging and store in a dry, cool place.
5. **No User-Serviceable Parts:** The heater contains no user-serviceable parts. Do not attempt to open or repair the appliance yourself. Contact qualified service personnel for any repairs.

6. Troubleshooting

If you encounter issues with your TRESKO Glass Convector Heater, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Overheat protection activated. Unit is tipped over.	Check if the plug is securely in the outlet and the power switch is on. Unplug, let cool for 30 minutes, then plug back in. Ensure the heater is upright on a stable surface.
Heater not producing heat.	Temperature setting is too low. ECO mode is active. Timer has expired.	Increase the desired temperature setting. Switch to Comfort mode or increase temperature. Check the timer setting and reset if necessary.

Problem	Possible Cause	Solution
WiFi connection issues.	Incorrect WiFi password. Router is too far or signal is weak. Heater not in pairing mode. Using 5GHz WiFi network.	Re-enter WiFi password in the app. Move heater closer to the router or use a WiFi extender. Follow app instructions to put heater into pairing mode. Ensure your router is broadcasting a 2.4GHz network and your phone is connected to it during setup.
Child lock is active, cannot change settings.	Child lock feature is engaged.	Press and hold the child lock symbol on the control panel for a few seconds to deactivate it.

7. Specifications

Brand	TRESKO
Model Number	1395-001
Power Output	1500 W
Voltage	220 Volts
Dimensions (L x W x H)	68.5 cm x 12 cm x 54.5 cm
Item Weight	7 Kilograms
Protection Class	IP24 (Splash-proof)
Heating Method	Convection
Temperature Range	5°C - 40°C
Connectivity	Wi-Fi
Installation Options	Freestanding (with wheels) or Wall-mounted
Recommended Use	Indoor, Home

8. Warranty and Support

TRESKO products are manufactured to high-quality standards. This product is covered by a standard manufacturer's warranty, subject to the terms and conditions of sale in your region.

- **Warranty Claims:** In the event of a defect, please contact the retailer from whom you purchased the product. You will typically need your proof of purchase.
- **Technical Support:** For technical assistance or questions not covered in this manual, please refer to the contact information provided by your retailer or the TRESKO official website.
- **Exclusions:** The warranty does not cover damage caused by improper use, unauthorized modifications, or failure to follow the instructions in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BC9X2TYR

More documents and user manuals: **https://manuals.plus/**