Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 1395-002

TRESKO® 1500W Glass Convector Heater with WiFi Function

Model: 1395-002

Introduction

Thank you for choosing the TRESKO® 1500W Glass Convector Heater. This electric heater is designed to provide efficient and comfortable warmth for your home, office, garage, or greenhouse. Featuring a sleek glass design, it offers versatile installation options (freestanding or wall-mounted) and convenient control via its integrated touch display or a smart mobile application. Please read this manual thoroughly before operation to ensure safe and optimal use of your new heater.

Safety Instructions

To prevent injury or damage, always adhere to the following safety guidelines:

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the heater (220 Volts). Do not overload electrical outlets.
- **Placement:** Position the heater on a stable, level surface. Maintain a safe distance from flammable materials, furniture, and curtains. Do not cover the heater.
- **Water Protection:** The heater has IP24 splash protection, making it suitable for use in bathrooms. However, do not immerse the unit in water or expose it to direct water jets.
- **Overheat Protection:** The heater is equipped with double overheat protection. If the unit overheats, it will automatically shut off. Unplug the unit and allow it to cool before restarting.
- **Tip-Over Protection:** An automatic shut-off feature activates if the heater is accidentally tipped over.
- **Child Safety Lock:** Utilize the child safety lock function to prevent unintended operation by children.
- **Ventilation:** Ensure adequate ventilation around the heater. Do not block air inlets or outlets.
- **Maintenance:** Always unplug the heater before cleaning or performing any maintenance.
- **Damage:** Do not operate the heater if the power cord or plug is damaged, or if the unit has been dropped or damaged in any way. Contact qualified personnel for repair.

Setup

Your TRESKO® Convector Heater offers flexible installation options:

Freestanding Installation

For freestanding use, attach the included feet with wheels to the base of the heater. This allows for easy mobility and placement

in various rooms.



Figure 1: TRESKO Glass Convector Heater in freestanding configuration, showing its sleek design and mobile app control.

Wall-Mounted Installation

The heater can also be securely mounted to a wall using the provided wall bracket. Ensure the wall material is suitable for supporting the heater's weight (7 kg) and follow the instructions for proper mounting to ensure stability and safety.



Figure 2: Dimensions of the heater (68.5 cm width, 12 cm depth, 54.5 cm height) and illustration of wall mounting and mobile wheels.

Power Connection

Once positioned, connect the power cable to a suitable 220V electrical outlet. The heater is now ready for operation.

Operating Instructions

The TRESKO® Convector Heater offers multiple ways to control its functions:

Touch Display Control

The integrated LED touch display allows for direct control of the heater's settings. You can adjust the temperature, set the timer, and select various modes directly from the panel.



Figure 3: Operating the heater via its touch display, highlighting its aluminum heating elements and fast convection heating.

Smart App Control (WiFi Function)

For enhanced convenience, download the compatible smart app (e.g., Smart Life App) to your smartphone. Connect the heater to your home WiFi network to control it remotely. The app allows you to:

- Adjust temperature settings (from 5°C to 40°C).
- Set the timer (1 to 24 hours).
- Activate ECO mode for energy saving.
- Configure weekly schedules for automated heating.
- Enable the child safety lock.
- Monitor current settings.



Figure 4: Controlling the heater remotely using the smart app, showcasing temperature adjustment and weekly scheduling.

Special Features

- **ECO Mode:** Reduces energy consumption by optimizing heating output.
- **Weekly Mode:** Allows for programming specific heating schedules for each day of the week.
- **Comfort Mode:** Maintains a consistent room temperature by continuous heating adjustments.
- **Frost Protection:** The sensor thermostat activates heating if the room temperature drops below a certain threshold (typically 5-7°C) to prevent freezing.
- **Silent Operation:** Designed to operate quietly, making it suitable for bedrooms or quiet environments.



Figure 5: Safety and efficiency features including IP24 splash protection, ECO mode, automatic shut-off, and child lock.

Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater:

- **Cleaning:** Before cleaning, always unplug the heater and allow it to cool completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging to protect it from dust and damage.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damage is found, do not use the heater and contact customer support.

Troubleshooting

If you encounter issues with your TRESKO® Convector Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power switch off; Overheat protection activated; Tip-over switch activated.	Check power outlet and plug connection. Ensure power switch is ON. Unplug and allow to cool if overheated. Reset heater if tipped over.
Heater not heating effectively.	Temperature setting too low; ECO mode active; Room too large for heater capacity.	Increase temperature setting. Deactivate ECO mode if higher heat is desired. Ensure heater is appropriately sized for the room.
WiFi connection issues.	Incorrect WiFi password; Router too far; App not properly configured.	Verify WiFi password. Move heater closer to router. Follow app's pairing instructions carefully. Restart router and heater.
Unusual noises or smells.	Dust accumulation; Internal component issue.	Unplug and clean the heater. If problem persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

Specifications

Brand	TRESKO
Model Number	1395-002
Color	White
Power Output	1500 W
Voltage	220 Volts
Dimensions (L x W x H)	81.5 cm x 12 cm x 54.5 cm
Weight	7 Kilograms
Heating Method	Convection
Special Features	WiFi and App Function, Timer Function, Child Safety Lock, Energy-Saving Mode, Double Overheat Protection, IP24 Splash Protection, Automatic Tip-Over Shut-off, Silent Operation, Frost Protection
Recommended Use	Indoor (Office, Garage, Home, Greenhouse)
Mounting Type	Freestanding (with wheels), Wall-mounted

Warranty and Support

Information regarding spare parts availability is not provided. For warranty details and customer support, please refer to the documentation included with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2023 TRESKO. All rights reserved. This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BC9XMXCB

More documents and user manuals: **https://manuals.plus/**