Manuals+
Q & A | Deep Search | Upload

PoKat 24" Ceramic Table Lamp Set (B0BF8ZTSLS)

PoKat Ceramic Table Lamps User Manual

Model: 24" Ceramic Table Lamp Set (B0BF8ZTSLS)

INTRODUCTION

Thank you for choosing PoKat Ceramic Table Lamps. This manual provides important information regarding the safe installation, operation, and maintenance of your new lamps. Please read this manual thoroughly before use and retain it for future reference.

Image: A pair of PoKat ceramic table lamps, showcasing their elegant design and how they appear in a living space setting.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury to persons, please follow these guidelines:

- Always unplug the lamp from the electrical outlet before cleaning, changing light bulbs, or performing any maintenance.
- Do not use with a dimmer switch unless specifically designed for dimmable bulbs.
- Do not touch the bulb when the lamp is on or immediately after turning it off, as it will be hot.
- Do not operate the lamp with a damaged cord or plug. If the cord or plug is damaged, do not attempt to repair it yourself. Contact qualified service personnel.
- Do not place the lamp near heat sources or in direct sunlight.
- Use only the type and wattage of bulb specified on the lamp.

- Keep the lamp away from water or other liquids.
- This lamp is intended for indoor use only.

Package Contents

Your PoKat Ceramic Table Lamp package should contain the following items:

- Ceramic Lamp Base (2 units)
- Lamp Shade (2 units)
- Harp (2 units)
- Finial (2 units)
- User Manual (This document)

Note: Light bulbs are not included and must be purchased separately.

Setup and Assembly

The lampshade requires simple assembly. Follow these steps to set up your PoKat Ceramic Table Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, flat, and stable surface.
2. **Assemble Lampshade:** The lampshade is typically shipped flat-packed. Expand the lampshade and secure its shape using the provided clips or frame. Ensure the top and bottom rings are properly aligned.
3. **Attach Harp:** Locate the harp, which is the U-shaped metal frame. Squeeze the two ends of the harp together and insert them into the saddle (the small metal piece) on the lamp base directly above the bulb socket. Release the ends to secure the harp in place.
4. **Place Lampshade:** Carefully lower the assembled lampshade onto the harp. The top ring of the lampshade should rest on the top of the harp.
5. **Secure with Finial:** Screw the finial (the decorative knob) onto the threaded rod at the top of the harp. Tighten it gently until the lampshade is held securely in place. Do not overtighten.
6. **Install Bulb:** Insert a compatible light bulb (E26 base, max 60W incandescent or equivalent LED) into the lamp socket.
7. **Position Lamp:** Place the assembled lamp on a stable surface, such as a nightstand, end table, or console. Ensure the cord is not pinched or in a high-traffic area.

Image: Dimensional diagram of the lamp, illustrating its overall height of 24 inches, shade diameter of 12 inches, and base width of 4.5 inches.

Operation

Operating your PoKat Ceramic Table Lamp is straightforward:

1. **Plug In:** Insert the lamp's power plug into a standard 120V AC electrical outlet.
2. **Turn On/Off:** Locate the rotary switch on the lamp socket. Turn the switch clockwise to turn the lamp ON. Turn it counter-clockwise to turn the lamp OFF.

Image: A single PoKat lamp positioned on a nightstand, demonstrating its suitability for bedside use.

Maintenance

Proper maintenance will ensure the longevity and optimal performance of your lamps:

- **Cleaning:**
  - Always unplug the lamp before cleaning.
  - Wipe the ceramic base with a soft, dry cloth. Do not use abrasive cleaners or polishes, as they may damage the finish.

- Dust the lampshade with a soft brush or a lint roller. For deeper cleaning, gently wipe with a slightly damp cloth and allow to air dry completely.

- **Bulb Replacement:**
  - Ensure the lamp is unplugged and the bulb has cooled down completely before attempting to replace it.
  - Unscrew the old bulb counter-clockwise.
  - Screw in a new E26 base bulb (max 60W incandescent or equivalent LED) clockwise until snug. Do not overtighten.

Troubleshooting

If you encounter any issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp not plugged in. Bulb is loose or burnt out. Power outlet is not working. Switch is faulty.	Ensure the lamp is securely plugged into a working outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance. Contact customer support if the switch is faulty.
Light flickers.	Loose bulb. Incorrect bulb type/wattage. Faulty wiring.	Tighten the bulb. Ensure the bulb is compatible (E26 base, max 60W). Unplug the lamp and contact customer support.
Lampshade is wobbly.	Finial is loose. Harp not properly seated.	Tighten the finial. Ensure the harp is securely inserted into the saddle.

If the problem persists after trying these solutions, please contact PoKat Customer Support.

Specifications

Feature	Detail
Brand	PoKat
Model Name	24" Ceramic Table Lamp Set
Product Dimensions	12"D x 12"W x 24"H
Base Material	Ceramic
Finish Type	Rustic
Bulb Base	E26
Max Wattage	60W (Incandescent equivalent)
Lamp Type	Table Lamp

Warranty and Support

PoKat offers a **2-year protection plan** on all ceramic lamps, ensuring peace of mind with your purchase. Every lamp undergoes rigorous quality checks for reliability and durability.

Our dedicated **24/7 customer service team** is available to assist you with any questions or concerns. Please do not hesitate to contact us for support, solutions, or warranty claims.

For assistance, please visit the PoKat Store on Amazon or refer to the contact information provided with your purchase.

© 2023 PoKat. All rights reserved.