Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO EKATM

TRESKO 10L Hot Beverage Dispenser and Mulled Wine Kettle

Model: EKATM | Brand: TRESKO

1. Introduction

This instruction manual provides essential information for the safe and efficient operation, maintenance, and care of your TRESKO 10L Hot Beverage Dispenser. Please read this manual thoroughly before first use and retain it for future reference. This appliance is designed for heating and keeping warm various beverages such as mulled wine, punch, tea, coffee, or water.



Image 1.1: The TRESKO Hot Beverage Dispenser in a kitchen setting, demonstrating its use for various hot beverages like tea, coffee, mulled wine, punch, or cocoa. The appliance is constructed from high-quality stainless steel, ensuring no foreign taste is imparted to your drinks.

2. Safety Instructions

To prevent injury or damage, always observe the following safety precautions:

- Ensure the appliance is placed on a stable, heat-resistant, and level surface, away from edges.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Always unplug the appliance from the power outlet before cleaning, filling, or when not in use.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Exercise extreme caution when handling hot liquids. The exterior surfaces of the appliance can become very hot during operation. Use the heat-resistant carrying handle for transport.
- Do not fill above the maximum fill line indicated on the level indicator.

- The appliance features an overheat protection system. If the appliance runs dry, it will automatically shut off.
- The ON/OFF switch is splash-proof for enhanced electrical safety.



Image 2.1: The TRESKO Hot Beverage Dispenser featuring a heat-resistant carrying handle, designed for safe transport even when the unit is hot.



Image 2.2: A close-up of the control panel, highlighting the splash-proof ON/OFF switch, which provides optimal electrical protection during use.

3. Product Overview

Familiarize yourself with the components of your TRESKO Hot Beverage Dispenser:

1. **Main Unit:** Double-walled stainless steel body for improved insulation.
2. **Lid:** Removable lid to cover the contents.
3. **Heat-Resistant Carrying Handle:** For safe transportation.
4. **Integrated Tap:** For easy dispensing of beverages.
5. **Fill Level Indicator:** Transparent strip to monitor the liquid level.
6. **Temperature Control Dial:** Adjustable thermostat from 30°C to 110°C.
7. **Heating Indicator Light:** Illuminates when the appliance is actively heating.
8. **Keep Warm Indicator Light:** Illuminates when the appliance is maintaining the set temperature.
9. **ON/OFF Power Switch:** Splash-proof switch to turn the appliance on or off.
10. **Power Cord:** For connecting to an electrical outlet.



Image 3.1: Front view of the TRESKO 10L Hot Beverage Dispenser in copper, showing the main unit, tap, level indicator, and control panel.



Image 3.2: Detailed view of the control panel, including the temperature control dial, heating and keep warm indicator lights, and the ON/OFF power switch.



Image 3.3: A close-up of the transparent fill level indicator, which allows for easy monitoring of the liquid volume inside the dispenser.

4. Setup

Before using your TRESKO Hot Beverage Dispenser for the first time, follow these steps:

1. **Unpacking:** Carefully remove the appliance from its packaging. Retain the packaging for future storage or transport.
2. **Initial Cleaning:** Wash the interior of the dispenser and the lid with warm soapy water. Rinse thoroughly with clean water and dry completely. Wipe the exterior with a damp cloth.
3. **Placement:** Place the dispenser on a flat, stable, and heat-resistant surface. Ensure there is adequate space around the appliance for ventilation and to prevent accidental contact with hot surfaces.
4. **Power Connection:** Ensure the ON/OFF switch is in the 'OFF' position before plugging the power cord into a grounded 230V ~ 50Hz electrical outlet.

5. Operating Instructions

Follow these steps to operate your hot beverage dispenser:

1. **Fill the Dispenser:** Remove the lid and fill the main unit with your desired beverage (e.g., water, mulled wine, tea). Do not exceed the 'MAX' mark on the fill level indicator.
2. **Secure the Lid:** Place the lid back onto the dispenser securely.
3. **Set Temperature:** Turn the temperature control dial to your desired temperature between 30°C and 110°C. For boiling, set it to the maximum.
4. **Power On:** Flip the ON/OFF power switch to the 'ON' position. The 'Heating' indicator light will illuminate, indicating the appliance is heating.
5. **Heating Process:** The appliance will heat the liquid to the set temperature. Once the temperature is reached, the 'Heating' light will turn off, and the 'Keep Warm' light will illuminate, indicating the appliance is maintaining the temperature. The heating element will cycle on and off to maintain the set temperature.
6. **Dispensing:** To dispense a beverage, place a cup under the tap. Push the tap lever down for continuous flow or pull it forward to fill a single serving. Release the lever to stop the flow.
7. **Monitoring:** Regularly check the fill level indicator to ensure the appliance does not run dry.
8. **Power Off:** When finished, flip the ON/OFF power switch to the 'OFF' position and unplug the appliance from the power outlet. Allow the appliance to cool down completely before cleaning.



Image 5.1: An internal view of the dispenser, showing the capacity and the integrated tap mechanism for easy serving. The image

depicts mulled wine with fruit, illustrating a typical use case.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Interior Cleaning:** Wash the interior with warm soapy water and a soft sponge. For stubborn residues, a non-abrasive cleaner can be used. Rinse thoroughly and dry completely.
- **Exterior Cleaning:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the finish.
- **Tap Cleaning:** Ensure the tap is clean and free of any blockages. Run clean water through it after each use.
- **Descaling:** Depending on water hardness and frequency of use, limescale may build up. Descale the appliance regularly using a commercial descaling solution suitable for stainless steel kettles, following the product instructions. Alternatively, a solution of white vinegar and water can be used (e.g., 1 part vinegar to 2 parts water). Fill the dispenser, heat to about 50°C, let it sit for an hour, then drain and rinse thoroughly several times.
- **Storage:** Store the clean and dry appliance in a cool, dry place.

7. Troubleshooting

If you encounter issues with your appliance, consult the following table:

Problem	Possible Cause	Solution
Appliance does not heat.	Not plugged in; Power switch off; Temperature dial set too low; Overheat protection activated.	Check power connection; Turn power switch ON; Adjust temperature dial; Allow to cool and reset.
Liquid not hot enough.	Temperature dial set too low.	Increase the temperature setting.
Tap is leaking or blocked.	Residue buildup; Tap not fully closed.	Clean the tap thoroughly; Ensure tap is in the fully closed position.
Heating indicator light not on.	Appliance has reached set temperature; Power off.	This is normal if 'Keep Warm' light is on; Check power switch.

8. Specifications

Feature	Specification
Brand	TRESKO
Model Number	EKATM
Capacity	10 Liters
Power	1500 Watts

Feature	Specification
Voltage	230 Volts
Frequency	50 Hz
Material	Stainless Steel
Color	Copper
Dimensions (L x W x H)	29 x 29 x 53 cm
Weight	Approximately 907 g
Temperature Range	30°C - 110°C (Continuously adjustable)
Special Features	Rapid boiling, Thermostat, Overheat protection, Integrated level indicator, Integrated tap, Double-walled body, Splash-proof ON/OFF switch, Heat-resistant carrying handle.

9. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHDR6CR3

More documents and user manuals: **https://manuals.plus/**