Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Karl home KHMAC1665

Karl home Mid-Century Accent Chair Instruction Manual

Model: KHMAC1665

1. Introduction

Thank you for choosing the Karl home Mid-Century Accent Chair. This modern retro leisure chair is designed to complement various home decor styles, from mid-century modern to country chic. Featuring a solid wood frame and comfortable upholstered fabric, it provides both functionality and elegance to your living space. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure long-lasting enjoyment of your new chair.



Figure 1: Karl home Mid-Century Accent Chair (Creamy-White)

2. Features

- **Mid-Century Retro Charm:** Designed to fit well with various home decor styles, adding exquisiteness and an elegant vibe.
- **Comfortable & Relaxable:** Features dedicated wooden armrests with subtle bend, smooth touch, comfortable Teddy fleece fabric, high-density sponge, and enough back support for maximum comfort.
- **Sturdy Solid Wood Structure:** Constructed with solid rubber wood for legs and internal frame, ensuring durability and stability.
- **Versatile Scenes:** Suitable for placement in the living room, bedroom, balcony, porch, or other desired spaces.
- **Simple Assembly:** Comes with labeled parts and easy-to-follow, detailed instructions for straightforward setup.



Figure 2: Detailed view of chair materials and construction

3. Safety Information

WARNING:

- Ensure to assemble the chair correctly and do not exceed the maximum weight capacity of 330 lb (150 kg) for safe use.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not stand on the chair or use it as a step stool.
- Avoid placing the chair near open flames or excessive heat sources.

4. Setup & Assembly

4.1 Unpacking

1. Carefully open the packaging and remove all components.
2. Lay out all parts on a clean, soft surface (e.g., a rug or blanket) to prevent scratches.
3. Verify that all listed parts and hardware are present according to the included parts list.

4.2 Assembly

The Karl home Mid-Century Accent Chair is designed for simple assembly. Follow the detailed instructions provided in your product packaging. Typically, assembly involves:

1. Attaching the backrest to the seat frame.
2. Securing the armrests to the main frame.
3. Attaching the legs to the base of the chair.
4. Inserting the cushions into their designated positions.
5. Ensure all screws and bolts are tightened securely before use.



Figure 3: Chair dimensions for assembly reference

5. Operating Instructions

Once assembled, your Karl home Mid-Century Accent Chair is ready for use. Simply sit back and enjoy the comfort it provides. The chair is ideal for reading, relaxing, or as an elegant addition to any room. Its sturdy construction ensures a stable and comfortable seating experience.

6. Maintenance

6.1 Cleaning

For general cleaning, wipe the chair clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the fabric or wood finish.

6.2 General Care

- Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary.
- Avoid prolonged exposure to direct sunlight to prevent fading of the fabric and wood.
- Keep the chair away from excessive moisture or humidity.
- For spills, blot immediately with a clean, dry cloth. Do not rub.

7. Troubleshooting

7.1 Common Issues

- **Wobbling:** Check that all assembly bolts are securely tightened. Ensure the chair is on a flat, even surface.
- **Loose Parts:** If any parts feel loose, re-tighten the corresponding screws or bolts. Do not overtighten.
- **Fabric Stains:** For stubborn stains, consult a professional upholstery cleaner or use a fabric-specific cleaning product following its instructions.
- **Creaking Noises:** Ensure all connections are tight. Applying a small amount of furniture wax or silicone spray to joints may help.

8. Specifications

Attribute	Value
Brand	Karl home
Model Name	KHMAC1665
Color	Creamy-white
Product Dimensions	31.9"D x 27.6"W x 33.1"H
Item Weight	26.5 pounds
Maximum Weight Recommendation	330 Pounds
Material	Teddy Fleece Fabric, Solid Rubber Wood Frame, Sponge Fill
Style	Mid-Century Modern
Product Care Instructions	Wipe Clean

Attribute	Value
Room Type	Living Room, Bedroom
Date First Available	October 11, 2022

9. Warranty & Support

Karl home products are manufactured with quality and care. For information regarding warranty coverage or technical support, please refer to the warranty card included with your purchase or visit the official Karl home website. You may also contact customer service through the retailer where the product was purchased.
For further assistance, please contact Karl home customer support:

Website: Karl home Store on Amazon

Email: [Insert Customer Service Email Here]

Phone: [Insert Customer Service Phone Number Here]

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question