Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 1397

TRESKO Oil Radiator Model 1397 - Instruction Manual

Your guide to safe and efficient operation

1. Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the rating label matches your mains supply. Do not operate the heater with a damaged cord or plug. Do not run the power cord under carpeting or cover it with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas where it will not be tripped over.
- **Placement:** Always place the heater on a firm, level surface. Maintain a minimum distance of 1 meter (3 feet) from walls, furniture, curtains, and other combustible materials. Do not use in bathrooms, laundry areas, or similar indoor locations where water may be present.
- **Overheat Protection:** The heater is equipped with an overheat protection system that will automatically shut off the unit if it becomes too hot. If this occurs, unplug the heater, allow it to cool down, and then check for any obstructions.
- **Children and Pets:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Do Not Cover:** Never cover the heater. Covering the heater can cause overheating and fire.
- **Moving the Heater:** Always unplug the heater before moving it. Use the integrated handle and wheels for transport.
- **Maintenance:** Unplug the heater from the power outlet before cleaning or performing any maintenance.

2. Product Overview

The TRESKO Oil Radiator Model 1397 is a mobile, energy-efficient electric heater designed for indoor use. It features a thermostat, multiple power levels, a 24-hour timer, and safety mechanisms like overheat and anti-tip

protection.



Figure 1: TRESKO Oil Radiator 2000W. This image shows the TRESKO Oil Radiator from the front, highlighting its compact design, control panel with thermostat and power settings, and the integrated castor wheels for easy mobility.

Components:

- **Heating Elements:** Oil-filled fins for efficient heat distribution.
- **Control Panel:** Includes thermostat knob, power selector switches, and timer dial.
- **Castor Wheels:** Four wheels for easy movement.
- **Integrated Cable Winder:** For neat cable storage.
- **Power Cord and Plug:** For electrical connection.
- **Handle:** For convenient transport.

3. Assembly and Setup

The TRESKO Oil Radiator comes with castor wheels that need to be attached before first use.

3.1 Attaching the Castor Wheels

1. Carefully turn the radiator upside down, ensuring it is stable.
2. Locate the wheel mounting brackets at the bottom of the radiator.
3. Insert the castor wheels into the designated holes on the brackets. Push firmly until they click into place or secure with provided screws/nuts if applicable (refer to packaging for specific fasteners).
4. Once all four wheels are securely attached, carefully turn the radiator upright.



Figure 2: Radiator with dimensions and wheels. This image illustrates the dimensions of the TRESKO Oil Radiator (24.5 cm depth, 38.5 cm width, 62.5 cm height) and highlights the practical castor wheels and integrated cable winder for convenient storage and movement.

3.2 Initial Placement

- Place the radiator on a stable, level surface.
- Ensure there is at least 1 meter (3 feet) of clear space around the heater to allow for proper air circulation and to prevent fire hazards.
- Unwind the power cord completely from the cable winder before plugging it into an electrical outlet.

4. Operating Instructions

Familiarize yourself with the control panel before operating the heater.



Figure 3: Control Panel. A close-up of the TRESKO Oil Radiator's control panel, showing the three heat settings (800W, 1200W, 2000W), the 24-hour timer dial, and the thermostat knob for temperature adjustment.

4.1 Power On/Off and Heat Settings

1. Plug the heater into a suitable 220-240V / 50/60Hz electrical outlet.
2. Turn the thermostat knob to the maximum setting initially.
3. Select the desired power level using the power selector switches:
    - **Switch 1 (I):** Activates low heat (e.g., 800W).
    - **Switch 2 (II):** Activates medium heat (e.g., 1200W).
    - **Both Switches (I + II):** Activates high heat (e.g., 2000W).
4. The indicator light will illuminate when the heater is operating.
5. To turn off the heater, set both power switches to the 'OFF' position and unplug the unit.

4.2 Thermostat Control

The thermostat maintains the desired room temperature.

1. Once the room reaches a comfortable temperature, slowly turn the thermostat knob counter-clockwise until the heater turns off.
2. The heater will now cycle on and off automatically to maintain this set temperature.
3. Turning the knob clockwise will increase the desired temperature; turning it counter-clockwise will decrease it.

4.3 24-Hour Timer Function

The integrated timer allows you to program the heater to turn on and off automatically within a 24-hour period.

1. The timer dial has segments representing time intervals (e.g., 15-minute segments).
2. Push the segments inwards for the periods you want the heater to be ON. Pull them outwards for the periods you want the heater to be OFF.
3. Ensure the current time is aligned with the arrow on the timer dial. Rotate the dial clockwise to set the current time.
4. The heater will operate according to the programmed schedule.

5. Maintenance

Regular cleaning and proper storage will ensure the longevity and efficient operation of your TRESKO Oil Radiator.

5.1 Cleaning

1. Always unplug the heater and allow it to cool completely before cleaning.
2. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
3. Do not immerse the heater in water or allow water to drip into the interior.
4. Ensure the heater is completely dry before plugging it back in.

5.2 Storage

- When not in use, store the heater in a cool, dry place.
- Wrap the power cord neatly around the integrated cable winder to prevent damage.
- If possible, store the heater in its original packaging to protect it from dust and impacts.

6. Troubleshooting

If you encounter issues with your TRESKO Oil Radiator, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Thermostat set too low. Overheat protection activated. Timer is off.	Check if the plug is securely in the outlet and the outlet is functional. Turn the thermostat knob to a higher setting. Unplug, let cool, check for obstructions, then plug back in. Adjust the timer to an 'ON' period.
Heater produces insufficient heat.	Low power setting selected. Thermostat set too low. Room size too large for heater capacity.	Select a higher power level (e.g., 2000W). Increase the thermostat setting. Ensure the heater is appropriate for the room size (up to 30 m^2).
Heater suddenly turns off.	Overheat protection activated. Anti-tip protection activated. Timer reached end of cycle.	Unplug, let cool, check for obstructions, then plug back in. Ensure the heater is on a stable, level surface. Check the timer settings.

If the problem persists after trying these solutions, please contact customer support.

7. Technical Specifications

Detailed technical information for the TRESKO Oil Radiator Model 1397.

Feature	Specification
Brand	TRESKO
Model Number	1397
Power Output	Up to 2000 W (3 power levels: 800W, 1200W, 2000W)
Voltage	220-240 V / 50/60 Hz
Number of Heating Elements	9 to 11 (depending on variant)
Dimensions (D x W x H)	Approx. 24.5 cm x 38.5 cm x 62.5 cm
Item Weight	10 kg
Color	White
Special Features	Overheat Protection, 3 Power Levels, 24-hour Timer, Castor Wheels, Integrated Cable Winder, Thermostat Control, Anti-tip Protection
Form Factor	Lightweight, Mobile
Usage	Indoor

Feature	Specification
Power Source	Electric Corded
Heating Method	Convection
Mounting Type	Floor Mount



Figure 4: Key Features. This image emphasizes key features of the TRESKO Oil Radiator, including quiet operation, anti-tip protection, high-quality construction, and rapid heating capability.

8. Warranty and Support

Specific warranty details for your TRESKO Oil Radiator Model 1397 are typically provided with the product packaging or on the retailer's website at the time of purchase. Please retain your proof of purchase for any warranty claims.

For technical support, spare parts availability, or further assistance, please refer to the contact information provided by your retailer or the manufacturer, DWD-Company GmbH & Co. KG.

9. Environmental Disposal

Do not dispose of electrical appliances as unsorted municipal waste. Use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

© 2024 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJ7GSKWY

More documents and user manuals: **https://manuals.plus/**