Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BT3000

Braun Beard Trimmer BT3000 User Manual

Model: BT3000

Introduction

This manual provides comprehensive instructions for the safe and efficient use of your Braun Beard Trimmer BT3000. Please read all instructions carefully before using the appliance to ensure optimal performance and safety. Keep this manual for future reference.

Important Safety Information

To reduce the risk of electric shock, injury, or fire, always observe the following safety precautions:

- Always keep the trimmer away from water sources. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- Avoid contact with eyes and skin.
- This appliance is not suitable for use on infants.
- Clean and maintain the trimmer according to the instructions provided in this manual.
- Always unplug the trimmer or remove batteries before cleaning or storing.
- Supervise children when the trimmer is in use or within their reach.

Package Contents

Your Braun Beard Trimmer BT3000 package should contain the following items:

- Braun Beard Trimmer BT3000 unit
- Precision comb (1-10mm)
- Cleaning brush
- Charger (power adapter)
- Travel pouch



Image: The Braun Beard Trimmer BT3000 shown with its included accessories: the trimmer unit, a precision comb, a cleaning brush, and a travel pouch.

Setup

1. Charging the Trimmer

1. Ensure the trimmer is switched off.
2. Connect the charger to the trimmer and plug it into a power outlet.
3. Allow the trimmer to charge fully before first use. A full charge typically provides sufficient operating time.

2. Attaching the Precision Comb

1. Ensure the trimmer is switched off.
2. Align the precision comb with the trimmer head.
3. Gently push the comb onto the trimmer head until it clicks into place.

Operating Instructions

1. Adjusting Trim Length

The Braun BT3000 features a precision wheel for adjusting the trim length. This allows for precise control over your beard style.

1. With the precision comb attached, rotate the precision wheel located on the trimmer body.
2. Select your desired trim length, indicated by the numbers on the wheel (e.g., 1-10mm).



Image: A close-up view of the Braun Beard Trimmer BT3000 showing the precision wheel with length settings and an arrow indicating rotation for adjustment.



Image: A detailed view of the trimmer's precision dial, highlighting the numbered length settings from 1 to 20, allowing for fine-tuned beard trimming.

2. Trimming Your Beard

1. Ensure your beard is clean and dry before trimming.
2. Switch on the trimmer by pressing the power button.
3. Hold the trimmer with the comb flat against your skin.
4. Move the trimmer against the direction of hair growth, using slow, even strokes.
5. For a clean finish, remove the comb and carefully trim edges and contours.

Maintenance

1. Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene.

1. Switch off the trimmer and disconnect it from the power source.
2. Remove the precision comb.
3. Use the provided cleaning brush to remove hair clippings from the trimmer head and comb.
4. The trimmer head and comb can be rinsed under running water. Ensure they are completely dry before reattaching or storing.
5. Do not immerse the main body of the trimmer in water.

2. Storage

Store the trimmer and its accessories in the provided travel pouch in a dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Braun Beard Trimmer BT3000, consider the following common solutions:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Check if the power button is pressed firmly.
- **Reduced trimming performance:** Clean the trimmer head and comb thoroughly to remove any trapped hair. Ensure the blades are not damaged.
- **Battery not charging:** Verify that the charger is properly connected to both the trimmer and the power outlet. Ensure the power outlet is functional.

If problems persist, please contact Braun customer support.

Specifications

Feature	Specification
Brand	Braun
Model Name	BT3000
Power Source	Battery Powered
Blade Material	Stainless Steel
Item Weight	0.37 Kilograms
Package Dimensions	18.7 x 14.5 x 6.2 cm
Batteries	1 Lithium Ion battery (included)

Warranty and Support

For warranty information or customer support, please refer to the warranty card included with your product or visit the official Braun website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJLBLQYF

More documents and user manuals: **https://manuals.plus/**