Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BT3242

Braun Beard Trimmer BT3242 User Manual

Model: BT3242

1. Important Safety Information

Please read these instructions completely before using the appliance. Keep them for future reference. This appliance is designed for household use only.

- Do not use the appliance with a damaged foil or comb, as this may result in injury.
- Do not open the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its supply cord out of reach of children less than 8 years.
- Only use the power supply provided with the appliance.
- The appliance is suitable for cleaning under running tap water.

2. Product Overview and Included Components

The Braun Beard Trimmer BT3242 is designed for precise beard trimming and styling. It features a precision dial for various length settings and comes with essential accessories for a complete grooming experience.



Image 1: Overview of the Braun BT3242 Beard Trimmer, two trimming combs, a cleaning brush, and a Gillette Fusion5 ProGlide razor.

Included Components:

- Braun BT3242 Beard Trimmer unit
- Precision Dial (integrated)
- Short Beard Comb (1-10mm)
- Long Beard Comb (11-20mm)
- Gillette Fusion5 ProGlide Razor
- Cleaning Brush
- Charging Cable

3. Setup and Initial Use

3.1 Charging the Trimmer

1. Ensure the trimmer is switched off.
2. Connect the charging cable to the trimmer and plug it into a power outlet.
3. The charging indicator light will illuminate. A full recharge takes approximately 8 hours.
4. Once fully charged, the trimmer provides up to 80 minutes of cordless trimming.

The trimmer can be used corded or cordless.

3.2 Attaching Trimming Combs

Select the appropriate comb for your desired beard length:

- **Short Beard Comb:** For lengths between 1mm and 10mm.
- **Long Beard Comb:** For lengths between 11mm and 20mm.

1. Align the comb with the trimmer head.
2. Press the comb firmly onto the trimmer head until it clicks into place.
3. To remove, gently pull the comb upwards from the trimmer head.

4. Operating the Trimmer

4.1 Adjusting Trimming Length

The precision dial allows for 39 length settings in 0.5mm steps, from 0.5mm to 20mm.



Image 2: The precision dial on the Braun BT3242 trimmer, used to select desired hair length.

1. Ensure a comb is attached.
2. Rotate the precision dial to select your desired trimming length. The selected length will be indicated on the dial.
3. For trimming without a comb, the trimmer provides a 0.5mm cut.

4.2 Trimming Your Beard

1. Turn on the trimmer by pressing the power button.

2. Hold the trimmer with the comb flat against your skin.
3. Move the trimmer against the direction of hair growth for an even trim.
4. For edging and defining lines, remove the comb and use the trimmer head directly against the skin.

4.3 Using the Gillette Fusion5 ProGlide Razor

The included Gillette Fusion5 ProGlide razor can be used for a clean shave on areas where you desire no hair, or for precise edging and detailing after trimming with the BT3242.

- Wet your face with warm water and apply shaving gel or foam.
- Shave in the direction of hair growth for a comfortable shave, or against for a closer shave.
- Rinse the razor blades frequently during shaving.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your Braun Beard Trimmer.

5.1 Cleaning the Trimmer Head and Combs

1. Turn off the trimmer and disconnect it from the power supply.
2. Remove the trimming comb.
3. Use the provided cleaning brush to remove hair from the trimmer head and combs.
4. The trimmer is fully washable. You can rinse the trimmer head and combs under running tap water.
5. Allow all parts to air dry completely before reassembling or storing.

Note: Do not immerse the entire trimmer unit in water for extended periods. Only the head and combs are designed for rinsing.

5.2 Blade Lubrication

For continued smooth operation, it is recommended to periodically lubricate the trimmer blades with a drop of light machine oil (not included). Apply oil to the blades after cleaning and before storage.

5.3 Storage

Store the trimmer and its accessories in a dry place, away from direct sunlight and extreme temperatures. Ensure the trimmer is clean and dry before storage.

6. Troubleshooting

If you encounter issues with your Braun Beard Trimmer BT3242, please refer to the following common solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is discharged.	Charge the trimmer for 8 hours.
Trimmer performance is poor or pulls hair.	Blades are clogged with hair or not lubricated.	Clean the trimmer head and blades thoroughly. Apply a drop of lubricating oil.
Comb attachment does not stay on.	Comb is not properly attached.	Ensure the comb clicks firmly into place. Check for any damage to the comb or trimmer head.

If the problem persists after attempting these solutions, please contact Braun customer support.

7. Specifications

Model:	BT3242
Brand:	Braun
Power Source:	Battery Powered
Charging Time:	Approximately 8 hours for full charge
Operating Time:	Up to 80 minutes cordless trimming
Length Settings:	39 (0.5mm to 20mm in 0.5mm steps)
Included Combs:	1-10mm, 11-20mm
Washable:	Yes (trimmer head and combs)
Item Weight:	0.46 Kilograms
Package Dimensions:	25.6 x 13.6 x 5.9 cm

8. Warranty and Support

Braun products are manufactured to meet high quality standards. In the unlikely event of a defect, your product is covered by a manufacturer's warranty.

- For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Braun website.
- For technical assistance, spare parts, or service, please contact Braun customer support. Contact information can typically be found on the Braun website or on the product packaging.
- You can also visit the official Braun Store on Amazon for more information and product registration.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJLG4Y7J

More documents and user manuals: **https://manuals.plus/**