Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard SOULBB

Billboard Soul Sound Wireless Speaker Instruction Manual

Model: SOULBB

1. Introduction

Thank you for choosing the Billboard Soul Sound Wireless Speaker. This manual provides detailed instructions to help you get the most out of your new speaker. Designed for portability and powerful sound, the Soul Sound speaker features IPX5 water resistance, vibrant LED lights, and versatile connectivity options including USB and 3.5mm, along with voice assistant compatibility.
Key features include:

- IPX5 Water Resistance (Resistant to water jets)
- Integrated LED Lights (RGB light up)
- USB and 3.5mm Connectivity
- Voice Assistant Compatibility
- Portable Design with Built-in Handle

2. Setup

2.1 Unboxing and Components

Carefully remove all items from the packaging. Please ensure you have the following components:

- Billboard Soul Sound Wireless Speaker
- Charging Cable



Front view of the Billboard Soul Sound Wireless Speaker, showcasing its sleek black design and integrated handle.

2.2 Charging the Speaker

Before first use, fully charge the speaker. Connect the included charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The charging indicator lights will show the charging status.

- A full charge typically takes approximately 3-4 hours.
- Battery life is approximately 5 hours on a full charge, depending on usage.

2.3 Powering On/Off

To power on the speaker, press and hold the Power button located on the top panel until you hear an audible prompt and the LED lights illuminate. To power off, press and hold the Power button again until the speaker shuts down.

3. Operating Your Speaker

3.1 Bluetooth Pairing

The Billboard Soul Sound speaker uses Bluetooth technology for wireless audio streaming. Follow these steps to pair your device:

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing Bluetooth indicator light).
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "Billboard Soul Sound" from the list.
4. Once connected, the Bluetooth indicator light will become solid, and you will hear a confirmation tone.

3.2 Controls and Functions



Close-up of the speaker's top panel, showing power, volume, play/pause, mode, and light controls.

- **Power Button:** Press and hold to turn on/off.
- **Volume -** / **Previous Track:** Short press for volume down. Long press for previous track.
- **Play/Pause** / **Call Answer:** Short press to play/pause music. Short press to answer/end calls.
- **Volume +** / **Next Track:** Short press for volume up. Long press for next track.
- **Mode Button:** Short press to switch between Bluetooth, USB, and AUX modes.
- **Light Button:** Short press to cycle through LED light modes or turn them off.

3.3 LED Light Features

The speaker features dynamic RGB LED lights that enhance your listening experience. Use the dedicated Light button to change light patterns or turn them off according to your preference.



Side profile of the speaker, highlighting the circular LED light on the end, illuminated in red.

3.4 Water Resistance (IPX5)

The Billboard Soul Sound speaker is IPX5 water-resistant, meaning it can withstand low-pressure water jets from any direction. This makes it suitable for outdoor use or near water. **Do not submerge the speaker in water.** Ensure all port covers are securely closed before exposing the speaker to water.

4. Maintenance

To ensure the longevity and optimal performance of your Billboard Soul Sound speaker, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. For stubborn dirt, a slightly damp cloth can be used, but ensure the speaker is completely dry before use or charging. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct

sunlight and extreme temperatures.

- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use, to maintain battery health.
- **Water Resistance:** Always ensure the charging port and other input covers are firmly sealed when using the speaker near water or in damp environments to maintain its IPX5 rating.

5. Troubleshooting

If you encounter any issues with your speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the Power button for a few seconds.
No sound.	Volume too low; Device not paired; Incorrect mode selected.	Increase speaker and device volume. Re-pair Bluetooth. Press Mode button to select correct input.
Bluetooth connection unstable or fails.	Too far from device; Interference; Device Bluetooth off.	Move speaker closer to device. Avoid obstacles. Turn device Bluetooth off/on. Forget device and re-pair.
LED lights not working.	Lights turned off; Malfunction.	Press the Light button to cycle through modes. If issue persists, contact support.

6. Specifications

Feature	Detail
Model Name	SOULBB (Soul Family)
Speaker Type	Coaxial
Special Feature	RGB light up
Recommended Uses	For smartphones or tablets, For computers
Compatible Devices	Smartphone, Tablet, Laptop, Television
Controller Type	Voice Control
Color	Black Soul Sound
Battery Life	5 Hours
Dimensions (L x W x H)	37 cm x 14 cm x 20 cm

Feature	Detail
Waterproof Rating	IPX5 (True)
Connectivity Technology	USB
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
Manufacturer	Stuffactory



Diagram showing the speaker's dimensions: 37 cm length, 14 cm width, and 20 cm height.

7. Warranty and Support

7.1 Limited Warranty

This product comes with a limited warranty provided by the manufacturer, Stuffactory. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use conditions.

7.2 Returns Policy

This product is eligible for a 30-day free return period from the date of purchase. Please refer to the retailer's return policy for specific terms and conditions.

7.3 Customer Support

For further assistance, technical support, or warranty inquiries, please contact the manufacturer or visit the official Billboard store on Amazon:

Visit the Billboard Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJYKV9NP

More documents and user manuals: **https://manuals.plus/**