Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pentax KF

PENTAX KF APS-C Digital SLR Camera with 18-55 WR Lens Kit User Manual

Model: KF

1. Introduction

The PENTAX KF is a compact digital SLR camera designed for advanced photography, offering robust performance in various outdoor conditions. It features a weather-resistant construction, an articulated LCD monitor, and a suite of creative functions.

Key Features:

- 24.24 effective megapixel APS-C CMOS sensor without a low-pass filter, offering an ISO range from 100 to 102400.
- Weather-resistant body, dustproof and resistant to inclement weather, with an integrated "SR" (Shake Reduction) mechanism.
- Articulated LCD monitor with a red-light profile option for improved night visibility.
- Pixel Shift Resolution technology with a low-pass filter simulator and motion correction.
- SAFOX X autofocus system with 11 AF points, including 9 cross-type sensors.
- Integrated Wi-Fi for use with the Image Sync app.
- Optional GPS unit for automatic celestial body tracking (Astrotracer function).

2. Setup

This section guides you through the initial setup of your PENTAX KF camera.

2.1 Unpacking and Included Items

Carefully unpack your camera and ensure all components are present:

- PENTAX KF Camera Body
- SMC PENTAX-DAL 18-55mm AL WR Lens
- USB Cable
- Lithium-ion Battery

- Battery Charger
- Strap
- Software (CD ROM)
- AC Plug
- USB Power Adapter
- Viewfinder Eyecup
- Flash Shoe Cover
- Body Cap

2.2 Battery Installation and Charging

1. Open the battery compartment cover on the bottom of the camera.
2. Insert the lithium-ion battery with the correct orientation.
3. Close the battery compartment cover securely.
4. To charge, connect the battery charger to a power outlet and insert the battery. The charging indicator will show the status.

2.3 Attaching the Lens

1. Remove the body cap from the camera and the rear lens cap from the lens.
2. Align the red dot on the lens with the red dot on the camera's lens mount.
3. Insert the lens into the mount and rotate it clockwise until it clicks into place.

2.4 Inserting a Memory Card

The PENTAX KF supports SDHC and SDXC flash memory cards.

1. Open the memory card slot cover.
2. Insert the memory card with the label facing the front of the camera until it clicks.
3. Close the memory card slot cover.

2.5 Initial Power On

Turn the power dial to the 'ON' position. The camera will power on, and the LCD monitor will display information. Set the date, time, and language as prompted.

3. Operating the Camera

This section covers the basic and advanced operations of your PENTAX KF camera.

3.1 Basic Controls and Display

Familiarize yourself with the camera's buttons and the information displayed on the LCD monitor.

Figure 3.1: Rear view of the PENTAX KF camera, displaying the LCD screen with current shooting settings such as shutter speed (1/125), aperture (F5.6), and ISO (200).

Figure 3.2: The PENTAX KF camera with its articulated LCD screen extended, allowing for flexible viewing angles during shooting.

3.2 Shooting Modes

The mode dial allows you to select various shooting modes, including:

- **Auto:** Camera automatically sets optimal exposure.
- **Program (P):** Camera sets aperture and shutter speed, but you can shift the combination.
- **Shutter Priority (Tv):** You set shutter speed, camera sets aperture.
- **Aperture Priority (Av):** You set aperture, camera sets shutter speed.
- **Manual (M):** You set both aperture and shutter speed.
- **Scene Modes:** Pre-set modes for specific situations (e.g., Portrait, Landscape).

3.3 Shake Reduction (SR) Mechanism

The PENTAX KF features an in-body Shake Reduction mechanism to minimize camera shake, especially useful in low light or with telephoto lenses.



Figure 3.3: Diagram showing the integrated SR (Shake Reduction) mechanism in the PENTAX KF, which effectively compensates for camera shake by shifting the image sensor.

3.4 Optical Viewfinder

The camera is equipped with a bright optical viewfinder, providing a clear and wide view of your subject.



Figure 3.4: Illustration of the PENTAX KF's optical viewfinder, highlighting its wide field of view and magnification for precise composition.

3.5 Astrotracer Function (with optional GPS unit)

For astrophotography, the PENTAX KF can utilize an optional O-GPS unit to track celestial bodies, allowing for extended exposures without star trails.



Figure 3.5: The PENTAX KF camera shown alongside the optional O-GPS unit, which enables the Astrotracer function for automatic celestial tracking in astrophotography.

3.6 Weather Resistance

The PENTAX KF is designed with 100 sealing parts to prevent the intrusion of water and dust, making it suitable for challenging environments. When paired with a PENTAX AW- or WR-series lens, it forms a highly dependable imaging system.



Figure 3.6: A visual representation of the PENTAX KF's weather-resistant construction, highlighting the sealing points that protect against dust and water intrusion.

3.7 Astrophotography Features

Beyond Astrotracer, the KF offers features like a red-light monitor display and interval composite shooting for stunning

astrophotography results.



Figure 3.7: Examples of astrophotography, including an interval composite image of star trails and a view of the red-light monitor display during night shooting, demonstrating the PENTAX KF's capabilities.

3.8 Video Recording

The PENTAX KF supports video recording at 1080p resolution in XAVC format. To start recording, switch to video mode and press the record button.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your camera.

4.1 Cleaning the Camera

- **Body:** Wipe with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly.
- **Lens:** Use a lens brush to remove dust, then a lens cloth with a specialized lens cleaning solution. Avoid touching the glass directly.
- **Sensor:** If dust appears on images, use the camera's built-in sensor cleaning function or a blower bulb. For persistent dust, consult a professional service center.

4.2 Battery Care

- Store batteries in a cool, dry place when not in use.
- Avoid fully discharging the battery frequently.
- Do not expose batteries to extreme temperatures.

4.3 Storage

When storing the camera for extended periods, remove the battery and memory card. Store the camera in a dry, dust-free environment, preferably with desiccant to prevent mold growth.

5. Troubleshooting

This section addresses common issues you might encounter with your PENTAX KF camera.

5.1 Camera Does Not Power On

- Ensure the battery is fully charged and correctly inserted.
- Check if the battery contacts are clean.
- Try using a different charged battery if available.

5.2 Images Are Blurry

- Check if the lens is properly focused.
- Ensure the Shake Reduction (SR) function is enabled if shooting handheld in low light.
- Verify that the shutter speed is fast enough for the shooting conditions.
- Clean the lens and sensor if smudges or dust are present.

5.3 Memory Card Error

- Ensure the memory card is inserted correctly.
- Try formatting the memory card (this will erase all data).
- Use a different compatible memory card.

5.4 Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled on both the camera and your smart device.
- Restart both devices.
- Check the Image Sync app for any specific connection instructions.

6. Specifications

Detailed technical specifications for the PENTAX KF camera.

Feature	Specification
Model Name	Pentax KF
Sensor Type	APS-C CMOS
Effective Pixels	24.24 MP
ISO Sensitivity	100 - 102400
Image Stabilization	Sensor-shift (SR)
Autofocus System	SAFOX X, 11 points (9 cross-type)
Shutter Speed	1/6000 to 0.2 seconds
Continuous Shooting	5 FPS
Video Resolution	1080p
Video Format	XAVC
LCD Monitor	3-inch Articulated LCD
Viewfinder	Optical
Connectivity	Wi-Fi, USB
Memory Card Slot	SDHC, SDXC (UHS-I compatible)
Lens Mount	Pentax K-mount
Weight (Body only)	Approx. 50 Grams (excluding battery and memory card)
Included Lens	18-55mm F4.0-F5.6 WR
UPC	027075305168
Manufacturer Part Number	01202

7. Warranty and Support

7.1 Product Warranty

The PENTAX KF camera comes with a**1-year product warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but typically excludes damage caused by misuse, accidents, or unauthorized repairs.

7.2 Customer Support

For technical assistance, service, or further inquiries, please visit the official Pentax support website or contact their customer service department. You can also find additional resources and FAQs on the Pentax Brand Store on Amazon.

© 2026 Pentax. All rights reserved.
This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLW5PC88

More documents and user manuals: **https://manuals.plus/**