Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 51-W1200S

Braun Series 5 Electric Shaver 51-W1200s User Manual

Model: 51-W1200S | Brand: Braun

1. Introduction

Thank you for choosing the Braun Series 5 Electric Shaver. This manual provides important information on the safe operation, maintenance, and troubleshooting of your new shaver. Please read these instructions carefully before using the appliance and keep them for future reference.

2. Product Overview

The Braun Series 5 Electric Shaver 51-W1200s is engineered for a close and comfortable shave, adapting to your facial contours. It features advanced technology for an efficient and personalized grooming experience.



The Braun Series 5 Electric Shaver 51-W1200s in white, shown alongside its precision trimmer attachment. The shaver features a sleek design with a power button and battery indicator lights.

付属品一覧　※特典ブラシも別途付属します



This image displays all included accessories: the shaver body, a precision trimmer, a cleaning brush, and the power cord. Note that a bonus cleaning brush is also included.



A hand demonstrates the shaver's 3-blade flexible head, designed to closely adhere to skin contours for a simpler, deeper shave.



The shaver is shown being rinsed under running water, illustrating the Quick Wash System that allows for easy and hygienic cleaning without needing to remove the foil head.



A man shaves with the Braun Series 5, highlighting its Artificial Intelligence Technology which adjusts power based on beard density to maintain powerful shaving performance.



This image shows the shaver with its precision trimmer attachment, demonstrating the simple head switching system that allows users to freely change heads to suit their grooming needs, such as for sideburns.



The Braun Series 5 shaver is presented on a textured grey background, accompanied by a German flag icon, emphasizing its German brand craftsmanship.

Key Features:

- **3-Blade Flexible Head:** Closely adheres to skin contours for a deeper, simpler shave.
- **Quick Wash System:** Enables easy and hygienic daily cleaning without removing the foil head.
- **Artificial Intelligence Technology:** Reads beard density and automatically adjusts power 13 times per second for efficient shaving.
- **Simple Head Switching System:** Allows for free switching of heads to meet various grooming needs, including a precision trimmer for sideburns.
- **100% Waterproof Design:** Suitable for wet and dry use with foam or gel.
- **Ergonomic Handle Design:** Provides a comfortable grip for simple and low-stress shaving.

3. Setup

Initial Charging:

1. Ensure the shaver is turned off.
2. Connect the power cord to the shaver and plug it into an AC100-240V power outlet.
3. Charge the shaver for approximately 1 hour for a full charge. The battery indicator lights will show the charging status.
4. A full charge provides sufficient power for multiple shaves.

Attaching/Detaching Heads:

- To attach a head (e.g., precision trimmer), align the head with the shaver body and press firmly until it clicks into place.
- To detach a head, gently pull it away from the shaver body.

4. Operating Instructions

Basic Shaving:

1. Press the power button to turn on the shaver.
2. Hold the shaver at a right angle (90°) to your skin.
3. Stretch your skin and shave against the direction of beard growth.
4. Apply gentle pressure; the shaver's flexible head will adapt to your facial contours.
5. For best results, shave before washing your face.

Wet Shaving:

- The shaver is 100% waterproof and can be used with shaving foam or gel.
- Apply foam or gel to your face as usual before shaving.
- Rinse the shaver head under running water during and after use.

Using the Precision Trimmer:

- Attach the precision trimmer head to the shaver body.
- Use the trimmer for shaping sideburns, mustaches, or for pre-trimming longer hairs before shaving.
- Hold the trimmer at a slight angle to the skin and move it slowly against the direction of hair growth.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your shaver.

Quick Wash System:

1. After each shave, turn on the shaver.
2. Rinse the shaver head under hot running water. You do not need to remove the foil head.
3. For a more thorough cleaning, you can use a small amount of liquid soap.
4. Rinse thoroughly until all residue is gone.
5. Turn off the shaver and gently tap off excess water.
6. Allow the shaver head to air dry completely before reattaching the protection cap.

Deep Cleaning (Periodically):

- For a deeper clean, remove the foil head.
- Use the included cleaning brush to brush away any trapped hair from the foil and cutter block.
- Do not use the brush on the foil itself, as this can damage it.
- Rinse both parts under running water.
- Allow to air dry completely before reassembling.

Lubrication:

- Periodically apply a drop of light machine oil (e.g., sewing machine oil) to the foil and cutter block to maintain optimal performance.

6. Troubleshooting

If you encounter any issues with your shaver, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes, or fully charge for 1 hour.
Poor shaving performance.	Foil or cutter block is worn or dirty.	Clean the shaver thoroughly. Consider replacing the foil and cutter block if they are old (recommended every 18 months).
Shaver pulls hair.	Battery is low; hairs are too long.	Fully charge the shaver. If hairs are long, use the precision trimmer first.
Shaver makes unusual noise.	Hair trapped in the head; damaged part.	Clean the shaver head thoroughly. If noise persists, contact customer support.

7. Specifications

Feature	Specification
Model Number	51-W1200S
Power Source	Rechargeable Battery
Voltage	AC100-240V
Charging Time	Approx. 1 hour
Operating Time	Up to 50 minutes (approx.)
Dimensions (W x D x H)	6.4 x 5.1 x 16.6 cm
Weight	Approx. 173g
Color	White
Blade Material	Stainless Steel
Head Type	Reciprocating
Waterproof	100% Waterproof

Feature	Specification
Included Accessories	Precision trimmer, Foil protection cap, Power cord, Cleaning brush

8. Warranty and Support

Braun products are manufactured to the highest standards of quality, safety, and reliability. This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For further assistance, product information, or to purchase replacement parts, please visit the official Braun website or contact Braun customer service in your region. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BMVH9K7C

More documents and user manuals: **https://manuals.plus/**