Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP XPB38-ZK3

ZOKOP Compact Single Tub Washing Machine User Manual

Model: XPB38-ZK3

1. Important Safeguards

Please read all instructions carefully before using this appliance to ensure safe and efficient operation. Keep this manual for future reference.

- Always unplug the washing machine from the power outlet when not in use or before cleaning.
- Do not operate the machine with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not immerse the electrical parts of the machine in water or other liquids.
- Ensure the machine is placed on a stable, level surface to prevent vibration and noise during operation.
- Do not wash items that are soiled with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Keep children and pets away from the machine during operation.

2. Product Overview

The ZOKOP XPB38-ZK3 is a compact, semi-automatic single tub washing machine designed for small loads. It features a built-in drain pump for convenient water disposal.



Figure 2.1: Front view of the ZOKOP XPB38-ZK3 washing machine.



Figure 2.2: The washing machine shown with its removable stainless steel spin basket.

Key Components:

- **Wash Tub:** Main compartment for washing clothes.
- **Spin Basket:** Removable stainless steel basket for spinning clothes.
- **Control Knobs:** For setting wash timer and wash/drain function.
- **Water Inlet:** Connection point for water supply.
- **Drain Hose:** For expelling dirty water.
- **Power Cord:** For electrical connection.

3. Setup

Proper setup ensures optimal performance and safety of your washing machine.

3.1 Unpacking

1. Carefully remove the washing machine from its packaging.

2. Check for any shipping damage. If damaged, do not operate and contact customer support.
3. Remove all packing materials, including any protective films or tapes.

3.2 Placement

1. Place the machine on a firm, level surface to minimize vibration and noise during operation.
2. Ensure there is adequate space around the machine for ventilation and access.
3. Avoid placing the machine in direct sunlight or in areas with extreme temperatures.

3.3 Water Connection

1. Connect the water inlet hose (not included, typically) to a cold water tap.
2. Ensure the connection is secure to prevent leaks.
3. Place the drain hose into a sink, bucket, or floor drain. The built-in drain pump allows for flexible drain placement, but ensure the hose is not kinked or blocked.



Figure 3.1: Side view illustrating the drain hose connection.

3.4 Power Connection

1. Plug the power cord into a grounded electrical outlet.
2. Do not use extension cords or adapters.

4. Operating Instructions

Follow these steps for effective washing and spinning.



Figure 4.1: Top view displaying the control panel with wash timer and function knobs.

4.1 Washing Clothes

1. **Load Clothes:** Open the lid and place clothes loosely into the wash tub. Do not overload the machine. The maximum capacity is 10 lbs.
2. **Add Water:** Fill the tub with water to the desired level. You can use the water inlet hose or manually pour water.

3. **Add Detergent:** Add the appropriate amount of laundry detergent directly into the tub.
4. **Set Wash Timer:** Turn the wash timer knob to select the desired wash time (e.g., 0-15 minutes).
5. **Select Function:** Turn the function knob to "Wash".
6. **Start Washing:** The machine will begin the wash cycle.
7. **Drain Water:** Once the wash cycle is complete, turn the function knob to "Drain" to empty the water from the tub. The built-in pump will activate.

4.2 Rinsing Clothes

1. After draining the wash water, refill the tub with clean water.
2. You may add fabric softener at this stage if desired.
3. Set the wash timer for a shorter duration (e.g., 3-5 minutes) and turn the function knob to "Wash" for rinsing.
4. Drain the rinse water by turning the function knob to "Drain".

4.3 Spinning Clothes

1. Carefully transfer the rinsed clothes into the removable spin basket. Ensure clothes are evenly distributed to prevent imbalance.
2. Place the spin basket securely into the wash tub.
3. Close the lid.
4. Turn the wash timer knob to select the desired spin time (e.g., 1-5 minutes).
5. Turn the function knob to "Spin".
6. The machine will begin spinning. Do not open the lid during the spin cycle.
7. Once the spin cycle is complete, remove the clothes.

5. Maintenance

Regular maintenance helps prolong the life of your washing machine.

5.1 Cleaning the Exterior

- Wipe the exterior of the machine with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.

5.2 Cleaning the Interior

- After each use, wipe down the inside of the tub to remove any residue.
- Periodically, run a wash cycle with hot water and a cup of white vinegar (without clothes) to clean the tub and remove odors.

5.3 Drain Hose Care

- Ensure the drain hose is free from kinks or blockages.
- Clean any lint or debris from the drain filter (if accessible and present) regularly.

5.4 Storage

- If storing the machine for an extended period, drain all water completely.
- Unplug the power cord and store it neatly.
- Store the machine in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Machine does not start.	Not plugged in; power outage; lid not closed properly.	Ensure power cord is securely plugged in; check circuit breaker; close lid completely.
Water does not drain.	Drain hose kinked or blocked; drain pump malfunction; function knob not set to "Drain".	Straighten drain hose; clear any blockages; ensure function knob is set to "Drain".
Excessive vibration or noise during spin.	Machine not level; clothes unevenly distributed in spin basket; overloading.	Adjust machine to be level; redistribute clothes evenly; reduce load size.
Water leaks.	Hose connections loose; drain hose not properly placed; tub overloaded.	Tighten hose connections; ensure drain hose is secure; do not exceed maximum water level.

7. Specifications

Technical details for the ZOKOP XPB38-ZK3 washing machine.

Feature	Detail
Model	XPB38-ZK3
Type	Compact Single Tub Semi-Automatic Washing Machine
Capacity	10 lbs (approx. 4.5 kg)
Color	Gray Cover
Drain System	Built-in Drain Pump
Drum Material	Stainless Steel (Spin Basket)
Special Features	Compact design

8. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact the retailer where the product was purchased.
Keep your proof of purchase for any warranty claims.

© 2024 ZOKOP. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQ9WWMHX

More documents and user manuals: **https://manuals.plus/**