Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RM-C3338-JV001

RM-C3338 Remote Control User Manual

Replacement Remote Control for JVC 4K UHD TVs

1. Introduction

This manual provides comprehensive instructions for the Azwok RM-C3338 replacement remote control, designed for various JVC 4K UHD TV models. This remote is a direct replacement and requires no programming.

Compatible JVC TV Models:

- LT-24C680, LT-24C681, LT-24C685, LT-24C686
- LT-32C690, LT-32C691, LT-32C695, LT-32C696
- LT-32C790, LT-32C795
- LT-40C790, LT-40C890
- LT-43C790, LT-43C795, LT-43C890, LT-43C898
- LT-49C790, LT-49C890, LT-49C898
- LT-55C870, LT-55C898





Figure 1: Front view of the RM-C3338 Remote Control, showing all buttons and the model number at the bottom.

2. Setup

2.1 Battery Installation

The RM-C3338 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.





Figure 2: Rear view of the RM-C3338 Remote Control with the battery cover open, illustrating the battery insertion points.

3. Operating Instructions

The RM-C3338 remote control is pre-programmed and ready for immediate use with compatible JVC 4K UHD TV models once batteries are installed. No additional setup or pairing is required.

3.1 Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Up/Down (V+ / V-):** Adjusts the TV volume.
- **Channel Up/Down (P+ / P-):** Changes TV channels.
- **Mute ( ):** Mutes or unmutes the TV sound.
- **Home ( ):** Accesses the TV's smart home screen or main menu.
- **Navigation Buttons (▲ ▼ ◀ ▶):** Used to navigate through menus and options.
- **OK Button:** Confirms selections in menus.
- **BACK Button:** Returns to the previous screen or menu.
- **EXIT Button:** Exits the current menu or application.

3.2 Smart TV and Media Buttons

- **Netflix Button:** Direct access to the Netflix application.
- **YouTube Button:** Direct access to the YouTube application.
- **Prime Video Button:** Direct access to the Amazon Prime Video application.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Control media playback within compatible applications.



Figure 3: Angled view of the RM-C3338 Remote Control, illustrating the ergonomic design and button placement.

4. Maintenance

4.1 Cleaning the Remote

To maintain the remote control's appearance and functionality, wipe it regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.

4.2 Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Remote Sensor:** Ensure the TV's infrared sensor is clean and not blocked.
- **TV Compatibility:** Verify that your JVC TV model is listed as compatible in Section 1.

5.2 Buttons Not Working

- **Clean Buttons:** Dirt or debris might be under the buttons. Gently clean around the affected buttons.
- **Battery Check:** Low batteries can sometimes cause intermittent button functionality. Replace them.

6. Specifications

Feature	Detail
Model Number	AU-RM-C3338-JV001
Compatible Brand	JVC
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	8.27 x 1.77 x 0.79 inches
Item Weight	2.46 ounces
Special Feature	No Programming Required

7. Warranty and Support

7.1 Warranty Information

This replacement remote control comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. If the product does not work with your compatible device, returns are accepted for refund or exchange.

7.2 Customer Support

If you encounter any issues not covered in this manual, or if your specific JVC TV model is not listed and you wish to confirm compatibility, please contact the seller or manufacturer for assistance. Provide your product model number (RM-C3338) and your TV's model number for quicker support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQN9WBTZ

More documents and user manuals: **https://manuals.plus/**