Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok QT1D

Azwok QT1D Remote Control User Manual

Replacement Remote for Soniq HD TV Models

1. Introduction

This manual provides comprehensive instructions for the Azwok QT1D replacement remote control, designed for various Soniq HD TV models. This remote is ready to use without any programming, requiring only the installation of batteries.

Compatible Soniq TV Models:

- E24Z15B, E23Z13A-AU, E23Z15A-AU, E24Z15B-AU
- E32V15B-AU, E32V15D-AU, E32V16B-AU, E32V17A-AU, E32V17B-AU
- E32W13A-AU, E32W13B-AU, E32W13D-AU
- E40V14A-AU, E40V14B-AU, E40V16A-AU, E40W13A-AU, E40W13C-AU
- E42V14A-AU, E43V15B-AU, E43V15C-AU, E43V15D-AU
- E48W13A-AU, L32V12B-AU
- E24HZ17B-AU, E32HV18A-AU, E42FV16A-AU, E48FH16A-AU, E55FV16A-AU
- S55UV16A-AU, S55UV16B-AU, S65UX16A-AU
- E24Z15B-AU REV.A, E43V15C-AU REV.B, E32HV18A-AU REV.A



Figure 1: Front view of the Azwok QT1D Replacement Remote Control.

2. Setup

2.1 Battery Installation

The Azwok QT1D remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.




ABS
ZF-463
19-11
CE
MADE IN CHINA



Figure 2: Back view of the remote control with the battery compartment open, showing AAA battery slots.

2.2 Initial Use

No programming is required for this replacement remote control. Once batteries are correctly installed, the remote is ready for immediate use with compatible Soniq HD TV models.

3. Operating Instructions

The Azwok QT1D remote control replicates the functions of your original Soniq TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions:

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or restores the TV audio.
- **0-9 (Number Buttons):** Selects channels directly.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels sequentially.
- **MENU:** Accesses the TV's main menu.
- **OK:** Confirms selections within menus.
- **Arrow Buttons (Up/Down/Left/Right):** Navigates through menus and options.
- **EXIT:** Exits the current menu or function.
- **SOURCE/INPUT:** Selects input sources (HDMI, AV, etc.).
- **P.MODE:** Changes picture modes.
- **S.MODE:** Changes sound modes.
- **SUBTITLE:** Activates or deactivates subtitles.
- **INFO:** Displays program information.
- **SLEEP:** Sets the sleep timer.
- **FAV:** Accesses favorite channels.
- **ASPECT:** Changes the screen aspect ratio.
- **PAUSE:** Pauses playback (if supported by the TV/media).
- **DVD:** Switches to DVD input (if applicable).
- **I-II/AUDIO:** Selects audio tracks or stereo/mono.
- **EPG:** Accesses the Electronic Program Guide.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context, often used for interactive features or teletext.

4. Maintenance

4.1 Cleaning the Remote Control

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both AAA

batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

5. Troubleshooting

If you experience issues with your Azwok QT1D remote control, refer to the following common troubleshooting steps:

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Specific buttons not working:**
  - This may indicate a faulty button or a need for battery replacement. Try replacing batteries first.
  - Ensure the button's function is applicable to your TV model (e.g., some older TVs may not support all advanced functions).
- **Intermittent response:**
  - Weak batteries are often the cause. Replace them.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.

If the issue persists after following these steps, please refer to the Support section for further assistance.

6. Specifications

Model Number	AU-QT1D-SQ001 (QT1D)
Product Dimensions	8.27 x 1.97 x 0.79 inches (21 x 5 x 2 cm)
Item Weight	3.17 ounces (90 grams)
Batteries Required	2 x AAA batteries (not included)
Connectivity Technology	Infrared (IR)
Compatible Devices	Soniq HD Televisions
Special Feature	No Programming Required

7. Warranty and Returns

The Azwok QT1D replacement remote control comes with a **1-year replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures a replacement if the product fails due to such issues.
Returns are accepted for refund or exchange if the remote control does not function with your specified devices. Please initiate returns within **30 days** of purchase, adhering to the seller's return policy.

8. Support

If you have questions regarding the compatibility of this remote control with your Soniq TV model, or if your specific model number is not listed in this manual, please contact the seller for assistance. Providing your TV's full model number will help in confirming suitability and finding the correct remote if necessary.
For technical support or warranty claims, please refer to your purchase documentation for seller contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BR2NBZGN

More documents and user manuals: **https://manuals.plus/**