Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GRF2202SXE

Geepas GRF2202SXE Double Door Direct Cool Refrigerator User Manual

Model: GRF2202SXE

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Geepas GRF2202SXE Double Door Direct Cool Refrigerator. Please read these instructions thoroughly before using the appliance and retain them for future reference.

The Geepas GRF2202SXE is a 168-liter capacity double-door refrigerator designed for household use. It features a top-mounted freezer compartment and a bottom refrigerator compartment, offering efficient cooling and storage solutions.

2. Safety Information

Electrical Safety:

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use extension cords or ungrounded adapters.
- Always unplug the refrigerator before cleaning or performing any maintenance.
- Do not touch the power plug with wet hands.

Placement and Ventilation:

- Place the refrigerator on a firm, level surface to prevent vibration and noise.
- Allow adequate space around the appliance for proper ventilation (at least 10 cm at the back and sides).
- Avoid placing the refrigerator in direct sunlight or near heat sources.

General Safety:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- The refrigerator is equipped with a lock and key. Keep the key out of reach of children to prevent accidental entrapment.

3. Product Overview

The Geepas GRF2202SXE refrigerator features a silver finish and a compact design suitable for various living spaces. It includes a freezer compartment at the top and a larger fresh food compartment at the bottom.



Figure 1: Front view of the Geepas GRF2202SXE Refrigerator.

Key Features:

- Double Door Direct Cool Refrigerator
- Total Capacity: 168 Liters (128L Refrigerator, 40L Freezer)

- Silver Finish
- Digital Temperature Control
- Low Noise and Low Voltage Operation
- Toughened Glass Shelves
- Transparent Door Baskets
- Adjustable Front Wheel for easy movement
- External Gripped Handle
- Door Lock and Key included



Figure 2: Top freezer compartment with door open.



Figure 3: Bottom refrigerator compartment with door open.

4. Setup and Installation

Unpacking:

- Remove all packaging materials, including foam and adhesive tape.
- Inspect the refrigerator for any damage during transit. Report any damage to your retailer immediately.

Placement:

- Choose a location with a stable, level floor.
- Ensure there is at least 10 cm of clearance on the back and sides for adequate air circulation.
- Avoid direct sunlight, heat sources (stoves, radiators), and damp areas.

Leveling:

- Use the adjustable front wheel to level the refrigerator. A level appliance operates more efficiently and quietly.

Initial Cleaning:

- Before first use, clean the interior and exterior of the refrigerator with a soft cloth and mild detergent. Rinse and dry thoroughly.

Power Connection:

- After placement and cleaning, wait at least 2-4 hours before plugging the refrigerator into a power outlet. This allows the refrigerant to settle.
- Connect the refrigerator to a dedicated, grounded power outlet (AC 168-240V, 50/60Hz).

5. Operating Instructions

Temperature Control:

- The refrigerator features digital temperature control. Refer to the control panel inside the refrigerator for specific temperature adjustment instructions.
- Adjust the temperature according to the amount of food stored and ambient conditions.

Food Storage Guidelines:

- **Refrigerator Compartment (Bottom):** Ideal for fresh foods, dairy products, fruits, and vegetables. Utilize the toughened glass shelves and crisper drawers for organized storage.
- **Freezer Compartment (Top):** Suitable for long-term storage of frozen foods, ice cream, and making ice.
- Do not place hot food directly into the refrigerator; allow it to cool to room temperature first.
- Ensure food items are properly sealed to prevent odor transfer and maintain freshness.

Door Usage:

- Use the external gripped handle to open and close the doors.
- Avoid opening the doors frequently or for extended periods to maintain internal temperature and energy efficiency.
- The included lock and key can be used to secure the refrigerator doors.

6. Maintenance and Cleaning

Regular Cleaning:

- Always unplug the refrigerator before cleaning.
- Clean the interior with a solution of mild detergent and warm water. Wipe dry with a soft cloth.
- Clean the exterior with a soft, damp cloth. For the stainless steel door, use a specialized stainless steel cleaner if necessary.
- Regularly clean the door gaskets to ensure a tight seal.

Defrosting (Freezer Compartment):

- As a direct cool refrigerator, the freezer compartment will accumulate frost. When the frost layer becomes approximately 5mm thick, manual defrosting is required.
- To defrost, unplug the refrigerator, remove all food items, and leave the freezer door open. Place towels at the bottom to absorb melting ice.
- Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.
- After defrosting, clean and dry the interior thoroughly before plugging the refrigerator back in.

Extended Absence:

- If the refrigerator will not be used for an extended period, unplug it, empty all contents, defrost the freezer, clean the interior, and leave the doors slightly ajar to prevent odors and mold growth.

7. Troubleshooting

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate	No power; plug loose; circuit breaker tripped.	Check power supply; ensure plug is secure; reset circuit breaker.
Insufficient cooling	Temperature setting too high; door not closed properly; excessive door openings; warm food placed inside.	Adjust temperature setting; ensure door is sealed; reduce door openings; allow food to cool before storing.
Excessive noise	Refrigerator not level; objects vibrating against the unit; normal operating sounds.	Level the refrigerator using the adjustable front wheel; ensure no objects are touching the unit; some sounds (compressor, refrigerant flow) are normal.
Water on floor (defrost water)	Drain hole blocked; drip tray overflowing.	Clear the drain hole; ensure drip tray is correctly positioned and not full.

If the problem persists after checking these points, please contact qualified service personnel.

8. Specifications

Feature	Specification
Brand	Geepas

Feature	Specification
Model	GRF2202SXE
Type	Double Door, Direct Cool
Total Capacity	168 Liters (5.9 Cubic Feet)
Refrigerator Fresh Food Capacity	128 Liters
Freezer Capacity	40 Liters
Product Dimensions (D x W x H)	47.9 x 49.8 x 148.2 cm (474x498x1482 mm)
Item Weight	69.9 Kilograms
Voltage	AC 168-240V, 50/60Hz
Annual Energy Consumption	549 Watts
Installation Type	Freestanding
Defrost System	Manual (Freezer), Automatic (Refrigerator)
Special Features	Digital Temperature Control, Door Lock, Easy Cleaning, Low Noise, Low Voltage
Shelves	3 Toughened Glass Shelves
Crispers/Drawers	2
Door Hinges	Right
Door Material Type	Stainless Steel
Color	Silver
Included Components	User Manual & Warranty Card

9. Warranty and Support

This Geepas GRF2202SXE Refrigerator comes with a**2-year manufacturer's warranty** from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

For technical assistance, service requests, or warranty inquiries, please contact Geepas customer support through the contact information provided on your warranty card or the official Geepas website.

© 2023 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BR5NT4ZL

More documents and user manuals: **https://manuals.plus/**