Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FANGOR SS-JP-BR143BK

FANGOR Portable Blu-ray Player User Manual

Model: SS-JP-BR143BK

Introduction

Thank you for purchasing the FANGOR Portable Blu-ray Player. This device offers a high-definition 14.1-inch TFT LCD screen (1366x768 resolution) with a 270-degree rotatable display, providing a vivid and immersive viewing experience. Equipped with Dolby Surround, it delivers powerful, high-quality sound. Its versatile connectivity options, including HDMI output and AV input, allow for flexible usage with external displays or as a standalone monitor. The built-in rechargeable battery provides up to 3 hours of continuous playback, making it ideal for on-the-go entertainment. This player supports a wide range of disc and media formats, including Blu-ray, DVD, and CD, and is region-free for DVDs, allowing playback of international content. It also supports CPRM for recorded digital broadcasts.



Image: The FANGOR Portable Blu-ray Player with its remote control, showcasing the main unit with the screen open, displaying a Blu-ray Disc logo.

Setup

1. Unpacking and Initial Inspection

- Carefully remove all components from the packaging.
- Verify that all accessories are present: AV cable, USB cable, car charger, remote control (batteries not included), and Japanese instruction manual.
- Inspect the player for any visible damage. If any damage is found, do not use the device and contact customer support.

2. Charging the Battery

Before first use, fully charge the built-in battery. The player supports three power sources: AC adapter, DC car charger, and the internal rechargeable battery.

- **Using the AC Adapter:** Connect the AC adapter to the player's DC IN port and plug it into a standard wall outlet.
- **Using the Car Charger:** Connect the car charger to the player's DC IN port and plug it into your vehicle's cigarette lighter socket.

The charging indicator light will typically show the charging status and turn off or change color when fully charged. A full charge provides approximately 3 hours of continuous playback.



Image: Illustration of the three power options for the FANGOR Portable Blu-ray Player: household adapter, internal 4000mAh battery, and car cigarette lighter socket.

3. Inserting Discs and Media

Open the disc tray by gently pressing the OPEN button or sliding the latch. Place the disc (Blu-ray, DVD, or CD) onto the spindle with the label side facing up and gently press down until it clicks into place. Close the disc tray. For digital media, insert a USB drive into the USB port or an SD card into the SD card slot.



Image: The FANGOR Portable Blu-ray Player with its disc tray open, illustrating the insertion of a disc. Icons for supported media types like BD, DVD, various video/audio formats, and image formats are shown, along with USB and SD card slots.

Operating Instructions

1. Powering On/Off

- To power on, slide the power switch to the ON position.
- To power off, slide the power switch to the OFF position.

2. Basic Playback

- Once a disc is inserted or media is connected, the player will typically start playback automatically or display a menu.
- Use the **PLAY/PAUSE** button on the player or remote to start or pause playback.
- Use the **STOP** button to stop playback.
- Use the **PREV/NEXT** buttons to skip chapters or tracks.
- Adjust volume using the **VOL+/-** buttons.

3. Screen Rotation and Viewing Angles

The 14.1-inch LCD screen can rotate up to 270 degrees, allowing for various viewing angles and configurations, including folding flat like a tablet.



Image: The FANGOR Portable Blu-ray Player demonstrating its 270-degree screen rotation capability, showing the screen in various positions from fully open to folded flat.

4. Connecting to External Devices

The player features HDMI output and AV input ports for enhanced connectivity.

- **HDMI Output:** Connect an HDMI cable from the player's HDMI OUT port to an HDMI IN port on a TV, projector, or larger monitor to enjoy content on a bigger screen.
- **AV Input:** Use the provided AV cable to connect external devices (e.g., game consoles, older media players) to the

player's AV IN port, allowing the player's screen to function as a display for these devices.

- **Headphone Jack:** Plug in headphones for private listening, especially useful in quiet environments like hospitals or libraries.



Image: The FANGOR Portable Blu-ray Player illustrating its connectivity options, including AV input for connecting to another player and HDMI output for connecting to a large screen TV or projector.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the player's exterior. For the screen, use a screen-specific cleaning solution and a microfiber cloth. Avoid abrasive cleaners or solvents.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of scratches. Store them in their cases when not in use.
- **Storage:** When not in use for extended periods, store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing for a long time, charge the battery to about 50% every few months.

Troubleshooting

Problem	Possible Cause / Solution
Player does not power on.	◦ Ensure the power adapter is securely connected and plugged into a working outlet. ◦ Check if the battery is charged. ◦ Verify the power switch is in the ON position.
Disc does not play or skips.	◦ Clean the disc with a soft, lint-free cloth. ◦ Check if the disc is scratched or damaged. ◦ Ensure the disc is inserted correctly with the label side up. ◦ Verify the disc format is supported (BD-ROM, DVD-ROM, CD-ROM, etc.).
No sound.	◦ Increase the volume using the VOL+ button. ◦ Check if headphones are plugged in. If so, unplug them to use the built-in speakers. ◦ If connected to an external display via HDMI, ensure the TV/monitor volume is up and the correct input is selected.
Remote control not working.	◦ Ensure there are no obstructions between the remote and the player's IR sensor. ◦ Replace the batteries in the remote control (requires AAA batteries, not included).
Image quality is poor.	◦ Ensure the disc or media file is of good quality. ◦ Adjust screen brightness and contrast settings if available in the player's menu. ◦ If connected to an external display, check the display's settings and cable connection.

Specifications

Feature	Detail
Model Number	SS-JP-BR143BK
Screen Size	14.1 inches
Display Type	TFT LCD
Resolution	1366 x 768 pixels
Screen Rotation	270 degrees
Supported Disc Formats	BD-ROM, BD-R, BD-RE, DVD-ROM, DVD±R, DVD±RW, CD-R, CD-RW
Supported Media Types	MP4, MOV, MPG, VOB, 3GP, FLV, AVI, MKV, 1P, 1S, Dolby Digital, MP3, OGG, WMA, WAV, APE FLAC, JPG, JPEG, BMP (via USB/SD)
CPRM Support	Yes
Region Free (DVD)	Yes
Connectivity	HDMI Output, AV Input, USB Port, SD Card Slot, Headphone Jack
Power Sources	AC Adapter, DC Car Charger, Built-in Rechargeable Battery
Battery Life	Approx. 3 hours (continuous playback)
Weight	1.5 kg (3.3 lbs)
Dimensions (Package)	39.4 x 37.1 x 9.5 cm
Included Accessories	AV cable, USB cable, Car charger, Remote control (batteries not included), Japanese Instruction Manual

Warranty and Support

This FANGOR product comes with a one-year warranty from the date of purchase. If you encounter any issues or have questions regarding the product, please do not hesitate to contact FANGOR customer support. Please refer to the contact information provided in your product packaging or on the official FANGOR website for assistance.
For the latest support information, FAQs, and driver downloads (if applicable), please visit the official FANGOR website.

© 2023 FANGOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BR7XB8M5

More documents and user manuals: **https://manuals.plus/**