Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vestel X Maxi 4-Blade Chopper

Vestel X Maxi 4-Blade Chopper User Manual

Model: X Maxi 4-Blade Chopper | Brand: Vestel

1. Introduction

Thank you for choosing the Vestel X Maxi 4-Blade Chopper. This appliance is designed to simplify your food preparation tasks, offering efficient and quick chopping of various ingredients. Please read this manual carefully before using the appliance for the first time to ensure safe and optimal performance. Keep this manual for future reference.



Figure 1.1: Fully assembled Vestel X Maxi 4-Blade Chopper. This image shows the motor unit, lid, glass chopping bowl, and the internal blade assembly.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or other liquids. Clean only with a damp cloth.
- Always unplug the appliance from the power outlet before assembling, disassembling, or cleaning.
- Blades are sharp. Handle with extreme care. Always hold the blade assembly by the plastic shaft.
- This appliance is equipped with a safety lock mechanism. Ensure all parts are correctly assembled before operation. The appliance will not operate if not properly assembled.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Keep hands and utensils out of the chopping bowl while processing food to prevent the possibility of severe injury to persons or damage to the chopper.
- Do not use outdoors.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use attachments not recommended or sold by the manufacturer.

3. Product Components

Familiarize yourself with the parts of your Vestel X Maxi 4-Blade Chopper:

1. **Motor Unit:** Contains the motor and control button.
2. **Lid:** Secures the chopping bowl and motor unit.
3. **4-Blade Assembly:** Stainless steel blades for efficient chopping.
4. **Glass Chopping Bowl:** The container for ingredients, with measurement markings.



Figure 3.1: The empty glass chopping bowl, showing measurement markings and the central pin for the blade assembly.



Figure 3.2: The detachable 4-blade stainless steel assembly. Note the sharp edges and handle with care.

4. Setup and Assembly

Before first use, wash all parts that will come into contact with food (chopping bowl, lid, blade assembly) in warm soapy water, rinse thoroughly, and dry. The motor unit should only be wiped with a damp cloth.

1. Place the glass chopping bowl on a clean, stable, and dry surface.
2. Carefully place the 4-blade assembly onto the central pin inside the chopping bowl. Ensure it sits securely.
3. Add your ingredients to the chopping bowl. Do not exceed the maximum fill line indicated on the bowl.
4. Place the lid onto the chopping bowl, ensuring it is properly aligned and seated.
5. Position the motor unit on top of the lid. Align the motor unit with the lid's opening and twist slightly if necessary until it locks into place. The appliance will not operate unless the motor unit is correctly seated and the safety lock is engaged.
6. Plug the power cord into a suitable electrical outlet.

5. Operating Instructions

Once the chopper is assembled and plugged in, you are ready to begin chopping.

- Ensure the appliance is correctly assembled as per Section 4.
- Press and hold the button on top of the motor unit to activate the blades.
- For best results and to achieve desired consistency, use short pulses rather than continuous operation. This allows you to control the chopping size and prevents over-processing.
- Do not operate the chopper continuously for more than 30 seconds. Allow the motor to rest for at least 2 minutes between cycles to prevent overheating.
- If ingredients stick to the sides of the bowl, release the button, unplug the appliance, remove the motor unit and lid, and use a spatula to scrape down the sides. Reassemble before continuing.
- Once chopping is complete, release the button, unplug the appliance, and carefully remove the motor unit and lid.
- Carefully remove the blade assembly by holding its plastic shaft before emptying the chopped ingredients.



Figure 5.1: The chopper in use, demonstrating its ability to process ingredients like tomatoes.



Figure 5.2: The chopper effectively processing onions, showing the fine chopping capability.

6. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your chopper.

- Always unplug the appliance before cleaning.
- Disassemble all removable parts: motor unit, lid, blade assembly, and glass chopping bowl.
- **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not immerse it in water or any other liquid.
- **Glass Chopping Bowl, Lid, and Blade Assembly:** These parts are recommended for hand washing. Wash them in warm, soapy water. Rinse thoroughly and dry immediately.
- **Blades:** Exercise extreme caution when cleaning the blades as they are very sharp. Use a brush if necessary to remove food residue.
- Ensure all parts are completely dry before reassembling or storing the appliance.
- Store the chopper in a dry place, away from direct sunlight and heat.



Figure 6.1: A close-up view of the 4-blade assembly within the glass bowl, highlighting the need for careful cleaning.

7. Troubleshooting

If you encounter issues with your Vestel X Maxi 4-Blade Chopper, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in.	Ensure the power cord is securely plugged into a working electrical outlet.
	Motor unit not correctly assembled.	Ensure the motor unit is properly seated and locked onto the lid, and the lid is correctly placed on the bowl. The safety lock prevents operation if not assembled correctly.
Chopping is ineffective or uneven.	Too much food in the bowl.	Reduce the quantity of ingredients. Do not exceed the MAX fill line.
	Ingredients are too large or hard.	Cut ingredients into smaller, more uniform pieces before chopping.
Motor stops during operation or overheats.	Continuous operation for too long.	Allow the appliance to cool down for at least 10-15 minutes before resuming operation. Use pulse function for better control and to prevent overheating.

8. Specifications

- **Brand:** Vestel
- **Model:** X Maxi 4-Blade Chopper
- **Power:** 1200 Watt
- **Blade Material:** Stainless Steel
- **Special Feature:** Safety Lock
- **Chopping Bowl Capacity:** 1500 ml (approx. 50 oz)
- **Care Instructions:** Hand Wash (for bowl, lid, and blades)
- **First Available Date:** January 16, 2023

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Vestel website. If you require further assistance, please contact Vestel customer service.
For more information, you can visit the Vestel Store on Amazon.

© 2023 Vestel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BSFZ4GHV

More documents and user manuals: **https://manuals.plus/**