Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BT7441

Braun Series 7 BT7441 Professional Beard Trimmer User Manual

1. Introduction

This manual provides detailed instructions for the safe and effective use of your Braun Series 7 BT7441 Professional Beard Trimmer. Designed for precision and control, this device helps you achieve professional grooming results at home. It features the ProBlade for sharp cutting, AutoSense technology for consistent performance across different beard types, and a ProWheel precision dial with 40 length settings. The trimmer offers up to 100 minutes of cordless operation.

2. Package Contents

Please check the box for the following items:

- 1 Braun Series 7 Beard Trimmer with ProBlade Head
- 1 Precision Trimmer Head
- 1 Precision Comb for Beard (0.5 to 10 mm)
- 1 Precision Comb for Hair (10.5 to 20 mm)
- 1 Beard Comb
- 1 Gillette ProGlide Razor
- 1 Gillette ProGlide Refill
- 1 Charging Base
- 1 Beard Stencil
- 1 Cleaning Brush
- 1 Travel Case



Image 2.1: The Braun Series 7 BT7441 beard trimmer along with its complete set of accessories, including various combs, a Gillette razor, charging base, and travel case.

3. Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- This appliance is suitable for cleaning under running water.
- Do not use the appliance with a damaged foil or comb, as this may result in injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the power supply provided with the appliance.

4. Initial Setup

4.1 Charging the Trimmer

Before first use, fully charge the trimmer. Connect the charging base to a power outlet and place the trimmer on the base. The charging indicator light will show the charging status. A full charge provides up to 100 minutes of cordless trimming time.



Image 4.1: The Braun Series 7 BT7441 trimmer positioned on its charging base, indicating its 100-minute cordless operation capability.

5. Operating Instructions

5.1 Attaching Combs and Heads

Select the appropriate comb or precision head for your desired style. Align the comb with the trimmer head and press firmly until it clicks into place. To remove, gently pull the comb away from the head.

5.2 Adjusting Trimming Length

The ProWheel precision dial allows you to select from 40 length settings in precise 0.5 mm increments. Rotate the dial to your desired length. Ensure the comb is securely attached before adjusting the length.



Image 5.1: A detailed view of the PrecisionWheel dial on the Braun Series 7 BT7441, illustrating the 0.5 mm increment settings for precise length control.

5.3 Trimming Techniques

Turn on the trimmer. For best results, move the trimmer against the direction of hair growth. The ProBlade ensures precision with every pass, while AutoSense technology adapts to your beard type for a uniform cut.

- **For Beard Trimming:** Use the precision beard comb (0.5-10mm) and adjust the ProWheel to your desired length. Move the trimmer in smooth, even strokes.
- **For Hair Trimming:** Use the precision hair comb (10.5-20mm) for longer styles.

- **For Detailing and Edging:** Remove the comb and use the precision trimmer head for sharp lines and contours. The included beard stencil can assist in creating defined shapes.
- **For Fading:** Gradually adjust the length setting as you move up the beard or hairline to create a smooth transition.



Image 5.2: A user demonstrating the Braun Series 7 BT7441 trimmer in action, carefully shaping his beard.



Image 5.3: Visual examples of using the trimmer for fading and detailing, highlighting its versatility for different styling needs.



Image 5.4: A close-up view of the ProBlade on the Braun Series 7 BT7441, emphasizing its sharp metal construction for effective hair capture.

6. Cleaning and Care

The Braun Series 7 BT7441 trimmer is 100% waterproof, making cleaning simple and hygienic.

- After each use, turn off the trimmer and remove the comb.
- Rinse the trimmer head and combs under warm running water.
- Use the included cleaning brush to remove any stubborn hair particles from the blades.
- Allow all parts to air dry completely before reattaching or storing.
- Periodically, apply a drop of light machine oil (not included) to the trimmer blades for optimal performance and longevity.

7. Troubleshooting

If you encounter any issues with your Braun Series 7 BT7441 trimmer, please refer to the following common

solutions:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. If it still doesn't turn on, try charging it for a longer period.
- **Poor trimming performance:** Check if the blades are clean and free of hair. Ensure the comb attachment is correctly secured. The blades may require oiling.
- **Battery not holding charge:** Ensure the charging base and power adapter are correctly connected and functioning. If the issue persists, contact customer support.
- **ProWheel dial not staying in position:** Ensure the dial is clean and free from debris. If the issue persists, it may indicate a mechanical fault.

For further assistance, please contact Braun customer service.

8. Product Specifications

Feature	Specification
Brand	Braun
Model Number	4210201448396
ASIN	B0BT51WNHL
Power Source	Battery Powered (1 Lithium-ion, included)
Battery Life	Up to 100 minutes
Special Feature	Waterproof
Blade Material	Stainless Steel
Body Material	Alloy Steel
Color	Black
Product Dimensions (L x W x H)	16 x 7.4 x 28.2 cm
Item Weight	472 Grams
Recommended Use	Beard
Target Audience	Men
Manufacturer	Procter & Gamble
Country of Origin	China

9. Warranty and Support

Braun offers a warranty for this product. Please refer to the official Braun website for detailed warranty terms and conditions, as well as information on how to register your product and access customer support.



Image 9.1: A badge indicating the possibility of up to 5 years warranty, subject to terms and conditions available on Braun's official website.

For any questions, technical assistance, or warranty claims, please visitwww.braun.com or contact your local

Braun service center.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BT51WNHL

More documents and user manuals: **https://manuals.plus/**