Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs RC1208

Dpofirs RC1208 Replacement TV Remote Control User Manual for MEDION Smart TVs

1. Introduction

This manual provides comprehensive instructions for the Dpofirs RC1208 replacement remote control. It is designed to be a direct replacement for your original MEDION Smart TV remote, offering full functionality without the need for complex setup.





Image 1.1: Front view of the Dpofirs RC1208 remote control.

The RC1208 remote control is compatible with a wide range of MEDION Smart TV models, making it an ideal solution if your original remote is lost, damaged, or requires replacement. It ensures sensitive control and access to all essential functions.

2. Product Features

- **Premium ABS Material:** Constructed from high-quality ABS material, ensuring durability and resistance to wear.
- **Wide Compatibility:** Specifically designed for MEDION Smart TVs, compatible with models such as MD20255, MD20294, MD21080, MD21106, MD21161, MD21189, MD21166, MD21227, RC1208, RC1900, P15125, MD30297, and many others.
- **Direct Replacement:** Serves as an excellent replacement option for lost, damaged, or non-functional original remote controls.
- **Full Functionality:** Provides easy and complete access to all buttons and functions, mirroring the original remote's capabilities.
- **No Pairing Required:** Operates immediately upon battery insertion; no programming or complex pairing procedures are necessary.



Image 2.1: The RC1208 remote control highlighting its key features and compatibility with a television.

3. Package Contents

Upon opening your package, you should find the following item:

- 1 x Dpofirs RC1208 TV Remote Control

Note: AAA batteries are not included and must be purchased separately.

4. Setup

4.1 Battery Installation

To begin using your Dpofirs RC1208 remote control, you must first install the batteries.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image 4.1: View of the open battery compartment, showing where to insert AAA batteries.

Once batteries are installed, the remote control is ready for immediate use with your compatible MEDION Smart TV. No additional programming or pairing is required.

5. Operating Instructions

5.1 Basic Functions

The Dpofirs RC1208 remote control provides intuitive access to all standard television functions. Point the remote control directly at your MEDION Smart TV for optimal performance.

5.2 Button Overview

The remote features a standard layout for easy navigation and control:



Image 5.1: Close-up view of the remote control's buttons, showing their labels and layout.

- **Power Button (Red Circle):** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (+/-):** Adjusts the sound volume.
- **Channel Up/Down (P+/-):** Changes TV channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu:** Accesses the TV's main menu.
- **Exit:** Exits current menu or function.
- **Source:** Selects input sources (HDMI, AV, etc.).
- **Media Controls (Play, Pause, Stop, Rewind, Fast Forward):** For controlling media playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within smart TV applications or teletext.
- **Info:** Displays information about the current program or input.
- **EPG:** Accesses the Electronic Program Guide.

6. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Care:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Replace batteries when the remote's responsiveness decreases.
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** While made from durable ABS material, repeated drops can cause internal damage. Handle with care.

7. Troubleshooting

If you encounter issues with your Dpofirs RC1208 remote control, try the following solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote has short range or intermittent response.	Weak batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's infrared sensor. Remove any obstructions.
Certain buttons do not respond.	Button malfunction or dirt under the button.	Clean the remote control. If the issue persists, the remote may be faulty and require replacement.
Remote does not control the TV.	Incompatible TV model.	Verify that your MEDION TV model is listed in the compatible models section of this manual.

8. Specifications

Feature	Detail
Brand	Dpofirs
Model Name	RC1208
Color	Black
Connectivity Technology	Infrared
Special Feature	Ergonomic design

Feature	Detail
Compatible Devices	MEDION Smart TVs (MD20255, MD20294, MD21080, MD21106, MD21131, MD31067, RC1222, MD30737, MD21161, MD21189, MD21166, MD21227, RC1208, RC1900, P15125, MD30297, etc.)
Maximum Range	10 Meters
Battery Type	2 x AAA (not included)
Material	ABS

9. Warranty and Support

Specific warranty information for this product is not provided in the available details. For any support inquiries or further assistance, please refer to the seller or retailer from whom the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTB1CCBP

More documents and user manuals: **https://manuals.plus/**