Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SIMPLI-MAGIC 79513

SIMPLI-MAGIC 60 Liter / 16 Gallon Dual Compartment Recycling Kitchen Step Trash Can

Model: 79513

Introduction

This manual provides essential instructions for the safe and efficient use of your SIMPLI-MAGIC 60 Liter / 16 Gallon Dual Compartment Recycling Kitchen Step Trash Can. Please read this manual thoroughly before initial use and retain it for future reference.

Safety Instructions

- Ensure the trash can is placed on a stable, level surface to prevent tipping.
- Do not overload the compartments.
- Keep hands and fingers clear of the lid mechanism when closing to prevent pinching.
- This product is intended for indoor household use only.
- Do not allow children to play with or around the trash can.
- Avoid using abrasive cleaners or scouring pads on the stainless steel finish.

Package Contents

Verify that all components are present:

- 1 x SIMPLI-MAGIC 60 Liter Dual Compartment Trash Can (Stainless Steel exterior)
- 2 x Inner Liner Buckets (1 Green, 1 Black)
- 1 x Odor Filter (pre-installed or separate)







Image: The SIMPLI-MAGIC 60 Liter Dual Compartment Trash Can with its lids open, revealing the two inner liner buckets, one green and one black, designed for waste and recycling separation.

Setup

1. **Unpacking:** Carefully remove the trash can from its packaging. Retain packaging for future transport if needed.
2. **Placement:** Position the trash can on a flat, stable surface in your desired location. Ensure there is adequate space for the lid to open fully and for the foot pedals to be operated comfortably.
3. **Insert Liners:** Place the green inner liner bucket into one compartment and the black inner liner bucket into the other. These are designed for easy identification of recycling and general waste.
4. **Install Trash Bags:** Drape standard 30-liter (8-gallon) trash bags over the rim of each inner liner bucket. Utilize the bag cinch feature (if present) or the hole near the top of each liner to secure the bag and prevent it from slipping.
5. **Odor Filter:** If not pre-installed, insert the odor filter into the designated slot on the underside of the lid. Replace the filter periodically for optimal odor control.



Image: A diagram illustrating the dimensions of the SIMPLI-MAGIC 60 Liter Dual Compartment Trash Can, including its overall height, width, and depth, as well as the height of the removable inner bins.

Operating Instructions

1. **Opening the Lid (Hands-Free):** Gently press down on the corresponding foot pedal located at the base of the trash can. The lid will open smoothly.
2. **Soft-Close Lid:** Release the foot pedal, and the lid will close slowly and quietly, reducing noise and preventing abrupt slamming.
3. **Lid Lock Feature:** For extended tasks, such as emptying contents or cleaning, press the foot pedal fully and then push the lid backward until it locks into an open position. To close, gently push the lid forward until it disengages from the lock and closes softly.
4. **Sorting Waste:** Use the green compartment for recycling and the black compartment for general waste, or assign them according to your local waste management guidelines.



Image: A close-up view of the two independent foot pedals at the base of the SIMPLI-MAGIC Dual Compartment Trash Can, highlighting the hands-free operation for each compartment.

Maintenance

- **Cleaning the Exterior:** Wipe the stainless steel exterior with a soft, damp cloth and a mild cleaner. Dry immediately with a clean, soft cloth to prevent water spots. The finish is designed to resist fingerprints and smudges.
- **Cleaning Inner Liners:** Remove the inner liner buckets and wash them with warm, soapy water. Rinse thoroughly and dry completely before returning them to the trash can.
- **Odor Filter Replacement:** The built-in odor filter helps control smells. Replace the filter every 3-6 months, or as needed, depending on usage. Replacement filters can be purchased from authorized SIMPLI-MAGIC retailers.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or steel wool, as these can damage the finish and internal mechanisms.



Image: The SIMPLI-MAGIC Dual Compartment Trash Can positioned in a contemporary kitchen, illustrating its sleek design and the benefit of its easy-to-maintain, fingerprint-resistant stainless steel finish.

Troubleshooting

Problem	Possible Cause	Solution
Lid does not close softly.	Mechanism obstruction or damage.	Check for any debris obstructing the lid's path. Ensure the lid is not forced open beyond its intended range. If the issue persists, contact customer support.
Lid does not open when pedal is pressed.	Pedal mechanism obstruction or damage.	Inspect the pedal and internal linkage for any obstructions. Ensure the inner liner is correctly seated and not interfering with the mechanism.
Unpleasant odors persist.	Full liners, soiled liners, or expired odor filter.	Empty and clean inner liners regularly. Replace the odor filter as recommended. Ensure trash bags are properly sealed.
Trash bag slips into the bin.	Incorrect bag size or improper installation.	Use standard 30-liter (8-gallon) trash bags. Ensure the bag is properly secured using the bag cinch feature or by tucking it securely around the liner's rim.

Specifications

Brand: SIMPLI-MAGIC

Model: 79513

Capacity: 60 Liters (16 Gallons) total (2 x 30 Liter compartments)

Dimensions (L x W x H): 19" x 12" x 26"

Material: Brushed Stainless Steel

Opening Mechanism: Hands-Free Foot Pedal

Special Features: Soft-Close Lid, Lid Lock, Odor Control Filter, Fingerprint-Resistant Finish

Item Weight: 26.9 pounds

UPC: 737857795130

Warranty and Support

This SIMPLI-MAGIC product comes with a**Limited Warranty**. For detailed warranty information, product support, or to purchase replacement parts (such as odor filters), please visit the official SIMPLI-MAGIC website or contact their customer service department.
For further assistance, please refer to the contact information provided on the SIMPLI-MAGIC official website or your purchase documentation.

Visit the SIMPLI-MAGIC Store

© 2023 SIMPLI-MAGIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTMY6JR7

More documents and user manuals: **https://manuals.plus/**