Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blütezeit ME-GO-RM-WB1

Blütezeit Wall-Mount Switch Wireless for Automatic Sliding Gate Opener

Model: ME-GO-RM-WB1

Brand: Blütezeit

Product Overview

The Blütezeit wireless push button controller is designed for versatile applications, primarily for essential access control at various locations. It features four buttons for easy operation: open, stop, and close functions for your gate. This device offers convenient control for your gate opener, simplifying access for users.

This wall remote switch is compatible with all Blütezeit openers that utilize a 433MHz mutual-duplicating type frequency. It functions by copying codes from existing original remotes. The switch can be installed at entrances, exits, or both sides of your gate for optimal control, with an effective working range of 65 feet (20 meters).

The wall remote control operates on a 23A 12V battery, eliminating the need for wire connections. Installation is flexible, allowing for wall mounting with screws or simple attachment using 3M high-strength double-sided foam tape. Its portable nature allows placement in various convenient locations such as bedrooms, living rooms, or patios.

This product is widely applicable in household, courtyard, warehouse, school, office building, and other commercial environments. It employs wireless signal transmission with a robust core, making it ideal for controlling gates, doors, and exits. It's highly recommended for use with your gate opener to provide a convenient method for opening and closing the gate with a simple press.

Important Note: This wall switch is constructed from high-quality ABS material with a powerful main board and classic rubber buttons for comfortable tactile feedback. However, it is **NOT waterproof**. For long-lasting performance, ensure the push button remote control is placed in a waterproof environment or protected with a waterproof casing.

Package Contents

- 1 x Blütezeit Wall Remote Control (Model: ME-GO-RM-WB1)
- 1 x Installation Kits (screws, 3M double-sided foam tape)
- 1 x 23A 12V Battery (pre-installed or included)

Setup and Installation

1. Powering the Device

The Blütezeit Wall-Mount Switch is battery-powered, requiring a 23A 12V battery. Ensure the battery is correctly inserted according to the polarity markings inside the battery compartment. No external wiring is needed for operation.



Image: The Blütezeit Wall-Mount Switch highlighting its wireless nature and battery power source (23A 12V battery shown).

2. Mounting Options

You have two primary options for mounting the wall switch:

1. **Screw Mounting:** Use the provided screws to securely attach the switch to a wall or desired surface. Ensure the surface is suitable for drilling.
2. **Adhesive Mounting:** For a less permanent solution, use the included 3M high-strength double-sided foam tape to fix the switch to a clean, dry, and smooth surface.

Image: Illustration of the two installation methods: using screws for permanent mounting or 3M double-sided foam tape for flexible placement.

3. Pairing with Your Gate Opener Remote

This wall switch is designed to duplicate the signal from an existing 433MHz mutual-duplicating remote control for your Blütezeit gate opener. It does not pair directly with the gate opener unit itself, but rather learns from your existing remote.

1. **Initiate Pairing Mode:** On the wall remote, press and hold the UP (▲) and DOWN (▼) buttons simultaneously for 3 seconds. The red signal light will flash quickly, indicating that the pairing process has started. Release your fingers.
2. **Pairing Individual Buttons:**
    - Press and hold the UP (▲) key on the wall remote. The red signal light will flash once.
    - While still holding the UP (▲) key on the wall remote, press the corresponding UP (▲) key on your original remote control. Continue holding both until the red signal light on the wall remote flashes continuously. This indicates successful pairing for that button.
    - Repeat the above steps for the STOP (■) and DOWN (▼) keys in turn, pairing each button individually until all desired keys on the wall remote are successfully paired.

3. **Verify Pairing:** After pairing, press each key on the wall remote one by one to check if the red signal lights illuminate, confirming they are working.

Your browser does not support the video tag.

Video: This video demonstrates the pairing process for the Blütezeit Wall Remote Control B, showing how to duplicate signals from an existing remote control. It illustrates holding buttons to enter pairing mode and then pressing corresponding buttons on both remotes to complete the pairing for each function (open, stop, close).

Operating Instructions

The Blütezeit Wall-Mount Switch provides intuitive control over your compatible gate opener. It features four distinct buttons for comprehensive operation:

- **UP (▲) Button:** Activates the gate to open.
- **STOP (■) Button:** Halts the gate's movement at any point.
- **DOWN (▼) Button:** Activates the gate to close.
- **Small Dot Button (•):** This button typically functions as a lock/unlock or a secondary control depending on the original remote's programming. Refer to your original remote's manual for its specific function.

Simply press the desired button to control your gate. The working range is approximately 65 feet (20 meters), allowing for convenient operation from various points within your property.



Image: The Blütezeit Wall-Mount Switch demonstrating its ease of use for controlling a gate opener with simple open, stop, and close functions.



Image: A detailed diagram illustrating the functions of each button on the Blütezeit Wall-Mount Switch: Signal Light, Move Left (Up), Stop, Lock/Unlock (Small Dot), and Move Right (Down).



Image: Examples of ideal placement for the wireless wall-mount remote control transmitter, including beside windows in a room, near the gate in a yard, and beside the door in a hall, demonstrating its versatility.

Maintenance

- **Battery Replacement:** When the signal light becomes dim or the remote's range decreases, it's time to replace the 23A 12V battery. Carefully open the back cover, replace the battery, and reassemble.
- **Cleaning:** Wipe the surface of the switch with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the ABS material.
- **Environmental Protection:** As the device is not waterproof, ensure it is installed in a dry location, protected from rain, splashes, and high humidity. Consider adding a waterproof enclosure if outdoor installation is necessary.

Specifications

Feature	Detail
Manufacturer	Blütezeit
Item Weight	1.83 ounces
Product Dimensions	3.35 x 3.35 x 0.48 inches
Country of Origin	China
Item Model Number	ME-GO-RM-WB1
Style	WB 1pc
Color	White & Blue
Material	ABS
Power Source	Battery-Powered (12V 23A)
Mounting Type	Protruding (Wall-Mount)

Compatibility	433MHz Mutual-Duplicating Blütezeit Openers
Working Range	65ft / 20m

Troubleshooting

If you encounter issues with your Blütezeit Wall-Mount Switch, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check the battery: Ensure the 23A 12V battery is correctly inserted and has sufficient charge. Replace if necessary.
  - Re-pair the remote: Follow the "Pairing with Your Gate Opener Remote" steps to re-establish the connection with your original remote.
  - Ensure line of sight: While wireless, obstructions can sometimes interfere with the signal. Try operating the switch closer to the gate opener's receiver or your original remote.
- **Limited Range:**
  - Replace the battery: A weak battery can significantly reduce the operating range.
  - Check for interference: Large metal objects, thick walls, or other wireless devices operating on similar frequencies can cause interference.
- **Signal Light Not Flashing:**
  - Verify battery: Confirm the battery is installed correctly and is not depleted.
  - Check for damage: Inspect the switch for any visible physical damage.

If these steps do not resolve the issue, please contact Blütezeit customer support for further assistance.

Warranty and Support

Blütezeit products undergo strict quality checks to ensure durability and performance. For specific warranty information, please refer to the documentation included with your purchase or contact Blütezeit customer service directly.
For technical support, troubleshooting assistance, or any inquiries regarding your Blütezeit Wall-Mount Switch, please reach out to Blütezeit US customer service. They are dedicated to providing reliable assistance for seamless installation and operation.
You can also visit the official Blütezeit Store on Amazon for additional product information and support resources:Blütezeit Amazon Store

© 2023 Blütezeit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTTBGT95

More documents and user manuals: **https://manuals.plus/**