Manuals+
Q & A | Deep Search | Upload

DEZIN 1903

DEZIN Electric Hot Pot with Steamer

Model: 1903 | Brand: DEZIN

1. Introduction

This manual provides essential information for the safe and efficient operation of your DEZIN Electric Hot Pot with Steamer. Please read all instructions carefully before first use and retain this manual for future reference.
The DEZIN Electric Hot Pot is a versatile 2-liter appliance designed for various cooking tasks, including boiling, frying, and steaming. Its compact and portable design makes it ideal for use in diverse environments such as dorm rooms, offices, RVs, and during travel.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is not dishwasher safe. Refer to the cleaning section for proper maintenance.

3. Product Overview

The DEZIN Electric Hot Pot is designed for convenience and versatility. It features a non-stick ceramic coating for easy cooking and cleaning, an ergonomic handle with integrated controls, and a removable steamer for healthy meal preparation.

Figure 3.1: Key Components of the DEZIN Electric Hot Pot

Figure 3.2: Dimensions of the DEZIN Electric Hot Pot

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Clean:** Before first use, wash the interior of the pot, the steamer, and the lid with warm, soapy water. Rinse thoroughly and dry completely. Do not immerse the main body of the pot (with electrical components) in water.
3. **Connect Power:** Insert the power cord securely into the port located at the end of the handle. Ensure the connection is firm.
4. **Placement:** Place the electric hot pot on a stable, heat-resistant, and dry surface away from flammable materials.

Your browser does not support the video tag.

Video 4.1: Overview of the DEZIN Electric Hot Pot and Power Connection

5. Operating Instructions

The DEZIN Electric Hot Pot offers dual power settings for various cooking needs. The control knob is located on the handle.

Figure 5.1: Dual Power Settings and Recommended Uses

5.1 Power Adjustment

- **OFF:** The appliance is turned off.
- **Mode I (400W):** Use this lower power setting for gentle cooking, simmering, or keeping food warm. Ideal for ramen, dumplings, oatmeal, and vegetables.
- **Mode II (800W):** Use this higher power setting for rapid boiling, frying, or searing. Perfect for steak, paella, fondue, and quick cooking.

5.2 Cooking Modes

- **Boiling/Simmering:** Add desired ingredients and liquid to the pot. Select Mode I or Mode II depending on the desired heat level. Cover with the lid for faster heating.
- **Frying/Searing:** Add a small amount of cooking oil to the pot. Select Mode II for high heat. Once hot, add ingredients and cook as desired.
- **Steaming:** Add water to the main pot (ensure water level is below the steamer basket). Place the removable steamer basket into the pot. Arrange food in the steamer basket. Cover with the lid. Select Mode II for steaming.

Figure 5.2: Example of cooking a seafood dish in the hot pot.

Your browser does not support the video tag.

Video 5.1: Demonstration of the DEZIN Electric Hot Pot and Steamer in use.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your DEZIN Electric Hot Pot.

Figure 6.1: Easy cleaning of the non-stick surface.

1. **Disconnect Power:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Wash Interior:** The non-stick ceramic coating makes cleaning easy. Use a soft sponge or cloth with warm, soapy water to clean the interior of the pot and the steamer basket.
3. **Wipe Exterior:** Wipe the exterior of the pot and handle with a damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the surface.
4. **Do NOT Immerse:** Never immerse the main body of the electric hot pot (with electrical components) in water or any other liquid.
5. **Dry Thoroughly:** Ensure all parts are completely dry before storing or next use.
6. **Storage:** Store the appliance in a dry place, away from direct sunlight and moisture.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in correctly; Power outlet malfunction; Appliance malfunction.	Ensure power cord is securely connected and plugged into a working outlet. Test outlet with another appliance. If problem persists, contact customer support.
Food not cooking evenly	Incorrect power setting; Overcrowding the pot.	Adjust to a higher power setting (Mode II) if needed. Avoid overcrowding; cook in smaller batches. Stir food periodically.
Food sticking to the pot	Insufficient oil; High heat for too long; Damaged non-stick coating.	Ensure adequate oil is used for frying. Adjust heat setting. Avoid using metal utensils that can scratch the coating.
Steam not generating effectively	Insufficient water; Lid not sealed properly.	Add more water to the main pot. Ensure the lid is placed firmly on top of the steamer basket.

8. Specifications

Feature	Detail
Brand	DEZIN
Model Number	1903
Capacity	2 Liters
Material	Non-Stick Ceramic Glaze Coating
Wattage	800 watts (Dual Power: 400W/800W)
Control Method	Touch (Dial)
Operation Mode	Automatic
Dishwasher Safe	No
Item Weight	4.62 pounds
Package Dimensions	17.6 x 10.79 x 6.81 inches

9. Warranty and Support

For warranty information, technical support, or any inquiries regarding your DEZIN Electric Hot Pot, please refer to the contact details provided with your product packaging or visit the official DEZIN website. Keep your purchase receipt as proof of purchase for warranty claims.