Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alfine A66

Alfine A66 4D Full Body Massage Chair Instruction Manual

Model: A66
Brand: Alfine

Important Safety Information

- Always follow the assembly instructions carefully.
- Do not exceed the maximum weight recommendation of 300 pounds.
- Keep the chair dry to prevent damage or safety hazards.
- Maintain proper posture in order to ensure accuracy and safety during use.
- Safety sensors do not guarantee any accident prevention.
- Ensure all children and pets maintain a safe distance from the chair during operation.
- If you feel pain or discomfort during use, reduce the intensity according to instructions in this manual. If the pain persists, discontinue use immediately.
- Always start at a low intensity and work your way up.
- Elderly users and those with chronic bone or muscle pain should take extra care during use.
- Remove all hard objects that may come into contact with the chair, including watches, jewelry, and hair accessories. Failure to do so may result in injury.
- Please wait until the chair has come fully upright before attempting to exit the chair.

1. Setup and Assembly

This section guides you through the initial setup and assembly of your Alfine A66 Massage Chair.

1.1. Required Tools

For assembly, you will need the following tools:

- Short Phillips Head Screwdriver
- Long Phillips Head Screwdriver
- Electric Screwdriver
- Needle-Nose Pliers

1.2. Packaging and Parts Overview

Your massage chair comes in three main boxes: Main Unit Box, Side Panel Box, and Footrest Assembly Box. Please verify all parts are present before beginning assembly.



Image: Packaging Diagram showing the three boxes: Main Unit Box, Side Panel Box, and Footrest Assembly Box.

The main unit includes the following components:

- Main Unit
- Side Panel Rear Cover Assembly
- Head Cover Assembly
- Accessory Box
- Footrest Assembly
- Left Side Panel
- Right Side Panel



Image: Parts Diagram illustrating the main unit and all its components before assembly.

The Accessory Box contains:

- Hand Controller Mount
- Touch Screen Mount
- Instruction Manual
- Power Cord
- Screw Package

1.3. Assembly Steps

1. **Massage Chair Reset:** Reset the massage chair to its initial position.

   ▶ **Watch video online**
   ALFINE A696 massage chair installation video

   Video: ALFINE A696 massage chair installation video. This video demonstrates the initial reset and subsequent assembly steps.

2. **Remove Back Cover:** Use an electric drill with a long Phillips head to remove the screws fixing the back cover.

Gently pull out the back cover with steady force.

3. **Detach Air Pipes and Wires:** Detach the left air pipe and unbind the tie securing the connector wire. Remove the air hose connector (it's redundant and protects the spring inside the air hose before assembly). Detach the right air pipe and its connector wire tie, then remove the air pipe connector.
4. **Prepare Side Panel Foam:** Install the right-side panel foam pad next to the main unit.
5. **Install Right Side Panel:** Follow the image instructions to securely insert the connection wire and air pipe. Hang the right-side panel hook onto the main frame. Align Slot one and Slot two simultaneously, then firmly press the side panel into place.
6. **Install Left Side Panel:** Repeat the process for the left side panel. Follow the image instructions to securely insert the connection wire and air pipe. Hang the left-side panel hook onto the main frame. Align Slot one and Slot two simultaneously, then firmly press the side panel into place.
7. **Secure Side Panels:** Secure the screws for both the right and left side panels using an electric screwdriver with an Allen key bit.
8. **Install Side Panel Cover Fabric:** Install the cover fabric for both the right and left side panels.
9. **Install Hand Controller and Touch Screen Brackets:** Install the hand controller bracket and the touch screen bracket.
10. **Install Hand Controller Assembly:** Connect the hand controller assembly.
11. **Install Small Rear Component:** Install the small rear component for the side panel using an electric screwdriver with a short Phillips head (four screws on each side).
12. **Install Head Cover Assembly:** Install the head cover assembly. Ensure the head cover pins are aligned and the speaker connections are made.
13. **Fix Head Cover Screws:** Screw fixation for the head cover.
14. **Install Lower Back Cover:** Snap the male and female fasteners together from bottom to top (press the back cover inward).
15. **Fix Back Cover Screws:** Turn off the massage chair to facilitate the installation of the back cover screws. Fix the upper and lower back cover screws.
16. **Remove DK Cover:** Remove the DK cover.
17. **Install Footrest:** Install the footrest. Connect the leg's air tube and wiring (ensure a firm connection).
18. **Install Locking Pins:** Install the left and right locking pins on the leg.
19. **Snap DK Cover Lock:** Snap the DK cover lock into place.
20. **Install Cover and Leg Connection Zipper:** Install the cover and leg connection zipper.

2. Operating Instructions

Learn how to operate your Alfine A66 Massage Chair using the touchscreen controller.

2.1. Starting a Massage

1. Plug in the power plug and press the power switch. The power indicator will light up.
2. Press the power button at the top of the touchpad. The screen lights up, and the massage chair starts initializing the chair body angle.
3. Please read the cautions during starting massage chair.

4. After power on, the massage chair will start auto program Master Mode. Wait for the body scanning process.
5. When the shoulder height confirmation appears on the screen, you can press OK to confirm the shoulder height position, or press the arrow to adjust the shoulder height up and down.

▶ **Watch video online**
ALFINE A696 massage chair VIDEO MANUAL

Video: ALFINE A696 massage chair VIDEO MANUAL. This video provides a comprehensive guide to operating the massage chair, including starting a massage and adjusting settings.

2.2. Auto Modes

The chair offers various auto modes for different massage experiences.

- **Focused:** Master Mode, Neck Focus, Waist & Buttocks, Spine Focus.
- **Body Section:** Neck & Shoulder, Upper Body, Spine, Lower Body, Leg, Whole Body.
- **Theme:** Morning, Restore, Unwind, Sleep, Stretch, Sports Massage.
- **Sonic Wave:** Upper Body Sonic Care, Spine Sonic Care, Lower Body Sonic Care, Whole Body Sonic Care, Stretching Sonic Care, Intensive Sonic Care.
- **Music Sync:** Bijarim, Shinrin-yoku, Nature Bliss, Romance, Land of Bliss, Bluetooth. In Bluetooth mode, you can connect the massage chair's Bluetooth with your cellphone's Bluetooth, then play music. Sonic wave vibration will work along with music.

2.3. Adjusting Settings in Auto Mode

- **4D Intensity:** 12 levels (default 3, minimum 1).
- **Back Sonic Level:** 6 levels (default 3, minimum 0). 0 means back sonic wave function stops.
- **Foot Sonic Level:** 6 levels (default 3, minimum 0). 0 means foot sonic wave function stops.
- **Legrest/Backrest Adjustment:** Continuously press the legrest/backrest up or down button to adjust the angle. Release the button to stop adjustment.
- **Footrest Extension/Shrink:** Continuously press the footrest extension or shrink button to adjust the length of the legrest. Release the button to stop adjustment.
- **Air Strength:** 6 levels (default 3, minimum 0). 0 means airbag stops.
- **Calf Roller:** 3 levels (default 0). 0 means calf roller stops.
- **Foot Roller:** 3 levels (default 0). 0 means foot roller stops.
- **Heating Control:** Press once for heating on (button lights up), press again for heating off (button light off). Default is off.
- **Massage Time:** Adjustable from 5 to 30 minutes. Maximum is 30 minutes. Pressing the button again after 30 minutes returns to 5 minutes.
- **Zero Gravity:** 3 levels of Zero Gravity.

2.4. Manual Modes

In manual modes, you can customize individual massage techniques.

- **Kneading:** 4 massage modes. Kneading can work together with tapping and clapping.
- **Tapping:** 2 massage modes.
- **Acupressure:** 1 massage mode. Acupressure can work together with clapping.
- **Clapping:** 2 massage modes.
- **Massage Coverage:** Full, Partial, Point. Point means focus on massaging the same position.
- **Massage Width:** Wide, Middle, Narrow. Please note during Kneading, you cannot adjust massage width.
- **4D Intensity:** 9 levels (default 3, minimum 1).

- **Massage Speed:** 7 levels (minimum 1).
- **Calf Roller:** 3 levels (default 0). 0 means calf roller stops.
- **Foot Roller:** 3 levels (default 0). 0 means foot roller stops.
- **Massage Position Control:** Continuously press the legrest up or down button to adjust the angle of the legrest. Release the button to stop adjustment.
- **Heating Control:** Press once for heating on (button lights up), press again for heating off (button light off). Default is off.

2.5. Air Massage Mode

Customize your air massage experience.

- **Airbag Position Selection:** Shoulder position, Armrest position, Leg and Foot position.
- **Air Strength:** Adjustable from 0 to 6. 0 means airbag massage stops.
- **Calf Roller:** 3 levels (default 0). 0 means calf roller stops.
- **Foot Roller:** 3 levels (default 0). 0 means foot roller stops.
- **Zero Gravity:** 3 levels of Zero Gravity.
- **Heating Control:** Press once for heating on (button lights up), press again for heating off (button light off). Default is off.

2.6. External Device Control

The External Device menu offers Bluetooth and Voice Control options.

- **Bluetooth:** The first time you use the massage chair, the default is ON. If you chose ON or OFF, next time you use the massage chair, the Bluetooth status will keep the same as you chose before. Bluetooth connection will turn OFF if massage mode has Sonic Wave. During massage pause, after pressing the pause button, you can connect Bluetooth. Both Back Sonic Level and Foot Sonic Level reduced to zero also can connect Bluetooth.
- **Voice Control:** The first time you use the massage chair, the default is OFF. If you chose ON or OFF, next time you use the massage chair, the Voice Control status will keep the same as you chose before. If you pull out the power plug and restart the chair, the voice control is OFF.

2.7. Memory Function

The Memory function allows you to save and recall your preferred massage programs.

- The upper line has four storage slots (Save I, Save II, Save III, Save IV). This function is for saving the currently running massage program, including automatic program, massage technique, air mode and intensity, position and angle of leg unit and backrest unit, and other massage functions.
- The down line has four recall slots (Use I, Use II, Use III, Use IV). This function is for calling the previously saved massage program.
- Please note: The calf roller and foot roller will follow the auto program original setting, so they cannot be memorized.

2.8. Customization

Create and save up to three custom massage programs.

- Click Customize 1, Customize 2, or Customize 3 to enter the Custom Setting interface.
- Then select the preferred massage technique (its icon will be highlighted after selection) and select the massage interval, 4D intensity, air massage, massage width, massage speed, air intensity, back heating, calf kneading, and other functions.
- Then click Save to save the current settings as Customized 1, Customized 2, or Customized 3.
- After the settings are saved successfully, the custom program will be immediately available and can be used for

the next massage by clicking the saved custom program.
- Please note: A custom program can only be selected if the massage content has been customized and saved before.

2.9. General Settings

Adjust various general settings for your massage chair.

- **4D Intensity:** 12 levels.
- **Massage Speed:** 7 levels.
- **Air Pressure:** 6 levels (OFF to 6). OFF means to stop airbag working.
- **Screen Off Time:** 1 min, 3 min, 5 min, 10 min, Never.
- **Heating Position Selection:** Waist and Calf can be controlled separately (ON/OFF).
- **Language:** Can be switched between Chinese, English, Korean.
- **Speaker Volume:** 6 levels (OFF to 6). OFF means turn off speaker.
- **Button Sound Volume:** 6 levels (OFF to 6). OFF means buttons be silent during clicking.
- **Screen Brightness:** 5 levels.
- **Ambient Light:** 8 colors (White, Yellow, Orange, Green, Blue, Purple, Red, Mixed Color). The first button is to close light on armrest.
- **Reset:** Press the RESET button. All adjust settings will return to original default level.
- **Pause:** Press the PAUSE button. Massage will pause, and during pause can connect device Bluetooth with massage chair.

3. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store in a dry environment to prevent damage.
- **Regular Checks:** Periodically check all connections and fasteners to ensure they are secure.

4. Troubleshooting

If you encounter any issues with your massage chair, please refer to the following common troubleshooting steps:

- **Chair Not Powering On:**
  - Ensure the power cord is securely plugged into both the chair and a working electrical outlet.
  - Check if the main power switch on the chair is in the "ON" position.
  - Verify the power outlet is functional by plugging in another device.
- **Massage Rollers Not Moving:**
  - Ensure the chair is not in a paused state. Press the "Pause" button to resume.
  - Check if a massage program is selected and active.

- If the chair recently performed a body scan, ensure it completed successfully and the shoulder position was confirmed.

- **Airbags Not Inflating/Deflating:**
  - Check the "Air Strength" setting in the operating menu; ensure it is not set to "0" (OFF).
  - Verify that all air pipe connections made during assembly are secure.
- **Heating Function Not Working:**
  - Ensure the heating function is turned "ON" in the settings or operating menu.
  - Check if the specific heating zones (Waist, Calf) are activated.
- **Bluetooth Connection Issues:**
  - Ensure Bluetooth is enabled on both your device and the massage chair (under External Device settings).
  - If the massage mode has Sonic Wave, Bluetooth connection will be OFF. Pause the massage to connect.
  - Ensure Back Sonic Level and Foot Sonic Level are reduced to zero to allow Bluetooth connection in certain modes.
- **Voice Control Not Responding:**
  - Verify that Voice Control is turned "ON" in the External Device settings.
  - If the chair was restarted after a power plug removal, Voice Control might default to OFF.

If the problem persists after attempting these steps, please contact customer support.

5. Specifications

Feature	Detail
Brand	Alfine
Model Name	A66
Model Number	SL-A710
Color	A66 Black
Material	Faux Leather, Foam (Fill Material)
Product Dimensions (D x W x H)	59.06"D x 29.92"W x 46.46"H
Item Weight	216 Pounds
Maximum Weight Recommendation	300 Pounds
Recommended Uses	Relaxing
Room Type	Indoor
Age Range Description	16+

Included Components	Arm Pad
Features	4D Massage, SL Track, Yoga Stretch, Zero Gravity, AI Voice Control, Heating, Automatic Footrest
Required Assembly	Yes
Product Care Instructions	Wipe Clean

6. Warranty and Support

Your Alfine A66 4D Full Body Massage Chair is backed by comprehensive support.

- **Coverage:** Our products are backed by a 3-year Coverage with Expert Support.
- **Customer Support:** 24/7 customer support is available. If you have any questions or issues with our products, feel free to contact us through Amazon or call our after-sales phone number directly. We are dedicated to providing you with the best shopping experience.



Image: U.S.-Based Support. This image illustrates the availability of customer support within the United States.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVYQM4WJ

More documents and user manuals: **https://manuals.plus/**