Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome 281IDSGL1BL

iHome Digital Bathroom Scale Instruction Manual

Model: 281IDSGL1BL

Brand: iHome

1. Introduction

Thank you for choosing the iHome Digital Bathroom Scale. This manual provides essential information for setting up, operating, and maintaining your new scale, ensuring accurate and consistent weight measurements. Designed for simplicity and precision, this scale is a reliable tool for tracking your health and fitness journey.



Figure 1: The iHome Digital Scale, showcasing its sleek design and included batteries.

The iHome Digital Scale features high-precision sensors, a 400 lbs / 180 kg max weight capacity, and a clear LED display. Its minimal and slim design allows it to fit seamlessly into any bathroom, bedroom, or gym environment. The 5mm tempered glass surface ensures durability and easy cleaning, while rounded corners provide enhanced safety.

2. Setup

2.1 Battery Installation

Your iHome Digital Scale requires 2 AAA batteries, which are included with your purchase. To install or replace batteries:

1. Locate the battery compartment on the underside of the scale.
2. Open the battery cover.

3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery cover securely.



Figure 2: The battery compartment and unit conversion button located on the bottom of the scale.

2.2 Scale Placement

For accurate readings, place the iHome Scale on a hard, flat, and level surface. Avoid placing it on carpets or uneven flooring, as this can affect measurement precision.



Figure 3: Proper placement of the scale on a hard, flat surface for optimal accuracy.

▶ **Watch video online**
Accurate weighing scale by iHome

Video 1: Demonstrates the unboxing, battery installation, and initial setup of the iHome Digital Scale.

3. Operating Instructions

3.1 Taking a Measurement

The iHome Digital Scale features a convenient step-on/step-off auto-calibrated platform for instant readings.

1. Place the scale on a hard, flat floor (not on a carpet).
2. Wait until the display reads "0.0" before stepping on.

3. Step onto the scale with bare, dry feet, standing still in the center.
4. Your weight will be displayed on the clear LED screen. The reading will blink to indicate it has locked in.



Figure 4: Visual guide for the step-on/step-off weighing process.

▶ **Watch video online**
iHome Weight Scale

Video 2: Shows the simple process of using the iHome Weight Scale to get a reading.

3.2 Unit Conversion

To switch between pounds (lb) and kilograms (kg):

1. Turn the scale over.
2. Locate the unit conversion button (usually a small button or switch) near the battery compartment.
3. Press or slide the button to toggle between lb and kg.

4. Maintenance

4.1 Cleaning the Scale

The iHome Digital Scale features a sleek, tempered glass surface that is easy to clean.

- Wipe the surface with a damp cloth and mild detergent.
- Do not use abrasive cleaners or immerse the scale in water.
- Ensure the scale is completely dry before storage or next use.

▶ **Watch video online**
Simple scale that is easy to use and clean!

Video 3: Demonstrates how easy it is to use and clean the scale, highlighting its simple design.

5. Troubleshooting Guide

If you are experiencing issues with your iHome Digital Bathroom Scale, please refer to the troubleshooting steps below to resolve common problems.

5.1 Scale Will Not Turn On

- **Check Batteries:** Ensure that the batteries are installed correctly and have sufficient charge. Replace with new AAA batteries if needed.
- **Battery Contacts:** Check for any corrosion or debris on the battery contacts and clean gently if necessary.
- **Reset the Scale:** Remove the batteries, wait 10 seconds, and then install them to reset the scale.

5.2 Inaccurate or Fluctuating Readings

- **Place on Hard, Flat Surface:** Use the scale on a hard, level surface (not carpet) for best accuracy.
- **Zero Calibration:** Step on and off the scale to allow it to calibrate to zero before weighing.
- **Consistent Positioning:** Stand still in the center of the scale with feet evenly spaced.
- **Environmental Factors:** Avoid weighing immediately after moving the scale or after changing the batteries. Allow the scale to rest for a minute before use.

5.3 Display Does Not Light Up

- **Battery Check:** Replace the batteries with new ones.
- **Contact Points:** Ensure the battery compartment is clean and the cover is securely closed.

5.4 Still Need Help?

If you have tried these steps and your scale is still not working properly, please contact our customer support team for further assistance.



Figure 5: Official troubleshooting guide for common scale issues.

6. Specifications

Product Dimensions	11 x 11 x 1 inches
Item Weight	2.2 Pounds
Max Weight Capacity	400 lbs / 180 kg (397 Pounds listed in specs)
Accuracy	0.1lb (0.05kg)
Display Type	LED
Batteries	2 AAA batteries (included)
Special Features	High Precision Sensors, Auto-Calibration
Material	5mm Tempered Glass

7. Warranty & Support

7.1 Warranty Information

The iHome Digital Scale comes with a 5-year warranty, ensuring long-term reliability and peace of mind. Please retain

your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, technical assistance, or warranty inquiries, please refer to the contact information provided in your product packaging or visit the official iHome website. Our dedicated customer support team is ready to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset and calibrate my iHome 281IDSGL1BL Digital Scale after changing the batteries to fix inaccurate readings?

If your iHome 281IDSGL1BL Digital Scale is providing inaccurate readings after a battery change, you should perform a manual reset and a zero-calibration. Follow these steps based on the official troubleshooting guide: Reset the...

Read full answer

Why does my iHome 281IDSGL1BL Digital Scale display 'Lo' even after I replaced the batteries?

On the iHome 281IDSGL1BL Digital Scale, the "Lo" message typically indicates low battery power. If you have already replaced the batteries and the message persists, please try the following troubleshooting steps: Perform a Hard...

Read full answer

Open the live page

https://manuals.plus/asin/B0BX1GVDBS

More documents and user manuals: **https://manuals.plus/**