Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCHLEICH 98642

Schleich 98642 Horse Club Advent Calendar Instruction Manual

Model: 98642

1. Introduction

Welcome to the instruction manual for your Schleich 98642 Horse Club Advent Calendar. This calendar offers a daily surprise, building anticipation throughout the holiday season. This manual provides essential information on setting up, using, and caring for your Advent Calendar and its contents to ensure an enjoyable experience.

2. Product Overview

The Schleich Horse Club Advent Calendar is designed to bring daily joy with 24 unique surprises. Each door reveals a special item, including two horse figurines and a variety of Horse Club accessories such as picnic baskets, apples, grooming supplies, and miniature animals. It's an exciting way to expand your Horse Club collection.



Figure 1: The Schleich 98642 Horse Club Advent Calendar in its packaging, showing the festive design and some of the included items.



Figure 2: A display of the various figurines and accessories included in the Advent Calendar, such as horses, a girl figure, a dog, chicks, and picnic items.

3. Setup

1. **Unboxing:** Carefully remove the Advent Calendar from its shipping packaging.
2. **Placement:** Place the calendar on a flat, stable surface, such as a table or shelf, where it can be easily accessed daily.
3. **Inspection:** Before starting, briefly inspect the calendar for any visible damage.

4. Daily Use (Operating)

The Advent Calendar is designed for daily interaction leading up to a special event. Follow these steps for optimal enjoyment:

1. **Identify the Date:** Each day, locate the door corresponding to the current date.
2. **Open the Door:** Gently press or pull the designated door to open it.
3. **Retrieve the Surprise:** Carefully remove the figurine or accessory found inside.
4. **Enjoy:** Integrate the new item into your Schleich Horse Club play scene.

5. Care and Maintenance

To ensure the longevity of your Schleich figurines and accessories, follow these care guidelines:

- **Cleaning:** Wipe figurines and accessories with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store items in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.
- **Handling:** Handle figurines and small parts with care to prevent breakage.

6. Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Keep small parts away from young children to prevent accidental ingestion.
- Adult supervision is recommended during play, especially with younger children.

7. Specifications

Brand	SCHLEICH
Model Number	98642
Product Dimensions (L x W x H)	38.61 x 7.37 x 28.19 cm
Item Weight	540 g
Material	Cardboard (calendar), Plastic (figurines/accessories)
Theme	Animal, Horse Club
Model Year	2022

8. Warranty and Support

For any questions regarding your Schleich 98642 Horse Club Advent Calendar, including product defects or missing parts, please contact Schleich customer support directly. Refer to the product packaging or the official Schleich website for the most current contact information and warranty details.

© 2023 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BXRFYZN6

More documents and user manuals: **https://manuals.plus/**