Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOTSTA 6

WOTSTA Ergonomic Gaming Chair with Massage and Footrest (Model 6) User Manual

1. Introduction

Thank you for choosing the WOTSTA Ergonomic Gaming Chair with Massage and Footrest. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.


WOTSTA
SUNIDA
WOTSTA

Image 1: WOTSTA Ergonomic Gaming Chair, Technobeige color, featuring a high back, headrest, lumbar support, armrests, and a retractable footrest.

2. Safety Information

To ensure safe operation and prevent injury, please adhere to the following guidelines:

- Do not exceed the maximum weight capacity of **300 lbs (136 kg)**.
- Exercise caution when adjusting the lumbar support and headrest to avoid pinching or injury.
- Use the caster wheels with care to prevent tipping, especially on uneven surfaces.
- This chair is intended for **indoor use only**.
- Always follow the assembly instructions precisely for safe and stable use.
- Keep children and pets away from the chair during assembly and adjustment.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Backrest
- Seat Base with Armrests
- Headrest Pillow
- Lumbar Support Pillow (with massage function)
- Retractable Footrest
- Gas Lift Cylinder
- Star Base with Caster Wheels
- Assembly Hardware (screws, washers, tools)
- Instruction Manual

4. Setup and Assembly

Assembly typically takes 10-15 minutes. Follow these steps carefully. All necessary hardware and tools are included.

1. **Attach Caster Wheels to Base:** Insert the five caster wheels into the holes on the star base until they click securely into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base.
3. **Attach Seat to Gas Lift:** Carefully place the seat base onto the gas lift cylinder. Ensure it is centered and stable.
4. **Connect Backrest to Seat:** Align the backrest with the seat base and secure it using the provided screws. Ensure all screws are tightened evenly.
5. **Attach Armrests:** Secure the armrests to the seat base using the designated screws.
6. **Install Footrest:** Slide the retractable footrest into its designated slots under the seat.
7. **Position Headrest and Lumbar Support:** Attach the headrest pillow and lumbar support pillow to the backrest using their adjustable straps. The lumbar pillow contains a massage motor and requires a USB

power source (not included).



Image 2: Illustration of attaching the caster wheels to the chair's star base.



Image 3: Illustration showing the gas lift cylinder being inserted into the base and the seat placed on top.



Image 4: Illustration demonstrating how to attach the backrest to the seat using screws.



Image 5: Illustration showing the armrests being secured to the chair's seat.



Image 6: Illustration of the retractable footrest being installed under the seat.



Image 7: Close-up view of the soft neck pillow and lumbar support with an inserted massage motor (USB powered).

5. Operating Instructions

5.1. Height Adjustment

To adjust the chair's height, locate the **Height Stick Button** (lever) on the right side, beneath the seat. Pull the lever upwards while seated to lower the chair, or pull it upwards while standing to raise the chair. Release the lever to lock the height.

5.2. Recline Function

The backrest can recline between 90 and 135 degrees. Locate the **Angle Stick Button** (lever) on the right side, beneath the seat. Pull the lever upwards to unlock the backrest, then lean back to your desired angle. Release the lever to lock the backrest in position.



Image 8: Diagram illustrating the recline function from 90 to 135 degrees and the location of the angle and height adjustment levers.

5.3. Retractable Footrest

To use the footrest, pull it outwards from beneath the seat. Extend it to your desired length. To retract, push it back under the seat until it is fully stored.



Image 9: Illustration showing the retractable footrest extended, with a cutaway view of its layered cushioning.

5.4. Massage Function

The lumbar support pillow includes a massage motor. Connect the USB cable from the lumbar pillow to a compatible USB power source (e.g., power bank, computer USB port, wall adapter). The massage function will activate upon connection.

5.5. 360-Degree Swivel

The chair is designed to swivel 360 degrees for ease of movement and access to your workspace.



Image 10: Diagram illustrating the chair's 360-degree swivel capability and height adjustment.

6. Maintenance

Proper care will extend the life and appearance of your WOTSTA Gaming Chair.

- **Cleaning:** The manufacturer recommends **dry cleaning** for the chair's upholstery. For minor spills, gently blot with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Caster Wheels:** Periodically check the caster wheels for hair or debris that may impede smooth rolling. Clean as necessary.
- **Fasteners:** Over time, screws and bolts may loosen. Periodically check and tighten all fasteners to maintain stability and prevent wobbling.
- **General Care:** Avoid exposing the chair to direct sunlight for prolonged periods to prevent fading. Keep away from sharp objects to prevent damage to the upholstery.

7. Troubleshooting

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable	Loose assembly screws; uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Height adjustment not working	Gas lift cylinder malfunction; lever not fully engaged.	Ensure the height adjustment lever is fully pulled or pushed. If the issue persists, contact customer service.

Problem	Possible Cause	Solution
Backrest does not recline or lock	Recline mechanism jammed; lever not fully engaged.	Ensure the recline lever is fully pulled or pushed. Check for obstructions.
Footrest is difficult to extend/retract	Mechanism obstruction or damage.	Check for any obstructions in the footrest tracks. Apply a silicone-based lubricant if movement is stiff. Do not force.
Massage function not working	USB power not connected or insufficient; motor malfunction.	Ensure the USB cable is securely connected to a working power source. Try a different USB port or power source.
Squeaking or creaking noises	Loose connections; friction between parts.	Tighten all screws. Apply a small amount of lubricant to moving parts or joints if necessary.

8. Specifications

Feature	Detail
Brand	WOTSTA
Model Name	6
Color	Technobeige
Product Dimensions (D x W x H)	18.9" x 20.87" x 51.97"
Seat Adjustable Height	17.3" to 21.5"
Maximum Weight Capacity	300 Pounds (136 kg)
Recline Function	90-135 Degrees
Swivel	360 Degree
Material	Premium PVC Leather, Sponge, Steel Frame
Special Features	Adjustable Height, Adjustable Lumbar, Arm Rest, Ergonomic, Swivel, Massage Function, Retractable Footrest
Product Care	Dry Clean
Item Weight	41.8 pounds (18.96 kg)
UPC	702909854400

PRODUCT DIMENSION



Image 11: Detailed diagram showing the various dimensions of the WOTSTA Gaming Chair, including height, width, and depth measurements.



Image 12: Close-up of the mute rolling caster wheels, highlighting their durability and 300 lbs load-bearing capacity.

9. Warranty and Support

WOTSTA provides the following customer guarantee:

- **30-Day Replacement:** Replacement for any reason within 30 days of purchase.
- **12-Month Parts Replacement:** Replacement for damaged or defective parts within 12 months of purchase.

For any dissatisfaction with our products or service, please contact WOTSTA customer service directly. Contact information can typically be found on the product packaging or the official WOTSTA website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BXW51QVX

More documents and user manuals: **https://manuals.plus/**