Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SENIX BLX2-M

SENIX 20V Cordless Leaf Blower (BLX2-M) Instruction Manual

Model: BLX2-M | Brand: SENIX

1. Important Safety Information

Always read and understand this instruction manual before operating the SENIX 20V Cordless Leaf Blower. Failure to follow all instructions may result in electric shock, fire, and/or serious injury.

General Safety Warnings

- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and gloves.
- Keep children and bystanders away while operating the blower.
- Do not operate the blower in wet conditions or in the presence of flammable liquids or gases.
- Ensure the battery is fully charged before use.

Battery Safety

- Use only the specified 20V Max Lithium-Ion battery and 20V Max 2 amp charger provided by SENIX.
- Do not expose batteries to water or extreme temperatures.
- Store batteries in a cool, dry place away from direct sunlight.

2. Product Overview

The SENIX 20V Cordless Leaf Blower (Model BLX2-M) is a lightweight, handheld electric blower designed for efficient lawn care and debris removal. It features a brushless motor for reliable performance and extended tool life.

Key Features:

- **Brushless Motor:** Provides efficient power and longer runtime.
- **3 Variable Speed Modes:** Low (70 MPH), Middle (100 MPH), High (180 MPH) for versatile use.
- **Air Volume & Speed:** Up to 75 CFM / 180 MPH for effective clearing.
- **Lightweight Design:** Easy to control with one hand, weighing approximately 4.4 pounds.
- **2.5Ah Battery & Charger:** Includes a 20V Max Lithium-Ion battery with power indicator and a 2 amp charger.
- **Cruise Control:** Allows for continuous operation without holding the trigger.



Image: Overview of the SENIX 20V Cordless Leaf Blower, highlighting its 3-speed selector, soft grip handle, lightweight design, and included battery and charger.



Image: Close-up of the blower's handle, illustrating the one-button trigger and variable 3-speed options (70 MPH, 100 MPH, 180 MPH).

3. Setup

Assembly Instructions

1. **Attach the Blower Tube:** Align the blower tube with the outlet on the main unit. Push the tube firmly onto the blower until it clicks into place. Rotate to secure it.
2. **Install the Battery:** Slide the 20V Max Lithium-Ion battery into the battery slot on the blower until it locks securely. Ensure it is fully seated.



Image: A visual guide showing five steps for quick setup: attaching the tube, rotating to secure, installing the battery, pressing the switch, and releasing the battery.

Battery Charging

- Connect the 20V Max 2 amp charger to a standard power outlet.
- Slide the battery onto the charger. The power indicator lights on the battery will show charging status.
- A fully discharged 2.5Ah battery charges in approximately 90 minutes.

Installation Video

▶ **Watch video online**

SENIX 20V Cordless Leaf Blower Installation Video

Video: Official SENIX 20V Cordless Leaf Blower Installation Video, demonstrating the assembly process and battery installation.

4. Operating Instructions

Starting the Blower

1. Ensure the battery is fully charged and securely installed.
2. Press the On/Off switch to power on the blower.
3. Use the variable speed trigger to adjust airflow. For continuous operation, engage the cruise control feature by turning the dial to your desired speed.



Image: A close-up of the blower's handle, showing the 3-speed control switch for adjusting wind speed to meet various needs.

Usage Tips

- **Low Speed (70 MPH):** Ideal for delicate areas like flower gardens or light debris.
- **Middle Speed (100 MPH):** Suitable for general clearing of dry leaves and light grass clippings.
- **High Speed (180 MPH):** Use for heavier or wet debris, and larger areas.
- The concentrator nozzle provides focused airflow for increased efficiency in specific areas.

▶ **Watch video online**
Watch How Strong This Cordless Leaf Blower Is!

Video: A demonstration of the SENIX 20V Cordless Leaf Blower's power in action, showing its effectiveness in clearing debris.

▶ **Watch video online**
Testing the Wind Speed of My Leaf Blower! 122MPH!!

Video: A test of the blower's wind speed, demonstrating its capability to reach up to 122 MPH.

5. Maintenance

Regular maintenance ensures optimal performance and extends the life of your SENIX 20V Cordless Leaf Blower.

Cleaning

- Always remove the battery before cleaning.
- Wipe the exterior of the blower with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the air intake and blower tube are free from debris to maintain proper airflow.

Storage

- Store the blower and battery in a cool, dry, and well-ventilated area.
- Keep out of reach of children and away from direct sunlight or extreme temperatures.
- For long-term storage, ensure the battery is partially charged (around 50%) to prolong its lifespan.

6. Troubleshooting

If you encounter issues with your SENIX 20V Cordless Leaf Blower, refer to the following common problems and solutions:

- **Blower does not start:**
  - Ensure the battery is fully charged and properly installed.
  - Check if the On/Off switch is in the 'On' position.
- **Low airflow:**
  - Check the blower tube and air intake for any obstructions.
  - Ensure the battery is fully charged.
- **Battery not charging:**

- Verify the charger is properly plugged into a working outlet.
- Ensure the battery is correctly seated on the charger.

7. Specifications

Feature	Specification
Brand	SENIX
Model Number	BLX2-M
Power Source	Battery Powered
Voltage	20 Volts
Item Weight	4.4 Pounds
Maximum Speed	180 Miles per Hour
Air Volume	75 CFM
Noise Level	75 Decibels
Included Components	Blower, 2.5Ah Battery, 2 Amp Charger

8. Warranty & Support

Warranty Information

The SENIX 20V Cordless Leaf Blower (BLX2-M) is covered by a **5-year limited warranty** for the tool and a **3-year limited warranty** for the battery.

Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact SENIX customer support. Refer to the contact information provided in your product packaging or visit the official SENIX website.

You can also visit the SENIX Store on Amazon for more product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZ5BQS1Y

More documents and user manuals: **https://manuals.plus/**