Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 61-R1200S

Braun Series 6 61-R1200S Wet&Dry Electric Shaver User Manual

Model: 61-R1200S

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your Braun Series 6 61-R1200S Wet&Dry Electric Shaver. Please read all instructions carefully before using the appliance and retain this manual for future reference. Your Braun shaver is designed for a comfortable and efficient shaving experience, whether dry or with foam/gel.

2. Important Safety Information

WARNING:
Always use the shaver over a sink or in the shower with caution to avoid slips. Do not use the shaver while charging or near water to prevent electrical shock. Always clean and dry the shaver thoroughly after each use to prevent bacterial growth and ensure optimal performance.

- Keep the appliance dry.
- Do not immerse the appliance in water.
- Do not open the appliance.
- This appliance is suitable for cleaning under running tap water.
- The appliance includes a special cord set with an integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised.

3. What's in the Box

Your Braun Series 6 61-R1200S package includes the following items:

- Braun Series 6 Electric Shaver

- Precision Trimmer attachment
- Charging stand/cable
- Cleaning brush
- Travel case
- User Manual



Image: The Braun Series 6 electric shaver, its packaging, and included accessories such as the precision trimmer and charging cable.



Image: A complete view of all items included in the package: the shaver, precision trimmer, charging cable, cleaning brush, and travel case.

4. Product Overview and Features

The Braun Series 6 61-R1200S is equipped with advanced features for a comfortable and close shave.

4.1 SensoFlex Head

The SensoFlex head is designed to adapt to your facial contours, minimizing pressure on the skin for a comfortable shave, especially on sensitive areas.



Image: A close-up view of the SensoFlex shaver head, highlighting its flexible design that adapts to facial curves.

4.2 AutoSense Technology

AutoSense technology reads your beard density and adapts the motor power to provide an efficient shave even on dense beards.



Image: A person using the Braun shaver, illustrating how AutoSense Technology adjusts to beard density for an optimal shave.

4.3 EasyClick System

The EasyClick system allows for quick and easy attachment changes, transforming your shaver for different grooming needs, such as trimming sideburns or styling a beard.



Image: Demonstrating the EasyClick system, showing how the precision trimmer attachment is easily clicked onto the shaver body.

5. Setup and Charging

5.1 Initial Charging

1. Before first use, charge your shaver for approximately 1 hour. This provides up to 50 minutes of shaving time.
2. Connect the special cord set to the shaver and plug it into an electrical outlet.
3. The charging indicator light will show the charging status.

5.2 Attaching/Detaching Attachments

1. To attach an EasyClick accessory (e.g., Precision Trimmer), remove the shaver head by pulling it upwards.
2. Align the accessory with the shaver body and press it down until it clicks into place.
3. To detach, pull the accessory upwards.

6. Operating Instructions

6.1 Shaving Your Face

- **Dry Shaving:** Ensure your face is dry before shaving. For best results, shave before washing your face.
- **Wet Shaving:** The shaver can be used with foam, gel, or in the shower. Apply shaving foam or gel to your face.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of hair growth.
- Apply gentle, even pressure. Do not press too hard.

6.2 Using the Precision Trimmer

The precision trimmer attachment is ideal for shaping sideburns, mustaches, or beards.

1. Attach the precision trimmer as described in section 5.2.
2. Turn on the shaver.
3. Carefully trim hair to the desired length or shape.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your shaver.

7.1 Daily Cleaning

1. After each shave, turn off the shaver.
2. Remove the shaver head.
3. Rinse the shaver head and the shaver body under hot running water until all hair residues are removed.
4. For a more thorough cleaning, you can use a small amount of liquid soap.
5. Shake off excess water and let the shaver head and body air dry completely before reattaching or storing.

7.2 Deep Cleaning (Weekly)

- Use the provided cleaning brush to remove stubborn hair particles from the shaver head.
- Apply a drop of light machine oil (not included) to the foil and cutter block once a week to maintain cutting performance.

7.3 Replacing Shaver Parts

To maintain 100% shaving performance, replace the foil and cutter cassette every 18 months, or when worn. Replacement parts are available from Braun retailers or service centers.

8. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is discharged.	Charge the shaver for at least 5 minutes, or until the charging indicator lights up.
Reduced shaving performance.	Foil and cutter cassette are worn or dirty.	Clean the shaver thoroughly. If performance does not improve, replace the foil and cutter cassette.
Shaver pulls hair.	Foil and cutter cassette are worn or damaged.	Replace the foil and cutter cassette. Ensure proper cleaning after each use.
Charging indicator not working.	Faulty power cord or outlet.	Check the power outlet with another device. Ensure the special cord set is correctly connected. Contact customer service if the issue persists.

9. Specifications

Feature	Detail
Model Name	Series 6
Item Model Number	61-R1200S (433002)
Brand	Braun
Head Type	Foil (SensoFlex)
Shaving Type	Wet & Dry
Power Source	Battery Powered (Li-Ion)
Battery Life	Up to 50 minutes (after 1 hour charge)
Quick Charge	5 minutes for one shave
Waterproof	Yes, 100% waterproof
Product Dimensions	10 x 5 x 1.27 cm
Item Weight	0.6 Kilograms
Blade Material	Stainless Steel

10. Warranty and Support

Braun products are manufactured to the highest quality standards. This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage.

For further assistance, troubleshooting, or to purchase replacement parts, please visit the official Braun website or contact Braun customer service in your region. Contact information can typically be found on the Braun website or in the warranty documentation.

Online Support: www.braun.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C159KQ4C

More documents and user manuals: **https://manuals.plus/**