Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy SW-M01-BK

Sweetcrispy SW-M01-BK Small Mobile Rolling Standing Desk User Manual

Model: SW-M01-BK | Brand: Sweetcrispy

Important Safety Information

Please read and understand all safety instructions before assembling or operating this product. Failure to follow these instructions may result in injury or product damage.

- Always use both hands to adjust the desk height to prevent sudden movements.
- Engage the wheel locks when the desk is in use to prevent unwanted movement.
- Keep fingers and other body parts away from the height adjustment mechanism while in use.
- Do not exceed the maximum weight capacity of 33 pounds (15 kg).
- Ensure the desk is placed on a stable, level surface.

Product Overview

Description

The Sweetcrispy SW-M01-BK is a versatile, height-adjustable mobile desk designed for various environments including home, office, and classroom. It features a gas spring system for smooth height adjustments and lockable casters for easy mobility and stability, providing an ergonomic workstation solution.

Key Features

- **Height Adjustable:** Gas spring system allows quick and smooth height changes from 28.5 to 42.5 inches.
- **Premium Material:** Durable thickened steel frames and wear-resistant desktop surface.
- **Mobile Design:** Four flexible, 360° rotating casters for easy movement, with two lockable for stability.
- **Space-Saving:** Single-column structure and compact base design allow for use in various settings and easy storage.
- **Versatile Applications:** Suitable for laptops, tablets, and various professional or personal uses.

Package Contents

Before assembly, please ensure all the following components are present in your package:

- Desktop Surface
- Central Support Column (with pre-installed gas spring)
- Base Frame
- 4 Caster Wheels (2 lockable)
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual



The Sweetcrispy SW-M01-BK mobile standing desk, showcasing its compact design and functionality.

Setup and Assembly

Assembly of the Sweetcrispy SW-M01-BK desk is straightforward and typically takes approximately 10-15 minutes. Follow these steps carefully to ensure proper setup.

Step-by-Step Assembly

1. **Attach the Base Frame:** Secure the base frame to the bottom of the central support column using the provided screws and Allen wrench. Ensure all connections are tight and stable.
2. **Install Caster Wheels:** Insert the four caster wheels into the designated slots on the base frame. Two of these wheels are lockable; ensure they are placed where easily accessible for locking and unlocking.
3. **Mount the Desktop:** Carefully align the desktop with the top of the central support column. Secure it firmly using the remaining screws and Allen wrench. Double-check all connections for stability.



This diagram illustrates the overall dimensions of the desk (25.7"D x 19"W x 28.5"-42.5"H) and its maximum load capacity of 33 lbs,

which is helpful for assembly and placement.

Operating Instructions

Adjusting Desk Height

The desk features a powerful gas spring system for smooth and effortless height adjustment.

1. Locate the height adjustment lever positioned on the side of the desktop, beneath the surface.
2. To **raise** the desk, gently lift the lever while applying slight upward pressure on the desktop. The gas spring will assist in lifting the desk to your desired standing height.
3. To **lower** the desk, lift the lever and apply firm downward pressure on the desktop. You may need to apply your full bodyweight for smooth compression, especially when lowering from higher positions.
4. Release the lever once the desired height (between 28.5 and 42.5 inches) is reached to lock the desk securely in place.



This image shows the desk's ergonomic sit-stand capability, illustrating its adjustable height range from 28.5 inches for seated use to 42.5 inches for standing.



This image details the pneumatic device lever used to effortlessly adjust the desk's height.

Moving the Desk

The desk is equipped with four caster wheels for easy mobility across various floor types.

1. To move the desk, ensure the two lockable casters are in the unlocked position.
2. Gently push or pull the desk to its desired location. The 360° rotation wheels allow for smooth movement on surfaces including carpet.
3. Once positioned, engage the locks on the two lockable casters to secure the desk and prevent unwanted movement during use.



This image highlights the desk's smooth and stable mobility, showing how the 4 upgraded mute smooth casters allow easy movement, with 2 lockable casters for stability.



This image illustrates the locking mechanism on the caster wheels, essential for securing the desk in a stationary position.

Maintenance

Cleaning

To maintain the appearance and longevity of your Sweetcrispy SW-M01-BK desk, follow these cleaning guidelines:

- Wipe the desktop and metal frame with a damp cloth to remove dust and spills.
- For stubborn marks, use a mild soap solution on a soft cloth, then wipe clean with a damp cloth and dry thoroughly.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.



This image demonstrates the ease of cleaning the desk surface with a damp cloth, highlighting its low maintenance.

General Care

- Regularly check all screws and connections to ensure they remain tight. Tighten if necessary to maintain stability.
- Keep the gas spring mechanism free from obstructions and excessive dust.
- Avoid placing excessively heavy items on the desk; adhere strictly to the maximum weight recommendation of 33 pounds.

Troubleshooting

Common Issues and Solutions

- **Desk is difficult to lower:** Ensure the height adjustment lever is fully engaged. Apply firm, even downward pressure on the center of the desktop while lifting the lever. The gas spring may require significant force to compress, especially when lowering from the highest position.
- **Wheels are not rolling smoothly:** Check for any debris, dust, or hair caught in the caster wheels. Clean them thoroughly if necessary. Ensure the wheel locks are fully disengaged.
- **Desk feels wobbly:** Verify that all assembly screws are securely tightened. Ensure the desk is placed on a flat, even surface. Avoid leaning heavily on the desk, particularly when it is set at its maximum height.
- **Desk does not stay at desired height:** Ensure the height adjustment lever is fully released after setting the height. If the issue persists, the gas spring mechanism may require inspection. Contact customer support for further assistance.

Specifications

Feature	Detail
Brand	Sweetcrispy

Feature	Detail
Model Number	SW-M01-BK
Product Dimensions (D x W x H)	25.7"D x 19"W x 28.5"-42.5"H
Color	Black
Material (Desktop)	Nylon
Material (Base/Frame)	Metal (Steel)
Height Adjustment Range	28.5 inches to 42.5 inches
Maximum Weight Recommendation	33 Pounds
Casters	4 (2 lockable)
Assembly Required	Yes
Item Weight	21.3 Pounds

Warranty and Support

Warranty Information

This Sweetcrispy product comes with a**Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions, or visit the official Sweetcrispy website for detailed warranty information.

Customer Support

For technical assistance, missing parts, or warranty claims, please contact Sweetcrispy customer support. When contacting support, please have your model number (SW-M01-BK) and purchase date available.

- **Website:** www.sweetcrispy.com (*Note: This is a placeholder URL. Please refer to your product documentation for the correct support website.*)
- **Email:** support@sweetcrispy.com (*Note: This is a placeholder email. Please refer to your product documentation for the correct support email.*)
- **Phone:** [Insert Phone Number Here] (*Note: Please refer to your product documentation for the correct support phone number.*)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1SG12TH

More documents and user manuals: **https://manuals.plus/**