Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC-304

Allimity RC-304 Replacement Remote Control User Manual

For Insignia TV Models

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your Allimity RC-304 Replacement Remote Control. This remote is designed to function as a direct replacement for various Insignia TV models, requiring no programming for immediate use.

2. Setup: Battery Installation

The Allimity RC-304 remote control requires two AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 1: Battery compartment with cover removed. This image shows the back of the remote control with the battery cover slid off, revealing the compartment designed to hold two AAA batteries. This illustrates where to insert new batteries for operation.

Once batteries are installed, the remote is ready for use with compatible Insignia TV models without any additional programming.

3. Operation

The Allimity RC-304 remote control provides full functionality for your compatible Insignia TV. Below is a guide to its primary buttons and their functions.




VOL
CH
INPUT
SLEEP
EXIT
INFO
OK
ENTER
GUIDE
MENU
1
2
3
4
5
6
7
8
RECALL
9
0
FAV
SAP
FREEZE
CCD
AUDIO
PICT
ZOOM
TV
VIDEO
COMP
HDMI
MUTE

Figure 2: Front view of the remote control with button layout. This image shows the complete layout of the Allimity RC-304 remote control, highlighting the power button, volume and channel controls, input selection, navigation pad with OK/Enter, number keys, and various function buttons.

3.1 Basic Functions

- **Power ( )**: Turns the TV on or off.
- **Mute**: Mutes or unmutes the TV audio.
- **VOL +/-**: Increases or decreases the volume level.
- **CH +/-**: Changes the TV channel up or down.
- **INPUT**: Cycles through available input sources (HDMI, AV, Component, etc.).
- **Navigation Pad (Up, Down, Left, Right)**: Navigates through on-screen menus.
- **OK/ENTER**: Confirms selections in menus.
- **EXIT**: Exits the current menu or on-screen display.
- **Number Buttons (0-9)**: Directly selects channels.

3.2 Advanced Functions

- **SLEEP**: Sets a timer for the TV to turn off automatically.
- **INFO**: Displays current channel information or program details.
- **GUIDE**: Accesses the electronic program guide (if supported by your TV and service).
- **MENU**: Opens the TV's main settings menu.
- **RECALL**: Switches between the current and previously viewed channel.
- **FAV**: Accesses favorite channels list.
- **SAP**: Selects Secondary Audio Program (e.g., different language audio tracks).
- **FREEZE**: Pauses the current image on screen.
- **CCD**: Activates Closed Captioning display.
- **AUDIO**: Adjusts audio settings or modes.
- **PICT**: Adjusts picture settings or modes.
- **ZOOM**: Zooms in on the screen.
- **TV**: Switches to TV mode.
- **HDMI**: Directly selects an HDMI input.
- **COMP**: Directly selects a Component input.

4. Compatibility

The Allimity RC-304 remote control is compatible with a wide range of Insignia TV models. This remote is designed to replace the original remote for the following models:

- NSL22Q10A
- NSL19Q10A
- NSL32Q0910A
- NSL19W1Q10A
- NSL26Q10A
- NSL47Q09
- NSL47Q0910A

- E199AZNKW3BANN
- E329XZNKW1BYNN
- E199AZNKW3BYNN
- E26RAZNKW3BTNN
- E199CZNKW3BYNN
- E19R2ZNKW3BANN
- E19R2ZNKW3BENN
- E2295ZNKW3BENN
- E2295ZNKW3BYNN
- E22R2ZNKW3BENN
- E22R2ZNKW3BYNN
- E269AZNKW3BBNN
- E19R2ZNKW3BYNN
- E269AZNKW3BTNN
- E269MZNKW3BTNN
- E329SZNKW1BYNN
- E26RAZNKW3BYNN
- E329GZNKW1BYNN
- E479MZNKW1BENN
- E479MZNKW1BMNN
- E26RAZNKW3BENN



Figure 3: Replacement remote compared to original. This image visually compares the Allimity RC-304 replacement remote with the original Insignia RC-304 remote, demonstrating their similar appearance and button layout, confirming its suitability as a replacement.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage**: Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If

the remote will not be used for an extended period, remove the batteries to prevent leakage.

- **Handling**: Avoid dropping the remote control or exposing it to excessive force, as this can damage internal components.

6. Troubleshooting

If you experience issues with your Allimity RC-304 remote control, try the following troubleshooting steps:

- **Remote Not Responding**:
  - Ensure the batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Specific Buttons Not Working**:
  - This may indicate a dirty or faulty button. Try cleaning the remote as described in the Maintenance section.
  - If only certain buttons fail, and others work, it might be a hardware issue.
- **TV Not Responding to All Functions**
  - While this remote is a direct replacement, some very specific functions might vary slightly depending on the exact TV model. Refer to your TV's original manual for specific feature compatibility.

7. Specifications

Model Number	RC-304
Brand	ALLIMITY
Power Supply	2 x AAA Alkaline Batteries (not included)
Connectivity Technology	Infrared (IR)
Compatible Devices	Insignia Televisions
Product Dimensions	5.9 x 1.8 x 0.8 inches
Item Weight	1.83 ounces

8. Warranty and Support

For any warranty claims or technical support inquiries regarding your Allimity RC-304 remote control, please contact the seller or manufacturer directly through your purchase platform. Details regarding specific warranty periods and support procedures are typically provided at the point of purchase or on the seller's information page.
Please retain your proof of purchase for warranty purposes.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2PXSK6Q

More documents and user manuals: **https://manuals.plus/**