Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun CG7040

Braun MultiGrill 7 CG 7040 Contact Grill User Manual

Model: CG7040

1. Introduction

The Braun MultiGrill 7 CG 7040 is a versatile contact grill designed for various cooking applications. It features three distinct grill positions: closed contact grilling, fully open BBQ grilling, and an oven function. The appliance is equipped with integrated heating elements for even heat distribution and offers independent temperature control for each plate, allowing for precise cooking. The removable, dishwasher-safe plates and integrated grease tray facilitate easy cleaning and maintenance.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.

3. Product Components

The Braun MultiGrill 7 CG 7040 includes the main grill unit and two interchangeable cooking plates: one grill plate and one flat plate.



Figure 3.1: The Braun MultiGrill 7 CG 7040 main unit with its control panel and the included grill and flat plates.



Figure 3.2: Illustration of the MultiGrill 7 unit and the two types of cooking plates (grill and flat) included in the package.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the grill.
2. **Initial Cleaning:** Before first use, wipe the exterior of the grill with a damp cloth. Wash the cooking plates and the grease drip tray in warm, soapy water, then rinse and dry thoroughly.
3. **Plate Installation:** Ensure the grill is unplugged and cool. Align the cooking plates with the slots on the grill base and top lid. Press down firmly until they click into place. The grill plate is typically used on the bottom, and the flat plate on the top, but they are interchangeable based on cooking needs.
4. **Grease Tray:** Insert the grease drip tray into its designated slot at the front or side of the grill base. This tray collects excess fat and juices during cooking.
5. **Placement:** Place the grill on a stable, heat-resistant, and level surface, away from walls and flammable materials, ensuring adequate ventilation.

5. Operating Instructions

5.1 Power On and Temperature Setting

- Plug the power cord into a grounded electrical outlet.
- Press the power button to turn on the grill.
- Use the individual temperature control knobs for the upper and lower plates to set the desired cooking temperature (up to 230°C). The display will show the set temperature.
- Allow the grill to preheat until the "READY" indicator appears on the display, signaling that the set temperature has been reached.

5.2 Grill Positions

The MultiGrill 7 offers three primary cooking positions:



Figure 5.1: Visual representation of the three available grill positions for diverse cooking methods.

1. **Contact Grill Position:**

   In this position, the top plate rests directly on the food, cooking both sides simultaneously. This is ideal for sandwiches, paninis, burgers, and thinner cuts of meat.



Figure 5.2: The grill operating in contact mode, cooking burgers between the upper and lower plates.

2. **BBQ Position (Fully Open):**

   By fully opening the grill, both plates lie flat, creating a large, open grilling surface. This is suitable for grilling larger quantities of food, such as steaks, chicken, vegetables, or seafood, similar to a traditional BBQ.



Figure 5.3: The grill fully opened to the BBQ position, used for grilling multiple items like steaks and vegetables.

3. **Oven Position:**

   This position allows the top plate to be locked at a certain height above the bottom plate, creating an oven-like environment. It is useful for melting cheese, warming food, or preparing dishes that require indirect heat from the top.



Figure 5.4: The grill in oven position, with the top plate elevated, suitable for dishes like bruschetta.

5.3 Cooking Process

- Once preheated, carefully place food onto the lower cooking plate.
- Close the top plate (for contact grilling) or leave it open (for BBQ grilling/oven mode) as desired.
- Monitor cooking progress. Cooking times will vary based on food type, thickness, and desired doneness.
- Use heat-resistant utensils to remove food from the grill.
- After cooking, turn off the grill and unplug it from the power outlet. Allow it to cool completely before cleaning.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your MultiGrill 7.

1. **Cool Down:** Always ensure the grill is unplugged and completely cool before attempting any cleaning.
2. **Remove Plates:** Press the plate release buttons to detach the cooking plates from the grill unit.
3. **Clean Plates:** The cooking plates are dishwasher-safe. Alternatively, they can be washed by hand with warm,

soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely before reattaching or storing.

4. **Grease Tray:** Empty the grease drip tray after each use. Wash it with warm, soapy water, rinse, and dry.
5. **Exterior Cleaning:** Wipe the exterior of the grill unit with a damp cloth. Do not use abrasive cleaners or scourers, as they may damage the finish. Never immerse the main unit in water or any other liquid.
6. **Storage:** Once clean and dry, reattach the plates and store the grill in a dry, safe place. The practical locking system allows for easy storage.



Figure 6.1: The cooking plates are designed to be easily removed and are safe for cleaning in a dishwasher.

7. Troubleshooting

Problem	Possible Cause	Solution
Grill does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Grill not heating up.	Temperature not set; grill not preheated; faulty heating element.	Check if the temperature knobs are set. Allow sufficient time for preheating. If problem persists, contact customer support.
Food is not cooking evenly.	Uneven food thickness; plates not fully preheated; incorrect temperature setting.	Ensure food is of uniform thickness. Allow grill to fully preheat. Adjust temperature settings as needed.

Problem	Possible Cause	Solution
Excessive smoke.	Grease buildup on plates; food with high fat content; drip tray full.	Clean plates thoroughly. Empty and clean the grease drip tray. Reduce cooking temperature if necessary.

8. Specifications

- **Model Number:** CG7040
- **Brand:** Braun
- **Manufacturer:** De'Longhi
- **Power:** 2000 Watts
- **Maximum Temperature:** 230°C
- **Material:** Cast Iron (plates), Black/Stainless Steel (housing)
- **Product Dimensions:** 31.5 x 36.5 x 17.3 cm (L x W x H)
- **Weight:** 5.4 kg
- **Special Feature:** Variable temperature control, Dishwasher-safe plates



Figure 8.1: Dimensional overview of the Braun MultiGrill 7 CG 7040, including its power rating.

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included with your product or visit the official Braun website. Keep your purchase receipt as proof of purchase.

Manufacturer: De'Longhi

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2VZJXZR

More documents and user manuals: **https://manuals.plus/**