Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Chicco 00011558000000

Chicco 2-in-1 Projector Polar Bear First Dreams User Manual

Brand: Chicco | Model: 00011558000000

Introduction

The Chicco First Dreams Polar Bear Projector is a versatile 2-in-1 device designed to create a soothing environment for your baby's sleep. It features spectacular lighting effects, including an aurora borealis projection, and relaxing melodies, combining classical music with nature sounds. This projector can be used either attached to a cot or placed on a bedside table, offering customizable functions to suit your needs.



The Chicco 2-in-1 Projector Polar Bear, a versatile device for creating a calming atmosphere.

Safety Information

Before use, carefully read the instructions and warnings contained in the leaflet and on the packaging.

- Always supervise infants and young children when the projector is in use.
- Keep the device out of reach of children when not in use or during battery replacement.
- Do not immerse the device in water or other liquids.
- Use only the recommended battery type (AAA) and ensure correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove exhausted batteries promptly.
- Dispose of batteries responsibly according to local regulations.
- Do not expose the device to extreme temperatures or direct sunlight.

What's in the Box

The package contains the following components:

- Chicco First Dreams Polar Bear Projector (made of ABS, PA, TPE, POM, PP plastics)
- Instruction Manual

Note: Batteries are not included. 3 AAA batteries are required for operation.

Setup

1. Battery Installation

1. Locate the battery compartment on the underside of the projector.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

2. Placement Options

The Chicco Polar Bear Projector offers two primary placement options:

A. Cradle/Cot Attachment

The modular mounting system allows the projector to be securely attached to most wooden cribs and Chicco Next2Me cots with walls up to 38mm thick.

1. Identify the adjustable clamp on the projector.
2. Open the clamp and position it over the edge of the cot rail.
3. Tighten the clamp securely until the projector is firmly attached and stable.



The projector features a modular mounting system compatible with most wooden cribs and Chicco Next2Me beds.

B. Bedside Table Placement

The projector can also be placed freestanding on any flat, stable surface, such as a bedside table or dresser.

1. Ensure the surface is level and clear of obstructions.
2. Place the projector in a position where its projection can be seen clearly on a wall or ceiling.

Operating Instructions

The Chicco Polar Bear Projector is designed for ease of use with customizable functions.

1. Power On/Off and Projection Control

- Locate the power/projection button on the projector.
- Press once to turn on the projector and activate the aurora borealis projection.

- Press again to turn off the projection.
- The projector automatically turns off after 30 minutes of operation.



Experience fascinating dancing light shows projected onto the wall or ceiling.

2. Melody and Sound Selection

- Locate the melody selection button.
- Press this button to cycle through the available melodies and nature sounds.
- The projector offers 30 minutes of classical music (Mozart, Bach, Glinka) and various nature sounds.



The projector provides relaxing melodies and nature sounds to aid in sleep.

3. Volume Control

- The projector features two volume levels.
- Use the dedicated volume control button to adjust the sound output to your preference.

4. Customizing the Bedtime Ritual

You can personalize the experience by choosing to have only music, only lights, or both simultaneously.

PERSONALIZZA IL RITUALE DELLA NANNA

2 *livelli di volume*

Scegli la *musica preferita*

Modalità *solo musica* o *solo luci*



Customize your baby's bedtime ritual with options for music, lights, and volume control.



The projector provides a reassuring light, suitable for older children as well.

Maintenance

Cleaning

- To clean the projector, wipe the surface with a soft, slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Ensure the device is completely dry before storing or next use.
- Do not immerse the projector in water.

Storage

- When not in use for extended periods, remove the batteries to prevent leakage.
- Store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Projector does not turn on.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA batteries, ensuring correct polarity.
No sound or distorted sound.	Volume is too low or batteries are low.	Increase volume using the control button. Replace batteries if sound remains distorted.
Projection is dim or not visible.	Room is too bright or batteries are low.	Ensure the room is sufficiently dark. Replace batteries.
Projector is unstable when attached to cot.	Clamp is not tightened sufficiently or cot rail is too thick/thin.	Re-tighten the clamp. Ensure cot rail thickness is within the 38mm limit.

Specifications

Feature	Detail
Product Dimensions	5.12 x 3.94 x 5.91 inches (13 x 10 x 15 cm)
Item Model Number	00011558000000
Batteries Required	3 AAA batteries (not included)
Material Type	Plastic (ABS, PA, TPE, POM, PP)
Power Source	Battery
Item Weight	1.34 pounds (0.61 kg)
Projection Timer	30 minutes automatic shut-off
Music Duration	30 minutes
Volume Levels	2
Cot Compatibility	Walls up to 38mm thick

Warranty and Support

For detailed warranty information and customer support, please refer to the official Chicco website or contact their customer service department. Keep your purchase receipt as proof of purchase.
You can visit the official Chicco website for further assistance:www.chicco.com

© 2024 Chicco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2Z624N9

More documents and user manuals: **https://manuals.plus/**