Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eufy X8 Pro

Eufy Clean X8 Pro Robot Vacuum with Self-Empty Station User Manual

Model: X8 Pro | Brand: Eufy

1. Introduction

Thank you for choosing the Eufy Clean X8 Pro Robot Vacuum with Self-Empty Station. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before using the product and keep it for future reference.

2. Package Contents

Ensure all items listed below are present in your package. If any item is missing or damaged, please contact customer support.

- Eufy Clean X8 Pro Robot Vacuum
- Self-Empty Station
- Power Cord
- Waterproof Pad
- Mop Module
- Cleaning Tool
- Instruction Manual



Image: All components included in the Eufy Clean X8 Pro package. This includes the robot vacuum, the self-empty station, power cord, mop module, and cleaning tools.

3. Setup

3.1 Preparing the Area

- Remove any power cords, small objects, or fragile items from the floor that could entangle the robot or be damaged.
- For optimal performance, ensure the cleaning area is free of excessive clutter.

3.2 Placing the Self-Empty Station

1. Place the Self-Empty Station against a wall on a hard, level surface.
2. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides of the station and 1.5 meters (4.9 feet) in front of it.
3. Connect the power cord to the station and plug it into a wall outlet.
4. Place the waterproof pad under the station if using the mopping function to protect your floor.



Image: Illustration showing the recommended clear space around the self-empty station for proper docking and operation.

3.3 Initial Charging

Place the robot vacuum onto the charging pins of the Self-Empty Station. The robot will automatically begin charging. Fully charge the robot before its first use (approximately 6 hours).

3.4 Downloading the Eufy Clean App

For full functionality and control, download the "Eufy Clean" app from the App Store (iOS) or Google Play Store (Android). Follow the in-app instructions to connect your robot vacuum to your Wi-Fi network.

4. Operating the Robot Vacuum

4.1 Starting and Pausing Cleaning

- **Via Robot:** Press the power button on the robot once to start or pause cleaning.
- **Via App:** Open the Eufy Clean app and tap the "Start" or "Pause" button.

4.2 Cleaning Modes

The Eufy Clean X8 Pro offers various cleaning modes accessible through the Eufy Clean app:

- **Auto Clean:** The robot intelligently cleans your home using its iPath Laser Navigation and AI.Map Technology 2.0.
- **Spot Clean:** Cleans a specific area with concentrated suction.
- **Zone Clean:** Allows you to define specific zones on the map for the robot to clean.
- **Custom Clean:** Manually control the robot's movement for targeted cleaning.

4.3 Mopping Function

To use the mopping function:

1. Fill the water tank in the mop module with clean water.
2. Attach the mop cloth to the mop module.
3. Install the mop module onto the robot.
4. Select the desired water flow level (3 levels available) in the Eufy Clean app.



Image: The Eufy Clean X8 Pro performing both vacuuming and mopping functions simultaneously on a hard floor.

4.4 App Features

The Eufy Clean app provides advanced control and customization:

- **Map Management:** View and edit cleaning maps, set no-go zones, and create virtual walls. The robot can store up to 5 floor maps.
- **Suction Power Adjustment:** Adjust suction power based on floor type (BoostIQ™ Technology automatically adjusts suction for carpets).
- **Scheduling:** Set cleaning schedules for automated cleaning.
- **Cleaning History:** Review past cleaning sessions.
- **Child Lock:** Prevent accidental operation by children or pets.



Image: Screenshot of the Eufy Clean mobile application interface, displaying a detailed floor map with cleaning zones and various

control options.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Eufy Clean X8 Pro.

5.1 Emptying the Dustbin (Robot)

While the Self-Empty Station handles most dust collection, it is recommended to periodically check and manually empty the robot's internal dustbin, especially if you notice reduced suction or if the station is not emptying effectively.

5.2 Cleaning the Main Brush

The Eufy Clean X8 Pro features a hair entanglement removal system. However, occasional manual cleaning of the main brush is still recommended.

1. Turn the robot over and remove the brush guard.
2. Lift out the main brush.
3. Use the provided cleaning tool to cut and remove any hair or debris tangled around the brush.
4. Reinsert the main brush and secure the brush guard.



Image: Close-up view of the Eufy Clean X8 Pro's main brush with its unique V-shaped design and integrated comb for automatic hair detangling.

5.3 Cleaning the Side Brushes

Check side brushes regularly for damage or entanglement. Remove any hair or debris. Replace worn brushes as needed.

5.4 Cleaning the Filters

Remove the dustbin and take out the filters. Tap them gently to remove dust. Do not wash HEPA filters with water. Replace filters every 3-6 months depending on usage.

5.5 Cleaning Sensors and Charging Contacts

Wipe the cliff sensors, anti-drop sensors, and charging contacts on both the robot and the station with a dry cloth to ensure proper function.

5.6 Maintaining the Self-Empty Station

The dust bag in the Self-Empty Station typically needs replacement every 2 months, depending on usage and pet hair

volume. Follow the station's indicator or app notification for replacement.

6. Troubleshooting

Problem	Possible Cause	Solution
Robot does not turn on or charge.	Battery is depleted; charging contacts are dirty; power cord is not connected.	Ensure robot is properly docked; clean charging contacts; check power connection.
Robot gets stuck frequently.	Obstacles on the floor; robot is stuck on high carpets or thresholds.	Clear obstacles; use no-go zones in the app; ensure thresholds are within robot's climbing ability.
Reduced suction power.	Dustbin is full; filters are clogged; main brush is tangled.	Empty dustbin; clean/replace filters; clean main brush.
Robot cannot connect to Wi-Fi.	Incorrect Wi-Fi password; router issues; robot too far from router.	Verify password; restart router; move robot closer to router; ensure 2.4GHz network is used.
Self-Empty Station not emptying.	Dust bag is full or improperly installed; suction port is blocked.	Replace dust bag; ensure bag is correctly installed; clear any blockages in the station's suction port.

7. Specifications

Feature	Detail
Brand	Eufy
Model	X8 Pro (T2276)
Suction Power	4000Pa x 2 (Dual Turbines)
Battery Life	Up to 180 minutes
Battery Type	Lithium-Ion
Navigation	iPath Laser Navigation, AI.Map Technology 2.0
Dust Collection	Automatic (Self-Empty Station)
Mopping Function	Yes, with 3 water flow levels
Color	Black
Control Method	Eufy Clean App, On-device buttons
Product Dimensions (Package)	40.9L x 58W x 47.6H cm
UPC/GTIN	194644136833

8. Warranty and Support

8.1 Warranty Information

Eufy provides an 18-month product warranty. By registering as a member on the official Anker Japan online store, your warranty can be automatically extended by an additional 6 months, totaling up to 24 months.



Image: Visual representation of the product warranty: 18 months standard, with an additional 6 months upon registration, for a total of 24 months.

8.2 Customer Support

For any questions regarding the product or delivery, please contact Eufy customer support. Our dedicated team is available to assist you.

- **Online Support:** Visit the official Eufy website for FAQs and support resources.
- **Contact Information:** Refer to the contact details provided in your product packaging or on the official Eufy website.



Image: Icon representing customer support, indicating availability for product inquiries.

Eufy also operates domestic repair centers to provide reliable after-sales service, both within and outside the warranty period.

© 2023 Eufy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4NN6GGY

More documents and user manuals: **https://manuals.plus/**