Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-BC1

User Manual

JOYROOM JR-BC1 ANC True Wireless Earbuds (White)

Model: JR-BC1

Introduction Safety Contents Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the JOYROOM JR-BC1 ANC True Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with Active Noise Cancellation (ANC) and a comfortable, secure fit. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

2. Important Safety Information

- Do not disassemble or modify the earbuds or charging case. This may cause malfunction or damage and will void the warranty.
- Keep the product away from extreme temperatures (hot or cold), direct sunlight, and high humidity.
- Avoid dropping or subjecting the product to strong impacts.
- Do not expose the earbuds or charging case to water beyond their water resistance rating. Ensure the charging port is dry before charging.
- Clean the earbuds and charging case with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Prolonged exposure to loud sounds may cause hearing damage. Adjust volume to a safe level.
- Dispose of the product responsibly according to local regulations. Do not dispose of with household waste.

3. Package Contents

Please check the package for the following items:

- JOYROOM JR-BC1 ANC True Wireless Earbuds (L/R)
- Charging Case
- USB Charging Cable
- Ear Tips (S/M/L sizes)

- User Manual



Image: Package contents of the JR-BC1 earbuds, showing the earbuds, charging case, USB-C charging cable, and the user manual.



Image: The retail packaging for the JOYROOM JR-BC1 ANC TWS Wireless Earbuds, displaying product features and branding.

4. Product Overview

4.1 Earbuds



Image: A close-up of the JOYROOM JR-BC1 earbuds, highlighting the ear tip, main body, and touch control area.

- **Touch Control Area:** For managing playback, calls, and ANC modes.
- **Microphone:** For calls and ANC functionality.
- **Ear Tip:** Ensures a comfortable fit and passive noise isolation.
- **Charging Contacts:** For charging the earbuds inside the case.

4.2 Charging Case



Image: The JOYROOM JR-BC1 earbuds resting in their open charging case, showing the charging indicators.

- **Earbud Slots:** Securely hold and charge the earbuds.
- **Charging Indicator:** Displays the charging status of the case and earbuds.
- **USB-C Charging Port:** For charging the case.
- **Lid:** Protects the earbuds and secures them during charging.



Image: The JOYROOM JR-BC1 earbuds displayed alongside their open charging case, illustrating the separate components.



Image: The JOYROOM JR-BC1 charging case in its closed state, showing the compact design.

5. Setup

5.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and the other end to a 5V USB power adapter (not included) or a computer USB port.
3. The indicator light on the charging case will show the charging status. It will typically turn solid or off when fully charged.
4. Charging time for the case is approximately 1.5-2 hours. Earbuds charge within the case in about 1 hour.



Image: A top-down view of the JOYROOM JR-BC1 earbuds correctly placed within their charging case, ready for charging.

5.2 Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Ensure the earbuds are charged.
2. Open the charging case lid. The earbuds will power on and automatically enter pairing mode. The indicator light on the earbuds will flash (e.g., white and green alternately).
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "JOYROOM JR-BC1" in the list of available Bluetooth devices.
5. Select "JOYROOM JR-BC1" to connect. Once connected, the earbud indicator lights will turn off or flash slowly.
6. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, and then repeat the steps.

Note: The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Open the charging case lid, or take the earbuds out of the case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

6.2 Touch Controls

The JOYROOM JR-BC1 earbuds feature intuitive touch controls on each earbud. The specific functions may vary slightly based on the operating system of your connected device.

Action	Function
Single Tap (L/R)	Play/Pause music; Answer/End call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (L/R)	Activate Voice Assistant (Siri, Google Assistant)
Long Press (L/R, 2 seconds)	Switch ANC/Transparency/Normal Mode
Long Press (L/R, 3 seconds during call)	Reject Incoming Call

6.3 Active Noise Cancellation (ANC)

The JR-BC1 earbuds feature Active Noise Cancellation to reduce ambient noise. You can cycle through different modes:

- **ANC Mode:** Reduces external noise for an immersive listening experience.
- **Transparency Mode:** Allows you to hear your surroundings while listening to audio, useful for awareness.
- **Normal Mode:** ANC and Transparency modes are off.

To switch modes, long press either earbud's touch control area for approximately 2 seconds until you hear an audible prompt indicating the mode change.

7. Maintenance and Care

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use liquids or sprays directly on the product.
- **Ear Tips:** Remove ear tips periodically and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.
- **Avoid Extreme Conditions:** Do not expose the product to extreme temperatures, humidity, or corrosive substances.

8. Troubleshooting

Problem	Possible Solution
Earbuds not pairing with device.	◦ Ensure earbuds are charged. ◦ Place earbuds back in case, close lid, then open to re-enter pairing mode. ◦ Turn off and on Bluetooth on your device. ◦ Forget "JOYROOM JR-BC1" from your device's Bluetooth list and try pairing again. ◦ Ensure no other devices are connected to the earbuds.

Problem	Possible Solution
Only one earbud is working.	◦ Ensure both earbuds are charged. ◦ Place both earbuds back into the charging case, close the lid, and then take them out together. ◦ Perform a factory reset (refer to manufacturer's website or contact support if not detailed in manual).
Earbuds not charging.	◦ Check if the charging cable is securely connected. ◦ Ensure the charging contacts on the earbuds and in the case are clean and free of debris. ◦ Try a different USB cable or power adapter.
Poor sound quality or intermittent connection.	◦ Ensure the earbuds are within the 10-meter Bluetooth range of your device. ◦ Reduce interference by moving away from other wireless devices or obstacles. ◦ Clean the ear tips and ensure a proper seal in your ear. ◦ Try resetting the earbuds.

9. Specifications

Model:	JR-BC1
Brand:	JOYROOM
Connectivity:	True Wireless (Bluetooth)
Special Features:	Active Noise Cancellation (ANC), Water Resistant (IPX4 - assumed based on "Water Resistant" feature and common earbud ratings)
Wireless Range:	Up to 10 meters (33 feet)
Input Voltage:	5V
Dimensions (Case):	Approx. 10 x 5 x 1.27 cm
Weight:	Approx. 150 g (total with case)
Color:	White (as per product title and images)

Note: Specifications are subject to change without notice. Battery life varies by usage and settings.

10. Warranty and Support

10.1 Warranty Information

JOYROOM products are covered by a limited warranty from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, please refer to the warranty card

included in your package or visit the official JOYROOM website.

10.2 Customer Support

If you encounter any issues or have questions regarding your JOYROOM JR-BC1 earbuds, please do not hesitate to contact our customer support team. We are committed to providing excellent service.

- **Email:** [Please refer to the official JOYROOM website or product packaging for specific contact email]
- **Website:** www.joyroom.com (Example, please verify official website)
- **Phone:** [Please refer to the official JOYROOM website or product packaging for specific contact number]

When contacting support, please have your product model (JR-BC1) and proof of purchase ready.

© 2025 JOYROOM. All rights reserved.
This manual is for informational purposes only. JOYROOM reserves the right to make changes to product specifications and features without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4PTXGQV

More documents and user manuals: **https://manuals.plus/**