Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz Party Grill 200 CV Single

Campingaz Party Grill 200 CV Single User Manual

Model: Party Grill 200 CV Single (2000023716)

Introduction

The Campingaz Party Grill 200 CV is a versatile and portable gas stove designed for outdoor use, perfect for camping, picnics, and weekend trips. It offers the flexibility of both a pan support and an enamelled grill rack, allowing for various cooking methods. Its compact design ensures easy transport and storage, with all components fitting neatly inside the unit.
This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Party Grill 200 CV.

Safety Information

WARNING: Failure to follow these instructions could result in fire, explosion, or serious injury.

- **Outdoor Use Only:** This appliance is designed exclusively for outdoor use. Do not operate indoors or in enclosed spaces.
- **Ventilation:** Ensure adequate ventilation during operation.
- **Gas Cartridges:** Use only Campingaz CV300+ or CV470+ gas cartridges. Do not attempt to use other types of gas or cartridges.
- **Leak Checks:** Always perform a leak check after connecting a new gas cartridge or if you suspect a leak. Use soapy water; never use a flame.
- **Hot Surfaces:** The grill and surrounding areas will become extremely hot during use. Allow to cool completely before handling or storing.
- **Children and Pets:** Keep children and pets away from the appliance during operation and while it is cooling down.
- **Stable Surface:** Always place the grill on a stable, level, non-combustible surface.
- **Flammable Materials:** Keep the grill clear of flammable materials, including tents, dry leaves, and clothing.
- **Storage:** Store gas cartridges in a cool, dry, well-ventilated area, away from direct sunlight and heat sources.

Components

The Party Grill 200 CV comes with the following components:

- Main Grill Unit (with integrated burner and piezo ignition)
- Detachable Legs (3)
- Pan Support
- Enamelled Grilling Grid
- Lid (doubles as a wok/pan)
- Spatula





Figure 1: Exploded view showing the lid, grilling grid, pan support, main grill unit, and gas cartridge connection.

Setup

1. **Unpack:** Remove all components from the main grill unit.
2. **Attach Legs:** Securely attach the three detachable legs to the designated slots on the base of the main grill unit. Ensure they click into place for stability.
3. **Connect Gas Cartridge:**
    - Ensure the control knob on the grill is in the "OFF" position.
    - Align the gas cartridge (CV300+ or CV470+) with the connection point on the grill.
    - Push the cartridge firmly onto the connection and twist clockwise until it locks securely. You should hear a click.
    - Perform a leak check: Apply soapy water to the connection point. If bubbles appear, there is a leak. Tighten the connection or replace the cartridge if necessary. Do not proceed if a leak is detected.
4. **Install Cooking Surface:** Place either the pan support or the enamelled grilling grid onto the main grill unit, depending on your cooking needs.
5. **Add Water to Drip Tray (Optional but Recommended):**For easier cleaning and to collect dripping grease, pour a small amount of water into the integrated water compartment at the bottom of the main grill unit.

Operating Instructions

1. **Ignition:**
    - Ensure the gas cartridge is securely connected.
    - Push and turn the control knob counter-clockwise to the "ON" position. You should hear the gas flowing.
    - Simultaneously press the piezo ignition button firmly. You should hear a click and see a flame.
    - If the grill does not ignite after a few attempts, turn the knob to "OFF", wait a minute, and try again.
2. **Adjusting Flame:** Once ignited, rotate the control knob to adjust the flame intensity to your desired cooking temperature.
3. **Cooking:** Place your cookware (pan on pan support) or food (on grilling grid) onto the chosen cooking surface.

4. **Turning Off:** When finished cooking, turn the control knob clockwise to the "OFF" position until the flame extinguishes completely.
5. **Cool Down:** Allow the grill to cool down completely before handling or disassembling. This can take a significant amount of time.

Maintenance and Cleaning

Regular cleaning and maintenance will extend the life of your Party Grill 200 CV.

- **Cool Down First:** Always ensure the grill is completely cool before cleaning.
- **Empty Water Compartment:** If you added water to the drip tray, carefully empty it and dispose of the grease and water mixture responsibly.
- **Grilling Grid and Pan Support:** The enamelled grilling grid and pan support are dishwasher safe for easy cleaning. For stubborn residue, soak in warm, soapy water before scrubbing.
- **Main Unit:** Wipe the main grill unit with a damp cloth and mild detergent. Do not immerse the main unit in water.
- **Burner:** Keep the burner clean and free from food debris. Use a soft brush if necessary.
- **Storage:** Once clean and dry, all components (legs, pan support, grilling grid, spatula) can be stored inside the main grill unit, and the lid can be attached for compact storage and transport.



Figure 2: The integrated water compartment simplifies cleaning by collecting dripping grease.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Grill does not ignite.	Gas cartridge not connected properly. Gas cartridge empty. Control knob not fully open. Piezo igniter faulty or wet.	Ensure cartridge is securely locked. Replace with a new cartridge. Turn knob fully to "ON" position. Allow igniter to dry; if still faulty, use a long match or lighter to ignite manually (with caution).
Flame is weak or inconsistent.	Low gas in cartridge. Burner partially blocked. Improper gas flow.	Replace gas cartridge. Clean burner ports. Ensure gas cartridge is not too cold.
Gas smell detected.	Gas leak.	Immediately turn off gas. Move grill to a well-ventilated area. Perform a leak check with soapy water. Do not use if leak persists. Contact customer support.

Specifications

Feature	Detail
Model Name	Party Grill 200 CV Single
Model Number	2000023716
Power	2000 W (2 Kilowatts)
Gas Consumption	145 g/h
Boiling Time (1L water)	4 Minutes and 18 Seconds
Ignition	Piezo, push and turn
Compatible Gas Cartridges	Campingaz CV300+, CV470+ Valve Gas Cartridge
Run Time (CV300+)	2 Hours 30 Minutes
Run Time (CV470+)	3 Hours
Weight	2.84 kg
Dimensions (Open)	Diameter 32 x 33 cm (with legs) / 12.6"D x 12.6"W x 12.99"H
Material	Steel
Special Feature	Portable

Warranty and Support

For warranty information, technical support, or spare parts, please contact Campingaz customer service. Refer to the packaging or the official Campingaz website for the most up-to-date contact details in your region.
Online Resources: For additional information and product registration, visit the official Campingaz website: www.campingaz.com

© 2024 Campingaz. All rights reserved.
Please recycle this manual responsibly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4QLW9SQ

More documents and user manuals: **https://manuals.plus/**