Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KARACA 153.09.01.0587

Karaca Multifry XXXL Digital Twin Airfryer User Manual

Model: 153.09.01.0587

1. Introduction

Thank you for choosing the Karaca Multifry XXXL Digital Twin Airfryer. This appliance is designed to provide a healthier and more convenient way to prepare a variety of meals using rapid air circulation technology. With its dual 4+4 liter baskets and 1700W power, you can cook two different dishes simultaneously or larger portions of a single dish. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow adequate air circulation.

- The appliance will automatically shut off after cooking is complete.

3. Product Overview

The Karaca Multifry XXXL Digital Twin Airfryer features a sleek design with two independent cooking zones, allowing for versatile meal preparation.



Figure 3.1: Front view of the Karaca Multifry XXXL Digital Twin Airfryer, showcasing the digital control panel and dual baskets.



Figure 3.2: Side view of the airfryer, highlighting its compact design.

Components:

- **Main Unit:** Houses the heating element, fan, and control panel.
- **Digital Control Panel:** Touchscreen interface for setting time, temperature, and cooking modes.
- **Cooking Baskets (x2):** Non-stick, fire-resistant baskets with handles for holding food.
- **Crisper Plates (x2):** Removable plates placed inside the baskets to allow air circulation around food.



Figure 3.3: The two independent cooking baskets with handles.



Figure 3.4: A single crisper plate, designed to fit inside the cooking basket.

4. Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Check that all components are present and undamaged.

Cleaning Before First Use:

1. Wipe the exterior of the main unit with a damp cloth.
2. Wash the cooking baskets and crisper plates in warm, soapy water. Rinse thoroughly and dry completely. These parts are also dishwasher safe.
3. Do not immerse the main unit in water or any other liquid.

Placement:

1. Place the airfryer on a stable, level, and heat-resistant surface.
2. Ensure there is at least 10 cm (4 inches) of free space around the back and sides of the appliance to allow for proper ventilation.
3. Do not place the airfryer directly under a wall cabinet, as steam may cause damage.

5. Operating Instructions

The Karaca Multifry XXXL Digital Twin Airfryer allows you to cook a variety of foods with minimal oil. It features a digital control panel for easy operation.

Basic Operation:

1. **Prepare Food:** Place your ingredients into the cooking baskets, ensuring not to overfill. For best results, place the crisper plate at the bottom of each basket.
2. **Insert Baskets:** Slide the baskets firmly into the main unit.
3. **Power On:** Plug the airfryer into a grounded wall outlet. The digital display will illuminate.
4. **Select Cooking Zone:** Press the '1' or '2' button on the control panel to select the basket you wish to program.
5. **Choose Cooking Mode:** Select one of the 7 pre-set cooking modes (e.g., fries, chicken, fish, meat, vegetables, cake, reheat) or manually set the temperature and time.
6. **Adjust Settings:** Use the temperature and time adjustment buttons to set your desired cooking parameters.
7. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle.
8. **Shake Reminder:** For some foods, the airfryer may beep to remind you to shake the basket for even cooking.
9. **Finish:** The airfryer will beep and automatically shut off when the cooking cycle is complete. Carefully remove the baskets and transfer food.



Figure 5.1: The airfryer in operation, demonstrating simultaneous cooking of different food items in each basket.

Dual Zone Cooking Features:

- **Sync Finish:** This function allows you to set different cooking times and temperatures for each basket, and the airfryer will automatically synchronize them to finish cooking at the same time.
- **Match Cook:** Use this function to easily apply the same cooking settings (time and temperature) from one basket to the other, ideal for cooking larger quantities of the same food.



Figure 5.2: The airfryer shown in a kitchen setting, illustrating its use in preparing a full meal.

6. Maintenance and Cleaning

Regular cleaning of your Karaca Multifry XXXL Digital Twin Airfryer will ensure its longevity and optimal performance.

Cleaning Procedure:

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Clean Baskets and Crisper Plates:** The non-stick cooking baskets and crisper plates are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse and dry thoroughly.
3. **Clean Exterior:** Wipe the exterior of the airfryer with a damp cloth. Do not use harsh abrasive cleaners or scouring pads, as they may damage the surface.
4. **Clean Interior:** If necessary, wipe the interior of the appliance with a damp cloth. Ensure no food particles are left behind.
5. **Storage:** Once clean and dry, store the airfryer in a cool, dry place.

Note: Do not immerse the main unit in water or any other liquid.

7. Troubleshooting

If you encounter any issues with your airfryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Airfryer does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the problem persists, contact customer support.
Food is not cooked evenly.	Baskets are overfilled; food not shaken or flipped.	Do not overfill baskets. Shake or flip food halfway through cooking for even results.
White smoke comes from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the baskets and crisper plates thoroughly after each use. For fatty foods, ensure excess fat is drained.
Plastic smell during first use.	New appliance odor.	This is normal for new appliances and will dissipate after a few uses. Ensure good ventilation.

8. Specifications

Feature	Specification
Brand	KARACA
Model Number	153.09.01.0587
Color	Inox (Stainless Steel)
Product Dimensions (L x W x H)	41 x 38 x 33 cm
Weight	9.54 Kilograms
Capacity	2 x 4 Liters (Total 8 Liters)
Power	1700 Watts
Voltage	230 Volts (AC)
Material	Stainless Steel
Special Feature	Roasting, Digital Control, Dual Zone, 7 Pre-set Modes, Sync Finish, Match Cook
Recommended Uses	Bake, Grill, Roast
Country of Origin	China

9. Warranty and Support

Information regarding specific warranty details and customer support contact methods is not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for warranty registration and

support contact information.

© 2023 KARACA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C58N5YBJ

More documents and user manuals: **https://manuals.plus/**