Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KEMEI KM-1071

KEMEI Hair Clippers User Manual

Model: KM-1071

Professional Barber Clipper for Hair Cutting Cordless & Corded, Rechargeable Beard Trimmer

Product Overview

The KEMEI KM-1071 Hair Clipper is a versatile and professional tool designed for both hair cutting and beard trimming. This comprehensive set provides everything needed for a precise and comfortable grooming experience, whether at home or in a professional setting.



Figure 1: KEMEI Hair Clipper and Included Accessories. This image displays the main clipper unit, various guard attachments, a comb, lubricating oil, a cleaning brush, and a USB charging cable.

Key Features:

- **Professional Hair Clippers:** Includes electric hair clipper, lubricating oil, cleaning brush, comb, USB charging cable, and guard attachments (3/6/10/13/16/19 mm) for various hair lengths (0.5-2 mm).
- **Cord & Cordless Operation:** Offers flexibility for prolonged use with cord or portability for travel without.
- **Powerful Motor & Strong Blade:** Features a 6500 RPM motor for efficient cutting of thick hair, operating quietly at less than 37 decibels.
- **Long-Lasting Battery:** Provides 240 minutes of continuous usage after a 3-hour charge.
- **4 Adjustable Gear Strength:** Allows for precise control over cutting power, indicated by LED lights.

Safety Information

Please read all safety warnings and instructions before using the KEMEI Hair Clipper to prevent injury or damage to the device.

- May cause skin irritation or eye injury.
- Do not use on wet hair.
- Do not use while charging.
- Keep away from water sources.
- Always unplug when not in use.
- Do not use on infants or children.
- Follow recommended cleaning and maintenance procedures.
- Do not plug in the charging cable with wet hands; otherwise there will be electric shock.
- Do not dip the machine body or the charging box into water or wash it; otherwise there will be electric shock or short circuit.
- Pull out the plug by holding the plug; do not pull out by dragging the wire, or it may cause electric shock, short circuit or fire.
- Do not use gasoline or water to clean the clipper.
- Please do not transform, disassemble or repair the product on your own; otherwise it may create electric shock, short circuit or fire.

Setup

1. Initial Charge

Before first use, fully charge the clipper. Connect the USB charging cable to the clipper's charging port and plug the other end into a compatible USB power source (e.g., computer, wall adapter). The LED power indicator will show charging status.



Figure 2: LED Power Indicator. Red light indicates charging, green light indicates charge complete.

2. Oiling the Blades

For optimal performance and longevity, apply a few drops of the included lubricating oil to the blades before each use, especially the first use. Turn the clipper on for a few seconds to distribute the oil evenly.



Figure 3: Oiling the Blades. Apply oil to the top and sides of the blades for smooth operation.

3. Attaching Guard Combs

Select the desired guard attachment (3/6/10/13/16/19 mm) based on the hair length you wish to achieve. Align the guard with the clipper blade and push firmly until it clicks into place.



Figure 4: Guard Comb Attachments. A selection of six different sized guard combs are included for various cutting lengths.

Operating Instructions

1. Powering On/Off

To turn the clipper on, slide the power switch located on the side of the unit upwards. To turn it off, slide the switch downwards.

2. Adjusting Taper Lever

The clipper features an adjustable taper lever on the side, allowing for fine-tuning of cutting lengths between 0.5mm and 2mm without changing guard combs. Move the lever up for a closer cut and down for a longer cut.



Figure 5: Taper Lever Adjustment. The lever allows for precise length control from 0.2mm to 0.5mm.

3. Adjusting Gear Strength

The clipper offers 4 adjustable gear strengths to handle different hair types and thicknesses. Press the power button repeatedly to cycle through the gears. The gear indicator lights up above the corresponding symbol (slow, medium, fast, fastest).

4. Hair Cutting and Trimming

Ensure hair is clean and dry before cutting. For best results, cut against the direction of hair growth. Use smooth, even

strokes. For beard trimming, use appropriate guard combs and follow the contours of your face.



Figure 6: Professional Use. A barber demonstrates using the KEMEI hair clippers for a precise haircut.

Maintenance

1. Cleaning the Blades

After each use, turn off and unplug the clipper. Use the included cleaning brush to remove any loose hairs from the blades. For a more thorough cleaning, the blades can be carefully detached and rinsed under running water, ensuring the main body of the clipper does not get wet. Dry thoroughly before reattaching.

2. Regular Oiling

Continue to oil the blades regularly (before each use or as needed) to maintain cutting efficiency and prevent rust. This is crucial for the longevity of the clipper.

3. Storage

Store the clipper and its accessories in a dry, cool place, away from direct sunlight and moisture. Keep out of reach of children.

Troubleshooting

If you encounter any issues with your KEMEI Hair Clipper, please refer to the following common solutions:

Problem	Possible Cause	Solution
Clipper not turning on.	Low battery; Power switch off.	Charge the clipper fully; Ensure power switch is in the 'ON' position.
Blades pulling hair or cutting poorly.	Blades are dull, dirty, or not oiled; Hair is too thick for current gear setting.	Clean and oil the blades; Try a higher gear strength; Consider professional sharpening if blades are dull.
Clipper making unusual noise.	Blades need oiling; Debris caught in blades.	Apply lubricating oil to blades; Clean blades thoroughly.
Battery not holding charge.	Battery degradation; Improper charging.	Ensure proper charging cable and power source are used. If issue persists, contact customer support.

Specifications

Feature	Detail
Product Dimensions	8.19 x 5.39 x 2.44 inches
Item Model Number	KM-1071
Batteries	1 AAA batteries required (included)
Item Weight	13.4 ounces (0.38 Kilograms)
Manufacturer	KEMEI
Color	Black
Hair Type Compatibility	Wet or Dry
Charging Time	3 hours
Continuous Usage Time	240 minutes
Motor Speed	6500 RPM
Noise Level	Less than 37 decibels

Warranty and Support

KEMEI offers a one-year warranty for this product. To activate your warranty and potentially receive an extra 1-month warranty and discount code, please register your product within 7 days of receiving your item.
For further warranty information or support, please visit the official KEMEI website:

www.kemei.live

KEMEI is committed to providing high-quality personal care appliances and ensuring customer satisfaction. Our products are inspected by professional testing organizations, and we pay meticulous attention to every detail to ensure that our customers are able to use products of superior quality.

© 2024 KEMEI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5CS62RG

More documents and user manuals: **https://manuals.plus/**