Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi KYN01011

Sky Viper Force Hover Sphere Instruction Manual

Model: KYN01011
Brand: Giochi Preziosi

Introduction

The Sky Viper Force Hover Sphere is an innovative gesture-controlled drone designed for intuitive and engaging flight. It features advanced motion sensors that allow it to react to hand movements, eliminating the need for a traditional remote control. This manual provides essential information for safe operation, setup, and maintenance of your Hover Sphere.

Safety Information

WARNING: This toy produces flashes that may trigger epilepsy in sensitized individuals.
Conforms to product safety standards ASTM F963. Not suitable for children under 3 years.**CHOKING HAZARD - Small Parts.**
Remove and discard wire ties before giving this product to children. Product colors and styles may vary from those shown. Retain this package for future reference.

Battery Specifications & Cautions:

- This toy contains batteries that are non-replaceable.
- Batteries are only to be charged.
- Non-rechargeable batteries are not to be recharged.
- Batteries are to be inserted using correct polarity.
- The supply terminals are not to be short circuited.

THIS PRODUCT CONTAINS A LITHIUM-POLYMER BATTERY 3.7V 300mAh: LiPo batteries have a severe risk of fire and injury if they are improperly handled or misused. Read all enclosed instructions, warnings and precautions regarding the care, use and disposal of LiPo batteries. The enclosed LiPo battery is only to be used with the drone and charger included with this product.
ADULT SUPERVISION REQUIRED: Read all enclosed instructions, warnings and precautions regarding the care and use of LiPo batteries. An adult should periodically check this product and the LiPo battery to ensure no damage or hazards exist. Spinning blades can cause injury. Adequate flying space is required. Keep a safe distance away from streets, public thoroughfares, bodies of water and powerlines. Be mindful of spectators. Read all enclosed information before operating.

What's in the Box

- Sky Viper Force Hover Sphere Drone
- 1x USB charging cable
- Built-in Lithium Ion Battery (3.7V 300mAh)



Image: The Sky Viper Force Hover Sphere drone shown with its included USB charging cable.

Setup

Charging the Hover Sphere:

1. Locate the charging port on the Sky Viper Force Hover Sphere.
2. Connect the included USB charging cable to the drone's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light on the drone will illuminate during charging and turn off or change color when fully charged.
5. A full charge provides approximately 5-6 minutes of flight time.



Image: A side view of the Sky Viper Force Hover Sphere, highlighting the location of the charging port.

Operating Instructions

Powering On and Initial Flight:

1. Ensure the Hover Sphere is fully charged.
2. Gently toss the drone into the air. It will automatically power on and begin to hover stably.
3. The drone's motion sensors will detect its surroundings and maintain a stable hover.



Image: A young boy smiling and interacting with the Sky Viper Force Hover Sphere as it hovers in the air, demonstrating its hand-controlled nature.

Gesture Control:

The Sky Viper Force Hover Sphere is controlled by hand gestures, utilizing its built-in motion sensors.

- **Pushing the Drone:** Move your hand towards the drone to gently push it in a desired direction. The drone will sense your hand and move away from it.
- **Controlling Altitude:** Place your hand underneath the drone to make it ascend. Move your hand away to allow it to descend.
- **Stopping the Drone:** To stop the drone, place your hand over the top of the drone and move it downwards. The drone will sense your hand and power down.
- **Trick Maneuvers:** For a neat trick, start with your hand over the drone and move it around until your hand is below the drone. This can initiate unique flight patterns.



Image: A young boy waving his hand to direct the Sky Viper Force Hover Sphere, illustrating the intuitive gesture control.



Image: A teenager holding their hand beneath the Sky Viper Force Hover Sphere, demonstrating how to control its altitude or perform a trick.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the drone. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the drone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the drone before storing it for extended periods.
- **Impact Resistance:** While designed to be impact resistant, repeated severe crashes can cause damage. Inspect the drone for any cracks or loose parts after significant impacts.

Troubleshooting

Problem	Possible Cause	Solution
Drone does not power on or fly.	Battery is not charged or is low.	Ensure the drone is fully charged using the provided USB cable.
Drone does not respond to hand gestures.	Sensors are obstructed or dirty. Incorrect gesture technique.	Ensure sensors are clean and unobstructed. Review the "Operating Instructions" section for correct gesture techniques. Ensure adequate lighting.
Short flight time.	Battery not fully charged. Normal battery degradation over time.	Ensure battery is fully charged before each use. Flight time is approximately 5-6 minutes per charge.
Drone crashes frequently.	Lack of adequate flying space. User unfamiliarity with controls.	Practice flying in an open, clear area. Review gesture control techniques.

Specifications

- **Model Name:** Sky Viper Force Hover Sphere
- **Item Model Number:** KYN01011
- **Product Dimensions:** 12 x 6 x 12 cm
- **Item Weight:** 160 Grams
- **Battery:** 1 Lithium Ion battery (3.7V 300mAh), included and non-replaceable
- **Charging:** USB charging cable included
- **Material Type:** Plastic
- **Color:** Black and Green
- **Recommended Age:** 6 months - 8 years (Manufacturer recommended, but product description states 8+ and Adults)
- **Assembly Required:** No
- **Remote Control:** Not required (Gesture-controlled)
- **Max Running Time:** Approximately 0.08 hours (5-6 minutes)
- **Max Speed:** 5 miles per hour

Warranty and Support

For warranty information and customer support, please refer to the packaging or contact Giochi Preziosi customer service directly. Keep your proof of purchase for any warranty claims.

Giochi Preziosi Contact Information: Please visit the official Giochi Preziosi website or refer to the contact details provided on the product packaging for support.

© 2024 Giochi Preziosi. All rights reserved.
Sky Viper Force Hover Sphere is a trademark of Giochi Preziosi.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5N94ZK9

More documents and user manuals: **https://manuals.plus/**