Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy 2SKSK1847B0L2

Skullcandy Terrain Wireless Bluetooth Speaker - User Manual

Model: 2SKSK1847B0L2

Introduction

This user manual provides essential information for the proper setup, operation, and maintenance of your Skullcandy Terrain Wireless Bluetooth Speaker. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The Skullcandy Terrain is a durable, portable Bluetooth speaker designed for adventure. It features IPX7 waterproofing, dual custom passive radiators for powerful bass, and a long-lasting 14-hour battery. It also supports Multi-Link technology, allowing connection with up to 99 other Skullcandy speakers.





Figure 1: Front view of the Skullcandy Terrain Wireless Bluetooth Speaker in black, showcasing its mesh grille and top controls.

What's in the Box

- SKDY Terrain™ Wireless Speaker
- 1 x 3FT C-to-A Charging Cable
- 1 x Wrist Strap
- 1 x User Manual (this document)

Setup

Charging the Speaker

Before first use, fully charge your Skullcandy Terrain speaker. Connect the provided 3FT C-to-A Charging Cable to the

USB-C port on the speaker and plug the other end into a compatible USB power adapter (not included).



Figure 2: Detail of the USB-C charging port and battery indicator lights on the side of the speaker.

The battery indicator lights will show charging progress. A full charge provides up to 14 hours of playtime.

Powering On/Off

To power on the speaker, press and hold the power button located on the top panel until you hear an audible cue and the indicator lights illuminate. To power off, press and hold the power button again.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Skullcandy Terrain" from the list of devices.
4. Once connected, the indicator light will turn solid, and you will hear a confirmation tone.

The speaker can only be connected to one device at a time.

Controlling Playback

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Multi-Link Feature

The Skullcandy Terrain speaker supports Multi-Link technology, allowing you to connect up to 99 Skullcandy speakers for a synchronized audio experience. To activate Multi-Link:

1. Ensure all speakers are powered on and not connected to any Bluetooth device.
2. On the primary speaker (the one you want to connect to your device), press the Multi-Link button.
3. On the secondary speakers, press their Multi-Link buttons. They will automatically search and connect to the primary speaker.
4. Once all desired speakers are linked, connect your device to the primary speaker via Bluetooth as described above.



Figure 3: Multiple Skullcandy Terrain speakers connected via the Multi-Link feature for expanded sound coverage.

Maintenance

Cleaning

To clean your speaker, use a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the USB-C port cover is securely closed before cleaning or exposing to water.

Water Resistance (IPX7)

The Skullcandy Terrain speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter (3 feet) for up to 30 minutes. While designed for water exposure, it is recommended to dry the speaker thoroughly after contact with water, especially the charging port, before charging or prolonged storage.



Figure 4: The Skullcandy Terrain speaker's IPX7 waterproof capability, shown with speakers in water.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully using the provided USB-C cable.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device too far; previously connected to another device.	Ensure speaker is in pairing mode. Move device closer. Disconnect from other devices or reset speaker's Bluetooth connection.
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and connected device. Re-establish Bluetooth connection.

Problem	Possible Cause	Solution
Multi-Link not working.	Speakers already paired to a device; incorrect linking procedure.	Ensure all speakers are disconnected from Bluetooth devices before initiating Multi-Link. Follow Multi-Link instructions carefully.

Specifications

- **Model Name:** 2SKSK1847
- **Item Model Number:** 2SKSK1847B0L2
- **Dimensions:** 3.1"D x 3.1"W x 6.3"H
- **Weight:** 0.46 Kilograms (1.01 pounds)
- **Waterproof Rating:** IPX7 (Submersible up to 1 meter for 30 minutes)
- **Battery Life:** Up to 14 Hours
- **Charging Port:** USB-C
- **Wireless Technology:** Bluetooth v5.3
- **Bluetooth Range:** 10 Meters
- **Audio Output Mode:** Stereo
- **Speaker Maximum Output Power:** 3 Watts
- **Frequency Response:** 30 Hz
- **Included Components:** Speaker, USB-C Charging Cable, Wrist Strap, User Manual

Warranty and Support

The Skullcandy Terrain Wireless Bluetooth Speaker comes with a **Limited Warranty**. For detailed warranty information, including terms and conditions, please refer to the official Skullcandy website or contact Skullcandy customer support. For technical support, troubleshooting assistance, or warranty claims, please visit the Skullcandy Support Page or contact their customer service directly.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5YYPJQX

More documents and user manuals: **https://manuals.plus/**