Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Erivess wash 02

Erivess Portable Twin Tub Washing Machine (Model: wash 02) - Instruction Manual

Your guide to efficient and convenient laundry.

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your Erivess Portable Twin Tub Washing Machine, Model wash 02. Please read this manual thoroughly before operating the appliance and retain it for future reference. This semi-automatic washing machine is designed for small loads, ideal for apartments, dormitories, RVs, and other spaces where a compact laundry solution is required.



Figure 1: Erivess Portable Twin Tub Washing Machine.

2. Important Safety Instructions

- Always place the washing machine on a flat, stable surface to prevent tipping or excessive vibration during operation.
- Ensure the machine is operated in an area where water spills will not cause damage, such as a tiled bathroom or shower stall. Avoid wooden floors or carpets.
- Do not overload the wash or spin tubs. Overloading can damage the motor and reduce washing efficiency.
- Keep the power cord away from water and heat sources. Always unplug the machine when not in use or before cleaning.
- Do not allow children to operate or play with the washing machine.
- Never reach into the tubs while the machine is operating.

3. Setup

3.1 Unpacking

Carefully remove the washing machine from its packaging. Check for any damage during transit. Ensure all accessories, including the inlet hose and drain hose, are present.

3.2 Placement

Place the washing machine on a firm, level surface. Ideal locations include a shower stall, bathtub, or a tiled utility area. The machine should be positioned near a water source and a drain.



Figure 2: Suitable placement environments for the portable washing machine.

3.3 Connecting Water Inlet

Connect the provided inlet hose to the 'Water Inlet' port on the top of the machine. The other end of the hose can be attached to a faucet. Alternatively, you can manually fill the wash tub using a shower head or a bucket for faster filling.



Figure 3: Water Inlet and Drain Hose connections.

3.4 Positioning the Drain Hose

Ensure the drain hose is positioned to allow water to flow directly into a drain (e.g., shower drain, sink). The machine uses gravity drainage, so the hose must be lower than the machine's base for effective draining.

4. Operating Instructions

4.1 Washing Clothes

1. **Load Clothes:** Place clothes into the wash tub. Do not overfill; ensure there is enough space for clothes to agitate freely. The maximum washing capacity is 11 lbs.
2. **Add Water:** Fill the wash tub with water to your desired level. If using the inlet hose, monitor the water level closely as there is no automatic shut-off.
3. **Add Detergent:** Add a small amount of liquid or powder laundry detergent. For this compact machine, you will typically need less detergent than for a standard washing machine. Avoid pre-measured laundry pods as they may contain too much detergent for small loads.
4. **Set Wash Timer:** Turn the 'Wash Timer' knob to select the desired washing time (up to 15 minutes).
5. **Select Wash Mode:** Turn the 'Select Switch' knob to 'Soft' for delicate items or 'Standard' for regular clothes.
6. **Start Washing:** The machine will begin agitating. Close the lid during operation.



Figure 4: Control Panel for setting wash time and mode.



Figure 5: Washing and Spinning Capacities.

4.2 Draining Water

1. Once the wash cycle is complete, turn the 'Select Switch' knob to 'Drain'.
2. Ensure the drain hose is positioned downwards into a drain. The water will drain out by gravity.

4.3 Spinning Clothes

1. **Transfer Clothes:** Move the washed clothes from the wash tub to the spin tub. Do not overload the spin tub (maximum 7 lbs).
2. **Secure Clothes:** Place the cover plate over the clothes inside the spin tub to prevent high-speed shaking.
3. **Rinse (Optional):** For a rinse cycle, fill the spin tub with clean water (manually or via shower head) and run the spin timer for 1-2 minutes. Then drain the water.
4. **Spin Dry:** Set the 'Spin Timer' knob to the desired spin time (up to 5 minutes). The clothes will be spun to remove excess water, leaving them damp.

▶ **Watch video online**
Erivess Portable Mini Twin Tub Washing Machine(22 lbs)

Video 1: Erivess Portable Mini Twin Tub Washing Machine in action.

5. Maintenance

5.1 Cleaning the Machine

- After each use, wipe down the interior and exterior of the machine with a soft, damp cloth.
- Do not use abrasive cleaners or solvents that could damage the plastic surfaces.

5.2 Cleaning the Lint Filter

The wash tub is equipped with a detachable lint filter. Regularly remove and clean the lint filter to maintain optimal washing performance and prevent lint buildup on clothes.



Figure 6: Detachable Lint Filter.

6. Troubleshooting

Problem	Possible Cause	Solution
Machine does not start	Not plugged in; Power outage; Timer not set.	Check power connection; Verify power supply; Set wash/spin timer.
Water does not drain	Drain hose is not positioned correctly (too high); Drain hose is kinked or blocked.	Ensure drain hose is lower than the machine; Straighten the hose; Clear any blockages.
Excessive vibration/noise	Machine is not on a level surface; Clothes are unevenly distributed in the spin tub; Overloaded tub.	Adjust machine placement; Redistribute clothes evenly; Reduce load size.
Water overflow	Water inlet left unattended.	Always monitor water level when filling manually or via inlet hose.

7. Specifications

Feature	Detail
Brand	Erivess
Model Number	wash 02 (ST-8)
Washing Capacity	11 lbs (5 kg)
Spinning Capacity	7 lbs (3.2 kg)

Feature	Detail
Washing Power	300 Watts
Spinner Power	110 Watts
Voltage	110 Volts
Amperage	15 Amps
Product Dimensions	15"D x 23.5"W x 26.6"H
Item Weight	7.9 Pounds
Operation Mode	Semi-Automatic
Drum Material	Plastic/Enamel-coated Steel
Included Components	Cover

8. Warranty Information

This product comes with a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to the warranty card included in your product packaging or contact Erivess customer support.

9. Customer Support

Should you encounter any issues or have questions not covered in this manual, please contact Erivess customer support. Contact information can be found on the product packaging or our official website.

© 2023 Erivess. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6H2YRWV

More documents and user manuals: **https://manuals.plus/**